
FastReporter 2

Post-Processing Software



Copyright © 2007–2017 EXFO Inc. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, be it electronically, mechanically, or by any other means such as photocopying, recording or otherwise, without the prior written permission of EXFO Inc. (EXFO).

Information provided by EXFO is believed to be accurate and reliable. However, no responsibility is assumed by EXFO for its use nor for any infringements of patents or other rights of third parties that may result from its use. No license is granted by implication or otherwise under any patent rights of EXFO.

EXFO's Commerce And Government Entities (CAGE) code under the North Atlantic Treaty Organization (NATO) is 0L8C3.

The information contained in this publication is subject to change without notice.

Trademarks

EXFO's trademarks have been identified as such. However, the presence or absence of such identification does not affect the legal status of any trademark.

Units of Measurement

Units of measurement in this publication conform to SI standards and practices.

Version: 16.0.1.1

Licence Agreement and Warranty

IMPORTANT: CAREFULLY READ THE FOLLOWING LICENSE AGREEMENT BEFORE OPENING THIS INSTALLATION PACKAGE. BY OPENING THIS PACKAGE AND USING THE SOFTWARE WHETHER INCORPORATED OR NOT IN AN EXFO INC. ("EXFO") PRODUCT, YOU INDICATE YOUR ACCEPTANCE TO BE BOUND BY THE TERMS AND CONDITIONS OF THIS AGREEMENT. IF YOU DO NOT ACCEPT THE TERMS AND CONDITIONS OF THIS LICENSE AGREEMENT, DO NOT OPEN THIS PACKAGE AND PROMPTLY RETURN THE PRODUCT OR SOFTWARE WITH YOUR PROOF OF PAYMENT, WHEREUPON YOUR MONEY WILL BE REFUNDED.

THE PRODUCT OR SOFTWARE YOU ORDERED MIGHT INCLUDE SOURCE CODE AND/OR SOFTWARE COMPONENTS, IT IS PROVIDED FOR YOUR CONVENIENCE IN MODIFYING THE PRODUCT OR SOFTWARE TO SUIT YOUR SPECIFIC NEEDS, OR TO CREATE DERIVATIVE WORKS INCLUDING SOURCE AND LIBRARY FILES IF APPLICABLE.

THE PRODUCT AND THE SOFTWARE MUST BE USED ONLY FOR YOUR INTERNAL BUSINESS OPERATION AND ITS INTENDED APPLICATION. YOU MAY NOT COPY OR USE THE SOURCE CODE OR THE SOFTWARE COMPONENTS TO PRODUCE OTHER SOFTWARE DEVELOPMENT TOOLS FOR DISTRIBUTION AND RESALE WITHOUT EXPRESS WRITTEN PERMISSION FROM EXFO. EXFO RETAINS ALL RIGHTS TO THE SOURCE CODE, THE SOFTWARE COMPONENTS AND ALL MODIFICATIONS THEREOF. YOU SHALL RESPECT AND COMPLY WITH ANY OF THE PROVISIONS LISTED BELOW WHICH MAY ALSO BENEFIT ANY GIVEN THIRD PARTY BENEFICIARY AS DEFINED HEREIN.

1. DEFINITIONS: The following definitions apply to the terms in the Agreement.

"Documentation" means the user's manual and other printed materials accompanying the Software.

"Product" means the EXFO instrument designed for use with the Software, as the case may be.

"Software" means the computer programs, source code and software components contained therein and all updates and upgrades thereto. The term also includes all copies of any part of the computer program, source code or software components.

2. GRANT OF LICENSE: EXFO grants to you, the purchaser of the enclosed Software, a limited, restricted, non-exclusive license. You shall use the Software only in conjunction with its purpose or in conjunction with the Product, subject to the limitations on use and disclosure contained herein and in the Documentation. You may:

- Use the Software on a network, file service or virtual disk; provided that access is limited to one user at a time and that you have the original copy of the Documentation and Software media.
- Make one (1) copy of the Software for backup or modification purposes in support of the use of the Software on a single computer.
- Merge the Software or incorporate the same into another program provided that such a program will, for so long as the Software is included therein, be subject to all of the terms and conditions of this Agreement.

You may not:

- Make copies of the Documentation.
- Assign, give or transfer the Software, any services or interests in the Software, to another individual or entity. Sublicense, lease, time-share, service bureau, lend, use for subscription service or rental use any portion of the Product, the Software, or your rights under this Agreement.
- Reverse engineering, disassemble or decompile in whole or in part the Software or the Product.
- Publish any result of benchmark tests run on the Software or the Product.

YOU RECOGNIZE THAT THE SOURCE CODE AND THE SOFTWARE COMPONENTS COMPRISING THE SOFTWARE ARE HIGHLY VALUABLE TRADE SECRETS OF EXFO OR ANY GIVEN THIRD PARTY BENEFICIARY AND THAT EXFO WISHES TO PREVENT THEIR DISCLOSURE TO YOU, OR ANY THIRD PARTY.

3. SOFTWARE OWNERSHIP: The Software is licensed, not sold. Title to the Software shall not be passed to you or to any other party. All applicable rights to patents, copyrights, trademarks and trade secrets in the Software, or any modifications made at your request, are and shall remain the property of EXFO.

4. AUDITS: EXFO reserves its right to audit, at its convenience, your use of the Software.

5. TERMS OF TERMINATION: This Agreement shall remain in full force and effect until you discontinue use of the Software or the Product, until the end of the life of the Product or Software or until this Agreement is terminated, whichever occurs earlier. Without prejudice to its other rights, EXFO may terminate this Agreement if you fail to comply with the terms thereof. In such event, you must destroy or return all copies of the Software and Documentation as requested in writing by EXFO. You shall be liable for all damages to EXFO as a result of the breach whether or not you were notified of the likelihood of such damages.

EXFO retains all rights to the Software not expressly granted hereunder. Nothing in this Agreement constitutes a waiver of the rights of EXFO or any Third Party Beneficiary.

6. LIMITED WARRANTY: EXFO warrants the media on which the Software is distributed to be free from defects in material and workmanship and that the Software will perform substantially in accordance with the Documentation. EXFO will replace defective media or Documentation at no charge, provided you return the item with dated proof of payment to EXFO within (60) days of the date of delivery. THESE ARE YOUR SOLE REMEDIES FOR BREACH OF WARRANTY. EXCEPT AS SPECIFICALLY PROVIDED ABOVE, EXFO MAKES NO WARRANTY OR REPRESENTATION, EITHER EXPRESS OR IMPLIED WITH RESPECT TO THE SOFTWARE OR DOCUMENTATION INCLUDING THEIR QUALITY, PERFORMANCE, MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE.

7. LIMITATIONS OF LIABILITY: Because software is inherently complex and may not be completely free of errors, you are advised to verify your work. IN NO EVENT WILL EXFO, ITS DEALERS, DISTRIBUTORS, RESELLERS, OR THIRD PARTY BENEFICIARY, BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, INCLUDING LOST PROFITS, DOWNTIME OR DAMAGES TO PROPERTY ARISING OUT OF THE USE OF OR INABILITY TO USE THE SOFTWARE OR DOCUMENTATION, even if advised of the possibility of such damages. THE WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS, ORAL OR WRITTEN, EXPRESS OR IMPLIED. No dealer, distributor, agent or employee is authorized to make any modification or addition to this warranty. Some US States or applicable local legislation do not allow the exclusion or limitation of implied warranties or limitation of liability for incidental or consequential damages, so the above limitation or exclusion may not apply to you.

8. U.S. GOVERNMENT RESTRICTED RIGHTS: The Software and Documentation are provided with RESTRICTED RIGHTS. Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c) (1) (ii) of The Rights in Technical Data and Computer Software clause at 52.227-7013. EXFO headquarters are located at 400 Godin Avenue, Quebec, Quebec, G1M 2K2, Canada.

9. EXPORT AND IMPORT LAWS: You must comply fully with all applicable export and import laws including, but not limited to, export laws and regulations of the United States of America. No Programs, Products or Software shall be exported, directly or indirectly, in violation of laws.

10. THIRD PARTY BENEFICIARY: EXFO may designate, from time to time, any Third Party Beneficiary, with respect to any Product or Software, which has duly executed a prior writing agreement with EXFO. Third Party Beneficiaries may include, but are not limited to, namely ORACLE, Business Objects, Advance Fiber Optics, and MapInfo. The terms of this Agreement also governs any source code that may be provided in some programs by Third Party Beneficiary, such as the one mentioned above. This Agreement is not intended to be for the benefit of and shall not be enforceable by any given Third Party Beneficiary without a prior written agreement duly executed with EXFO.

11. GENERAL: This Agreement constitutes the entire agreement between you and EXFO as concerns the subject matter hereof and supersedes any prior agreement as to such subject matter. If any provision of this Agreement shall be deemed to be invalid, illegal or unenforceable, the validity, legality and enforceability of the remaining portions of this Agreement shall not be affected or impaired thereby. This Agreement shall be governed by and construed in accordance with the laws applicable in the province of Quebec, Canada without regards to its conflict of laws provisions.

BY USING THE SOFTWARE, YOU ACKNOWLEDGE THAT YOU HAVE READ THIS AGREEMENT, THAT YOU UNDERSTAND IT, AND YOU AGREE TO BE BOUND BY ITS TERMS AND CONDITIONS.

If you have any questions regarding this Agreement, you may contact the Legal Department at EXFO at (418) 683-0211.

Contents

1	Introducing FastReporter 2	1
	Available Features	2
	Conventions	8
2	Getting Started with FastReporter 2	9
	Installing and Uninstalling FastReporter 2 on a Computer	10
	Installing FastReporter 2 on an EXFO Platform	11
	Using the Software Customization Wizard	12
	Starting FastReporter 2	15
	Activating the FastReporter 2 Software Options	18
	Customizing the Main Window	22
	Working with Two Monitors (PC Version)	26
	Selecting Items From Lists and Menus	27
	Displaying Menu Items on the FTB-1 Platform	27
	Changing FastReporter 2 Options	28
	Exiting FastReporter 2	36
3	Working with Projects (FR2-FC Mode)	37
	Managing Projects	37
	Managing Project Templates	46
	Changing File Direction	50
	Matching Files	51
	Setting Auto Refresh in a Specific Folder	59
	Working in Loopback Mode (FR2-LB)	60
4	Using EXFO Connect with FastReporter 2 (FR2-FC Mode, PC Only)	93
	Setting Up the Connection to the Server	94
	Using the EXFO Connect Browser	95

Contents

5 Working with OTDR Files	117
Changing OTDR Settings	121
Using the Auto Template (FR2-FC Mode)	139
Managing the OTDR Event Table View	143
Changing the Main Measurement	148
Setting the OTDR Graphic Display Options	150
Viewing Section Length for the Linear View	150
Using the Zoom Functions	151
Managing Markers	154
Setting and Applying OTDR/OTDR Bidir Reference as Template (FR2-FC Mode)	166
Analyzing Measurements	171
Using the Failed Items Filter	172
Displaying Statistics for Measurements	173
Setting Span Positions with Absolute Lengths	174
Setting the IOR Value by Distance	176
Changing Fiber Core Size (FR2-FC Mode)	177
Reverting to File Test Settings	178
Managing Bidirectional OTDR Files (FR2-FC Mode)	179
Creating Batch Documentation	187
Saving an OTDR File in a New File Format	188
Generating Text Files From OTDR Measurements (FR2-FC Mode)	189
Modifying Space Between Traces on the Graph	190
6 Working with OLTS Files	191
Accepted File Formats	191
Changing OLTS Settings	192
Applying a Configuration File to Selected OLTS Files	196
Using Custom Identifiers	197
Changing the OLTS Fiber Type	198
Changing the Number of Connections in the Link Definition	199
Changing the Number of Splices in the Link Definition	200
Changing the Loss Calculation Method for Bidirectional Files	201
Setting FasTesT Pass/Fail Thresholds	202
Viewing FasTesT Results	206
Viewing Link View Results	207
Viewing Pass/Fail Status Information	209
Understanding Diagnostics	210

7 Working with CD Files	211
Accepted File Formats	211
Changing CD Settings	212
Changing CD Fiber Type	216
Changing Analysis Range	218
Changing the Fiber Length	219
Switching Between Curve Types	220
8 Working with PMD Files	221
Accepted File Formats	221
Changing PMD Settings	222
Changing Fiber Length	225
Working with PMD Statistic Measurements	226
9 Working with OPM/PPM Measurements	229
Accepted File Formats	229
Selecting the Absolute Power Unit	230
Changing OPM/PPM Settings	231
Viewing Power Meter Results	233
Changing the Correction Factor (FR2-FC Mode)	234
10 Working with Fiber Inspection Probe (FIP) files	235
Accepted File Formats	235
Modifying Unit Model and Serial Number	236
Showing or Hiding Threshold and Result Information	238
Applying a Configuration File to Selected FIP Files	239
FIP Graphic Display Options	240
Using Custom Identifiers	242
Saving Legacy FIP Files in .cmax2 File Format	243
Viewing Power Meter and OLTS Results	244
Viewing Geolocation Information	244

Contents

11 Working with iOLM files	245
Accepted File Formats	245
Understanding the Link View	245
Managing Multiple Measurements	249
Selecting Element Alignment Type	251
Modifying Tolerance and Bidirectional Settings	252
Modifying iOLM Thresholds	254
Using the Auto Template (FR2-FC Mode)	266
Modifying iOLM Settings (FR2-FC Mode)	271
Modifying the Splitter Ratio Information	274
Modifying Identifier Labels (FR2-FC Mode)	275
Changing Fiber Core Size (FR2-FC Mode)	276
Changing the iOLM Fiber Type	277
Changing the Number of Connections in the Link Definition	278
Changing the Number of Splices in the Link Definition	279
Managing Elements	281
Customizing the Elements Table Tab	284
Analyzing Measurements (FR2-FC Mode)	302
Using the Failed Element Filter	302
Generating a .sor File From iOLM Measurements (FR2-FC Mode)	303
Managing Configuration Files (FR2-FC Mode)	305
Understanding Diagnostics	309
Viewing Power Meter Results	310
Managing Bidirectional iOLM Files	310
Viewing Section Length for Multiple Measurements	318
Matching Link Elements with a Reference	319
Matching Link Elements Without a Reference	320
Displaying Statistics for Matched Measurements	321
Using the FTTx Mode	322
12 Viewing and Editing Measurements	325
Editing Measurement Identification Information	325
Modifying Summary Information (FR2-FC Mode)	331
Viewing and Sorting Files or Measurements	332
Saving Measurement Files	335
Using the Identifiers View	339

13 Generating, Previewing and Printing Reports	343
Generating Measurement or Summary Reports (FR2-FC Mode)	344
Previewing Summary or Measurement Reports	349
Printing Summary or Measurement Reports	350
Generating Application-Related Reports	351
Using the Clipboard (FR2-FC Mode)	353
Importing and Exporting Templates	354
Creating and Modifying Report Templates	358
Using Crystal Report Templates	359
Using Excel Report Templates	361
14 Using FastReporter 2 Tools	375
Setting a Reference File or Measurement (FR2-FC Mode)	376
Automatically Documenting Measurement Files (FR2-FC Mode)	378
Using the Duplicated Measurements Tool (FR2-FC Mode)	383
15 Exporting Data for Postprocessing (FR2-FC Mode)	387
16 FastReporter 2 Examples	391
Creating an OTDR Bidirectional Project	392
Creating a Fiber Characterization Report	393
Creating a Project Template	398
17 Troubleshooting	403
Consulting the Online Help	403
Contacting the Technical Support Group	404
A Description of Event Types	405
Span Start	406
Span End	406
Short Fibers	406
Continuous Fiber	407
End of Analysis	408
Non-Reflective Event	409
Reflective Event	410
Positive Event	411
Launch Level	412
Fiber Section	413
Merged Event	414
Echo	420
Reflective Event (Possible Echo)	421
Coupler	422

Contents

B Measuring Chromatic Dispersion: Theory	423
Method behind the Chromatic Dispersion Analyzer	423
Using Data Fits to Obtain Dispersion	424
Helping You Manage Chromatic Dispersion	426
C Measuring Polarization Mode Dispersion: Theory	427
D Report Samples	431
Bidirectional OTDR	432
OTDR	433
Fiber Characterization	434
Fiber Inspection Probe	435
iOLM	436
OTDR Advanced Cable (Excel Template)	437
iOLM + FIP (Excel Template)	438
iOLM Bidirectional (Excel Template)	439
iOLM Advanced Cable Report (Excel Report)	440
Index	441

1 **Introducing FastReporter 2**

FastReporter 2 is an advanced management, analysis, and reporting tool for many types of optical tests, including the following:

- optical loss
- optical return loss (ORL)
- optical time-domain reflectometry (OTDR)
- polarization mode dispersion (PMD)
- chromatic dispersion (CD)
- optical and PON power meters (OPM/PPM)
- fiber inspection probe (FIP)
- intelligent optical link mapper (iOLM)

Note: *Depending on the platform you are using, some test modes may not be available.*

Available Features

There are two application levels: Basic and the advanced version, which includes the fiber characterization option (FR2-FC) and the loopback option (FR2-LB). Depending on which version you are using, the features in the table below are available or not.

Note: A feature with an “*” mark indicates that the modification is allowed for single measurements.

Global Features

Feature	Basic	FR2-FC
Viewing and sorting files or measurements	X	X
Applying sorting to other windows	X	X
Saving measurement files*	X	X
Viewing measurement summary information	X	X
Managing reports and report templates	–	X
Using the clipboard	–	X
Adding and removing measurement files*	–	X
Managing projects and project templates	–	X
Editing measurement identification and summary information*	X	X
Generating reports	–	X
Matching files	–	X
Setting a reference file or measurement	–	X

Feature	Basic	FR2-FC
Automatically documenting measurement files	–	X
Using the duplicated measurements tool	–	X
Exporting data for postprocessing	–	X
Setting auto refresh in a specific folder	–	X
Managing files using EXFO Connect	–	X
Filtering files using the Identifiers Tab	X	X

OTDR

Note: Files coming from older OTDR modules may not be compatible with the 64-bit version.

Feature	Basic	FR2-FC
Changing OTDR settings*	X	X
Setting OTDR event table options	X	X
Editing OTDR event properties	X	X
Adding OTDR event with one marker position	X	X
Adding OTDR event with manually positioned markers	X	X
Modifying event markers position on existing events	X	X
Retrieving marker position from file	X	X
OTDR graphic display options	X	X
Using the zoom functions	X	X
Applying an OTDR reference as a template	–	X
Changing the main measurements	–	X
Analyzing or reanalyze measurements*	X	X

Introducing FastReporter 2

Available Features

Feature	Basic	FR2-FC
Viewing failed measurements only	X	X
Setting spans position with absolute length*	X	X
Setting the spans position to modify the IOR value*	X	X
Changing fiber core size*	–	X
Creating bidirectional OTDR files	–	X
Saving an OTDR file in a new file format*	X	X
Generating text file from OTDR measurement	–	X
Performing loopback tests (with the FR2-LB option).	–	X
Creating unidirectional files from a bidirectional file	–	X
Modifying the space between traces on the graph	X	X
Generating reports using the OTDR application format.	X	X
Using the Auto template mode.	–	X

OLTS

Note: *Not available for FTB-1. Files earlier than those coming from the MAX-900 series may not be compatible with the 64-bit version.*

Feature	Basic	FR2-FC
Changing OLTS settings	X	X
Using custom identifiers	X	X
Changing the fiber type	X	X
Changing the number of connections in the link definition	X	X
Changing the number of splices in the link definition	X	X

Feature	Basic	FR2-FC
Setting FasTesT pass/fail thresholds	X	X
Viewing FasTesT results	X	X
Setting ORL pass/fail thresholds (singlemode only)	X	X
Viewing power meter result files	X	X

CD

Note: *FTB-5800 files are not available for FTB-1.*

Feature	Basic	FR2-FC
Changing CD settings	X	X
Changing CD fiber type	X	X
Changing analysis range	X	X
Changing the fiber length	X	X
Toggling between curve types	X	X

PMD

Note: *FTB-5500 files are not available for FTB-1 or compatible with the 64-bit version.*

Feature	Basic	FR2-FC
Changing PMD settings	X	X
Changing fiber length	X	X
Working with PMD statistic measurements	X	X

Introducing FastReporter 2

Available Features

FIP

Feature	Basic	FR2-FC
Setting FIP thresholds table options	X	X
Setting FIP results table options	X	X
FIP graphic display options	X	X
Generating reports using the FIP application format.	X	X

OPM/PPM

Feature	Basic	FR2-FC
Managing power meter results	X	X
Changing correction factor	–	X

iOLM

Feature	Basic	FR2-FC
Viewing iOLM thresholds	X	X
Modifying iOLM thresholds	–	X
Viewing iOLM settings	–	X
Modifying iOLM settings	–	X
Modifying identifier labels	–	X
Adding element	–	X
Modifying Element Types	–	X
Deleting Elements	–	X
Setting Launch Fiber and Receive Fiber on new or existing Element*	–	X

Feature	Basic	FR2-FC
Analyzing measurements	–	X
Viewing failed measurements only	X	X
Generating SOR file from iOLM measurement	–	X
Creating configuration files	–	X
Managing power meter results	X	X
Viewing measurement identification information	X	X
Creating a bidirectional iOLM file	X	X
Working with multimode fibers	X	X
Matching link elements with and without a reference	X	X
Changing core size	–	X
Performing loopback tests (with the FR2-LB option).	–	X
Generating reports using the iOLM application format.	X	X
Viewing files in FTTx mode	–	X
Using the Auto template mode.	–	X

Conventions

Before using the product described in this guide, you should understand the following conventions:



WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in *death or serious injury*. Do not proceed unless you understand and meet the required conditions.



CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in *minor or moderate injury*. Do not proceed unless you understand and meet the required conditions.



CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in *component damage*. Do not proceed unless you understand and meet the required conditions.



IMPORTANT

Refers to information about this product you should not overlook.

2 **Getting Started with FastReporter 2**

If you are using FastReporter 2 on a platform, it is usually pre-installed on your unit. If it is not already installed, you can install it yourself through Update Manager. Refer to the Update Manager documentation for details.

If you are using FastReporter 2 on a computer, the latter needs to meet minimum requirements, depending on which operation system you are using:

System Element	Windows 7	Windows 8.x	Windows 10
Processor	Pentium (1.6 GHz or higher)	Pentium (1 GHz with support for PAN, NX, and SSE2)	1 GHz
RAM	1 GB (32-bit) or 2 GB (64-bit), 4 GB recommended	1 GB (32-bit) or 2GB (64-bit), 4 GB recommended	
Disk Space	8 GB	16 GB (32-bit) or 20 GB (64-bit)	
Monitor	One super VGA (800 X 600) monitor (two 1024 X 768 monitors recommended)	Microsoft DirectX 9 graphics device with WDDM driver	
Other requirements	<ul style="list-style-type: none">➤ Network adapter➤ Microsoft Internet Explorer version 8.0 or later➤ Microsoft Office 2007 or later to open .xls files		

Installing and Uninstalling FastReporter 2 on a Computer

The installation wizard will guide you through the installation step by step. The application is available in two versions:

- 32-bit: Contains all test modes and file formats.
- 64-bit: Allows you to process more measurements and reports, but older files formats, such as CD and PMD (FTB-5500, FTB-5700 and FTB-5800) are not supported.



Note: *You can let the wizard install the complete package, or you can select a custom installation if you want to skip installing the USB key management system.*

To install FastReporter 2:

1. Insert the installation DVD in the DVD drive. The installation should start automatically. If the installation does not start automatically after inserting the DVD, locate the setup.exe application and double-click on it to start the process.



2. Click **Next** to start the installation and follow the on-screen instructions. When asked to, select the type of installation you want to use.



To uninstall FastReporter 2:

Use the **Add/Remove Programs** utility in Windows' Control Panel as you would for any other application.

Installing FastReporter 2 on an EXFO Platform

To install your application on any platform other than a standard computer, use Update Manager.

Using the Software Customization Wizard

The Software Customization Wizard helps you to set the application according to your needs. For each user, you can change the following settings:

- Language
- Field of application
- Supported measurement types
- Distance units
- Additional product information

Note: *The Software Customization Wizard is displayed only once when the application is started by the current Windows user for the first time.*


Note: *At any time while configuring the application using the Software Customization Wizard, you can apply the default settings by clicking **Cancel**. To apply the changes you have made, click **Finish**. To return to the previous page, click **Back**.*

To customize the FastReporter 2 application:

1. In the first step, select whether you want to use the default system language, or select the desired language from the list, then click **Next**.




2. As desired, select the field or fields of application you are involved in, then click **Next**.




Getting Started with FastReporter 2

Using the Software Customization Wizard

3. Select the measurement types that you want the application to support, then click **Next**.



4. Select your preferred unit for displaying distances, then click **Next**.



5. In the case of the PC version, for more details on additional product information, technical support, multimedia and training, and EXFO blog, click on the required link.



6. Click **Finish** to apply the changes and go to the main application window.

Note: *These settings can also be modified in the **Tools** menu, under **Display Options**.*

Starting FastReporter 2

Once installed, all you need to do is double-click the FastReporter 2 shortcut corresponding to the version you want to use.



Note: *You can also access FastReporter 2 through the start menu of Windows, under the EXFO folder. The access path differs depending on the operating system you are using.*

Getting Started with FastReporter 2

Starting FastReporter 2

When you run the application for the first time, the application allows you to activate the trial version of the application or basic options of the application.

- To activate the trial version, click **Start Trial**.
- To activate the basic options of the application, click **Start FastReporter 2**.
- To activate the options you have purchased, click **Activate Option Keys**.



Note: For more information to activate the option keys, see *Activating the FastReporter 2 Software Options* on page 18.

Once the trial period is over, you will have the possibility to renew it for 10 additional days.

To extend the trial period:

1. On the window that appears when the trial period is over, click **Renew Trial**.



2. Enter your My EXFO account information, then click **OK**.



Activating the FastReporter 2 Software Options

Some features of the application are grouped and named as FastReporter 2 Fiber Characterization (FR2-FC) and FastReporter 2 Loopback (FR2-LB). They are available only in the complete version of the product, but you can use them during the 30-day trial period of the product.

If you wish to continue using the features after the trial period, you must activate them using the activation wizard.

Note: *To view the options, you have to activate them from the trial window or from the **Help** menu. If the trial period is over, you can also activate the options by clicking the required option.*

Note: *You can view which options are activated for your products in the **About** window of the **Help** menu.*

There are two types of licenses you can obtain for your application:

- **Fixed:** You have one license for one computer.
- **Floating:** You have one license that you can use on several computers, but on only one at a time. Such a license is contained on a USB dongle key. The dongle key also features some storage space for your data.

In the case of a floating license, FastReporter 2, it will verify if a valid dongle key is connected, and if so, will continue to validate the presence of said key every 10 minutes. If no dongle key is installed, you can only use what is available on your unit (for example, no options are enabled, or you revert to the trial mode).

To generate and send the Identification file for a fixed license:


1. From the trial window, click **Activate Option Keys**.



OR

From the main window, select the **Help** menu, then **Activate Options**.


2. Click the **Generate and Send Identification File** button.



Getting Started with FastReporter 2


Activating the FastReporter 2 Software Options

3. Select which option or options you want to activate.



The screenshot shows the 'Identification File' dialog box. The 'Software Option Details' section is highlighted with a red circle, showing two checked checkboxes: 'FR2-FC' and 'FR2-LB'. Below this, the 'Customer Information' section contains several text input fields: 'Name: Your Name', 'Company: Your Company', 'Telephone:', 'E-mail: name@address.com', and 'PO/Order number placed with EXFO or the Distributor name: 113-432-3434-3555'. The 'Identification File Information' section shows 'File Location: C:\Users' and 'File Name: Your Company_FR2-FC_FR2-LB_Your Name_113-432-3434-3555.xml'. There are 'Generate and Send Identification File...' and 'Cancel' buttons at the bottom.

4. Under **Customer Information**, enter the required details.



The screenshot shows the 'Identification File' dialog box. The 'Customer Information' section is highlighted with a red circle, showing the text input fields: 'Name: Your Name', 'Company: Your Company', 'Telephone:', 'E-mail: name@address.com', and 'PO/Order number placed with EXFO or the Distributor name: 113-432-3434-3555'. The 'Software Option Details' section is also visible, with 'FR2-FC' and 'FR2-LB' checked. The 'Identification File Information' section shows 'File Location: C:\Users' and 'File Name: Your Company_FR2-FC_FR2-LB_Your Name_113-432-3434-3555.xml'. There are 'Generate and Send Identification File...' and 'Cancel' buttons at the bottom.

Note: All fields are mandatory.

5. Click **Browse** to save the file in the desired location.

Note: The identification file name is automatically generated and is not editable.


6. Click **Generate and Send Identification Information**. A new e-mail window is displayed with the identification information file as an attachment. The e-mail displays the information entered in the **Identification File** window and the recipient e-mail address is `softwarekeys@exfo.com`.

Note: *If the e-mail software is not configured in your computer, an error message is displayed to configure an e-mail option. You can send identification file from any other e-mail address with the required details.*

To apply the Identification file:

Note: *This step is not necessary if you are using floating licenses.*

1. From the **Product Activation** window, click **Apply Software Options Key**.



2. Select the Software key file from the required location and click **Open**.
3. Your option is now installed. Click **Exit** to close the window.

Getting Started with FastReporter 2

Customizing the Main Window

Customizing the Main Window


When you start FastReporter 2, the main window appears. In the graphics area of the main window, the application displays the EXFO Web page with information related to FastReporter 2.

You can access any other Web page by entering the URL in the address bar; you can also select any other website as the default opening page.

For more information, see *Changing FastReporter 2 Options* on page 28.

Note: *FastReporter 2 was meant to be operated to its full potential using a mouse and keyboard. Therefore the instructions herein imply that both peripherals are connected to your unit.*

Note: *The appearance of your application may differ from the illustrations in this user documentation depending on the resolution and platform you are using.*




This window can be customized. You can add or remove toolbars, resize the panes as needed and move them around, or even auto-hide panes when they are not in use and reopen them later for as needed.

To display the various toolbars and panes:

1. In the main window, select the **View** menu.
2. Point to **Toolbars** and select or clear options according to what you want to display.

To resize a pane:

Use the split bars enclosing the pane you want to resize.



To close a pane:

Click the **X** button in the upper right corner.

Note: If you hide a toolbar, you can access the same commands on the menu bar.

Getting Started with FastReporter 2

Customizing the Main Window

To move a toolbar:

1. Select the toolbar handle.
2. Click and drag the toolbar to the new location.

To auto-hide a pane or tab:

Click the vertical pushpin () in the upper right corner of the pane.


To show the pane again, move the mouse pointer over the desired hidden pane or tab. Select the tab containing its name.

To turn off the auto-hide feature, click the horizontal pushpin ()

To move a pane or tab:

1. Click and hold the selected pane title bar or tab to select it.

Anchor points indicate where the selected item can be moved. The purple area represents the item you are currently moving.



2. Drag the item from its current location to the desired anchor point, then release the mouse button.

Getting Started with FastReporter 2

Working with Two Monitors (PC Version)

Working with Two Monitors (PC Version)

If your computer is equipped with two monitors, you can use one of the monitors to view the trace files, and the other monitor to view the results or the tabs you work most with. For more information on setting two monitors on your computer, refer to the instructions provided with your monitors, computer and video card.

To move an item to the other monitor:

Drag the item and release it when it appears on the desktop of the secondary monitor.

FastReporter 2 will remember the size and position of the window the next time you start the application.



Another way of increasing workspace is to open Windows Explorer and drag it onto the desktop of the secondary monitor. You can then use the FastReporter 2 drag-and-drop feature to add measurement files to your projects simply by dragging them into the main FastReporter 2 window and releasing the mouse button.

Selecting Items From Lists and Menus

When selecting items in a list or menu, you can in many cases use the Ctrl and Shift keys on your keyboard to make multiple selections, as you would in other Windows-based applications.

Also, the same command can often be performed from the Toolbar, the menus on top of the window, or by right-clicking into the pane where you want to perform an action. For readability reasons, the menu method is privileged in the explanations in this user documentation.

Displaying Menu Items on the FTB-1 Platform

By default, the toolbars and some menu items are hidden in the FTB-1 platform to optimize the screen space. If you want to display them, select the **View** menu, then **Toolbars**.

Changing FastReporter 2 Options

You can change the general options including the user interface language, field of application and supported measurement types, or the display options including date and time formats. You can also narrow down the supported measurement types to simplify the user interface.




IMPORTANT

You cannot open files corresponding to a file type that you have not selected as supported.

To change the user interface language:

1. On the **Tools** menu, click **Options**.
2. Click the **General** tab.
3. Select whether you want to use the default system language, or specify the desired language in the list.




4. Click **Apply** to save your change and continue configuring FastReporter 2 or **OK** to save your changes and exit the window.

Note: Any changes made to the user interface settings will be applied only when you restart the application.

To select the field of application:

1. On the **Tools** menu, click **Options**.
2. Click the **General** tab.
3. Select which fields of application that you want the application to support.




4. Click **Apply** to save your changes and continue configuring FastReporter 2 or **OK** to save your change and exit the window.

Getting Started with FastReporter 2

Changing FastReporter 2 Options

To change supported measurement types:

1. On the **Tools** menu, click **Options**.
2. Click the **General** tab.
3. Select the measurement types that you want the application to support.




4. Click **Apply** to save your change and continue configuring FastReporter 2 or **OK** to save your change and exit the window.

Note: Any changes made to supported measurement types will only take effect after you exit and restart FastReporter 2.

To change display options:


- 1.** On the **Tools** menu, click **Options**.
- 2.** Click the **Display** tab.
- 3.** Select the time setting you want to use, either local or universal.




Getting Started with FastReporter 2

Changing FastReporter 2 Options


4. If needed, select **Display time difference from GMT / UTC** to display the difference between local time and GMT (Greenwich Mean Time), or UTC (depending on the option you selected in step 3).




5. Select **Display a visual clue (*) for manually modified result values** to easily locate them in the result tables.



6. If you do not want to see the menu items that are not activated for your application, select the corresponding option.




7. Select if you want to be notified of when new versions of your application are available (PC version only).



Getting Started with FastReporter 2


Changing FastReporter 2 Options

8. Select your preferred distance unit.



9. If you want a Web page to appear in the graphic pane, you can enable the option here.

When you start the application for first time, this option is enabled and the EXFO FastReporter 2 related URL is entered. You can enter another URL if you want to view another page.




Note: In the standard toolbar of the application, you can click the  icon to switch between the graph view and the Web view. You can access this option only if the **Display webpage in graphics** option is enabled. You can use **Ctrl+W** from the keyboard to switch between the graph view and the Web page view.

Getting Started with FastReporter 2

Exiting FastReporter 2

10. Select whether you want the links from the graphics pane to open in the default browser or in the graphics pane.



11. Click **Apply** to save your changes and continue configuring FastReporter 2 or **OK** to save your changes and exit the window.

To revert to the default settings, click **Default Settings**, then **OK** to apply the default settings and exit the window.

Exiting FastReporter 2

Note: *If there are unsaved changes to the project or project files, you will be prompted to save them when you exit the application.*

To exit FastReporter 2:

On the **File** menu, click **Exit**.

OR

Click the  in the top right corner of the main window.

3 Working with Projects (FR2-FC Mode)

Projects are the files that you require in your analysis or post-processing activity. You can select one or many files, from different sources, and save the project for later consultation.

You can also manage project templates, to help you quicken your work.

Managing Projects


Each time you start FastReporter 2, a project is created automatically using the default project template. You can also create a new project from scratch.

Once a project is created, you can add files to it, or remove them.

When you save a project in FastReporter 2, the project settings and *references* to the files you added to the project are saved. When you open the project file, the project settings you modified and the files you added will still be part of the project file, unless you moved or renamed any of the files. Any changes to the measurement files themselves, however, are not saved in the project file.

To create a project from scratch:

1. On the **File** menu, point to **New**, and click **Project**.
2. In the list, click the template you want to use.




3. Click **OK**.
4. On the **File** menu, click **Open File**.

Working with Projects (FR2-FC Mode)


Managing Projects

5. Select the desired files to include in the project.



6. Click **Open** to add the files to the project.
7. On the **File** menu, click **Save Project**.
8. Click the folder where you want to save the project file.

9. In the **File name** box, type a name for the project file.



Note: *FastReporter 2* automatically adds the *.prj* extension to the file name when you save the file.

10. Click **Save**.

To open an existing project:

1. On the **File** menu, click **Open Project**.
2. Select and open the folder where your project file is located.
3. Select the project file and click **Open**.

Note: *If your project includes files that come from the EXFO Connect server, you will be prompted to either check them out, or view them in read-only mode. See Managing Files on page 103 for details.*

Working with Projects (FR2-FC Mode)

Managing Projects

To save a project file:

On the **File** menu, click **Save Project**.

To save the project file and the measurement files in the project, click **Save All**.


Note: *If your project includes files that come from the EXFO Connect server, you will be prompted to either check them in, or discard them. See Managing Files on page 103 for details.*

To save a project file under a new file name:


1. On the **File** menu, click **Save Project As**.
2. Type a new file name for the project.
3. Click **Save**.

To import a Fiber Characterization (FC) project:


1. From the **File** menu, click **Import**, then **FC Project (settings + files)**.
2. Select the file you want to import and its original location.



3. Select the destination where you want to import the file.



4. If you want to delete the file from the original location once the import is complete, select the corresponding option.



5. Click **Import** to confirm your action.

The project is opened as the default project and all of the corresponding settings are displayed accordingly.


Note: When you import a project, all of the files included in it are copied to the selected location as well.

Working with Projects (FR2-FC Mode)

Managing Projects

To export a Fiber Characterization (FC) project:

1. From the **File** menu, select **Export**, then **FC Project (settings + files)**.
2. If needed, enter a name for your project, and select a location.



3. Click **Save** to confirm your action.


Note: *Exporting the project also exports the corresponding project files. The default name for the exported project is the name of the project.*

Adding and Removing Measurement Files

A FastReporter 2 project can contain files from different tests, and different formats. For more information about the available formats, see the sections corresponding to the format you want to use.

To add measurement files to a project:

1. From the **File** menu, click **Open File**.
2. If needed, select a desired file type to filter the available choices.




Note: You can set the direction in OTDR and FIP files by selecting the direction when you add the files. For example, to set the direction of the selected OTDR files to A->B, select OTDR A->B in the **Files of type** list.

Working with Projects (FR2-FC Mode)

Managing Projects

3. Select the measurement files to add.



4. Click **Open** to add the selected files to the project.

When you open an OTDR file generated using the iOLM application, or a file received from an OTDR manufacturer other than EXFO, a warning message appears with the file name, indicating possible limitations or consequences. You can choose not to see the message again, if you already are aware of those limitations.

Note: When you open any read-only file in the application, it is indicated in the **Attributes** column of the **Files** tab.

To remove measurement files from a project:


1. In the **Files** window, select the files you wish to remove.
2. On the **Edit** menu, click **Delete**.
3. Confirm your choice by clicking **OK**.

Changing General Project Properties

You can provide a descriptive title for a project and identify the author, company and customer.

To change general project properties:

1. On the **Settings** menu, click **Project Settings**.
2. Under the **Identification** tab, click in the column to the right of the property you want to change and enter the information.



Note: The template file name for the project is displayed automatically according to the template you selected when you created the project.


3. Click **Apply** to apply the changes without closing the dialog box.
4. Click **OK** to close the **Project Settings** window.

Managing Project Templates

You can save the properties and settings you often use when creating projects in a project template.

To create a project template:

1. On the **File** menu, point to **New**, and click **Project**.
2. In the list, select a template. If there is an existing template that already has properties and settings that you want to use in the new template, you can use it as a starting point.



3. Click **OK**.
4. Change the properties and settings to suit the projects you want to create with the new template.

Note: Changes made to the display (for example, showing/hiding windows and toolbars using the **View** menu) or to program options (**Options** on the **Tools** menu) are saved when you end your work session. They are not saved in project templates.

5. On the **File** menu, click **Save Project As Template**.

6. In the **File name** box, type a name for the project template file.
FastReporter 2 automatically selects the folder where to save the project template.



7. Click **Save**.



IMPORTANT


FastReporter 2 automatically saves project templates in the Project Template folder. If you change the location, the template will not be available for selection in the New Project dialog box when you start a new project.

Working with Projects (FR2-FC Mode)

Managing Project Templates

To change the default template file:

1. On the **File** menu, point to **New**, and click **Project**.
2. To set the new project template as the default template, click the file name, and click **Set as Default**.



3. Click **OK** to start a new project or **Cancel** if you do not wish to start a new project at this time.

To rename a project template:

To rename a project template, rename the project template file as you would any other file while leaving the .prjt file extension intact. The template will be listed on the **New Project** dialog box with the new name.


To remove a project templates:

To permanently remove a project template, simply delete the project template file in the Project Template folder. To remove a project template so that it is no longer listed on the **New Project** dialog box, remove it from C:\ProgramData\EXFO\FastReporter 2\Standard\Project Template, and put it in another folder.

If you later need to use the template, you can simply move it back to the Project Template folder.

To display the project template name in the application title bar:

1. On the **Settings** menu, click **Project Settings**.
2. Under the **Identification** tab, select the corresponding option at the bottom of the identification table.



3. Click **Apply** to apply the changes without closing the dialog box.
4. Click **OK** to close the **Project Settings** window.

Changing File Direction

Changing the direction for your measurement is useful when you create your reports. For OTDR and iOLM test files, changing the file direction can be useful to create bidirectional and virtual bidirectional files.

Note: *You cannot change the direction on MAX-900 series OLTS files or iOLM FTTx files.*

To change the direction of the measurement or file:

1. Select the required measurement or file from the **Measurement** or **Files** window.

Note: *You can select multiple measurements change the direction if the direction is supported by the measurements.*

2. On the **File** menu, point to **Direction**, and click **A->B** or **B->A** to set the direction.

Matching Files

FastReporter 2 provides three options for matching files in projects:

- File matching based on information present in the file (for example, matching fiber IDs and cable IDs). This is the default setting for projects.
- File matching based on file name. You can have FastReporter 2 ignore expressions in the file names. For example, if you select “A_B” as the expression to ignore, a file named fiber1A_B.trc and a file named fiber1.trc are considered as matching.
- Manual file matching.

Matching Files Based on Information

Depending on which identifiers you select, the automated matching process will look for the corresponding information in your file to pair the measurements.

The application allows you to add custom identifiers for iOLM, OPM, and PPM measurements. This option is available only if the iOLM, OPM/PPM plug-in is selected from **Tools > Options**.

Note: *Only the selected identifiers are displayed in the **Measurements** window and **Matched Files** window. By default, the custom identifiers added in the **Identification** tab are considered for file matching, even if they are not available in the identifiers list under the **File Matching** window.*

Working with Projects (FR2-FC Mode)

Matching Files

For this type of file matching, the file type is the first priority for each measurement and the direction of the file is the second priority. The file type priority and the direction priority is listed in the following tables.


File Type	Priority
iOLM	1
OTDR	2
FIP	3
OLTS	4
OPM	5
PPM	6
PMD	7
CD	8

Direction	Priority
A -> B	1
B -> A	2
Bidir	3
None	4

Note: *The matching function is not case sensitive and will match actual numbers (for example, 001 and 1 are both considered as the same number).*

To automatically match files based on information:

1. On the **Settings** menu, click **Project settings**.
2. Under the **File Matching** tab, select **By information present on file**.
3. If you want to perform inverted matching for your iOLM and power meter files, select the corresponding option.


**IMPORTANT**

If you want to perform inverted matching for the iOLM and power meter measurements, you must select Support Inverted Identifiers. Otherwise, this action will not be possible.

Working with Projects (FR2-FC Mode)

Matching Files

4. Select the required identifiers type to use them for file matching.



5. To apply the changes without closing the dialog box, click **Apply**.
6. Click **OK** to close the **Project Settings** window.

To add an identifier:


1. On the **Settings** menu, click **Project settings**.
2. Under the **File Matching** tab, click .
3. Enter a name for your identifier.



4. Click **OK**.

To delete identifiers:

1. On the **Settings** menu, click **Project settings**.
2. Select the required identifiers that you want to delete.



3. Click to delete the identifiers. The application displays the confirmation message to delete the identifiers.

Note: You cannot delete the default identifiers.

Matching Files Based on their File Names

The automated matching based on file name can be optimized by adding expressions or terms to ignore, so that the matching is as specific as possible.


To automatically match files by file name:

1. On the **Settings** menu, click **Project settings**.
2. Click the **File Matching** tab.

Working with Projects (FR2-FC Mode)


Matching Files

3. Select **By filename**.



4. If needed, add or remove items.

- Click **+**, then type the expression to add to the list and click **OK**.



- Select an expression from the **Ignored Expression** list, then click **X** to remove it.


5. Click **OK** to exit the window.

Matching Files Manually

The manual file matching mode allows you to decide which files to match in your list.

To match files manually:

1. On the **Settings** menu, click **Project settings**.
2. Click the **File Matching** tab.
3. Click **None (Manual)**.



4. Click **OK**.


Working with Projects (FR2-FC Mode)

Matching Files

5. In the **Matched Files** window, select a file in the **File 1** column and drag it into the **File 2** column beside the file to match it to.

OR

Click in the **File 2** column and click  to display the **File Selection** dialog box, which lists the files that have not yet been matched.



If you attempt to match files manually when one of the two automated modes are selected (by information or by file name), FastReporter 2 will ask if you want to change the matching mode.


Setting Auto Refresh in a Specific Folder

The auto refresh option updates the **Files** and **Measurement** tabs for a specified duration whenever you add files to a specified auto refresh folder. You can specify the auto refresh folder on your computer, platform, USB storage, or network drive.

Note: When the application is running, if the specified auto refresh folder is modified or deleted, the application displays a warning message and the default folder is selected.

To specify the auto refresh folder:

1. On the **Settings** menu, click **Project Settings**.
2. Under the **Auto Refresh** tab, enable the **Auto refresh** option.



3. Click  to locate the desired folder.
4. Select the auto refresh duration that suits your needs.
5. Click **Apply** to apply the changes without closing the dialog box.
6. Click **OK** to close the **Project Settings** window.

Working in Loopback Mode (FR2-LB)

The loopback mode allows you to test both A -> B and B -> A, and Tx and Rx at once, which saves time and manipulations. You can set the loop length yourself, or let the application find it automatically with a default loop length.

This mode is available for both OTDR and iOLM measurement files.

If you have activated the loopback option for your application, it is ready to use when needed. You can use the loopback mode that fits your needs:

- Unidirectional: Will split the measurement file into two directions, with the corresponding verdict.
- Bidirectional: Will split two unidirectional files set as a virtual bidirectional file each their two directions.

Note: *Files created using the loopback mode cannot be used again to perform a bidirectional loopback, but you can redo a loopback with the unidirectional mode result files.*


Note: *You cannot perform bidirectional loopback tests on iOLM multimode files.*

Performing Unidirectional Loopback Measurements

The unidirectional loopback mode is available as soon as you select one file. The steps are quite similar for the iOLM and OTDR modes; the iOLM steps will be shown here for illustration purposes.

To perform a unidirectional loopback measurement:


1. Select the file or files that will be included in the test.
2. From the **Tools** menu, select **OTDR** or **iOLM**, then **Create Loopback Unidirectional Files**.
3. If needed, rearrange the files in the list. Since they appear in the same order as they are in the **Files** tab, they may not be in the order that you need them. You can sort the files using the headers in the table, or you can drag the files manually in the list. Once you are done, click **Next** to proceed to the next step.



Working with Projects (FR2-FC Mode)

Working in Loopback Mode (FR2-LB)

4. Set the automated documentation for your resulting files. If you have done a loopback operation on them before, you may keep the documentation information you had set then by selecting the corresponding option.




If you want to use new information, proceed as follows:

- 4a.** Select which identifiers will be used for the documentation. In OTDR mode, you cannot change the identifier types. In iOLM mode, you need at least two identifiers, either from the list of available choices, or you can enter a new identifier of your choice. The first identifier will be the one with the highest occurrence rate in the corresponding identifiers of the selected files. If no values were set, the first two default identifiers are Cable ID and Fiber ID.

Note: You can have four identifiers for OTDR files, and up to five identifiers for iOLM files.

To use the identifiers in the file name, select the corresponding option.



Working with Projects (FR2-FC Mode)

Working in Loopback Mode (FR2-LB)

4b. Set the value you want to show for each identifier.

OTDR Loopback Unidirectional File Creation

Steps

File order ✓ Auto documentation ✓ Auto naming Overview Loop Localization Summary

Auto documentation

Keep existing file documentation Apply new file documentation

Identifier 1	Identifier 2	Identifier 3	Identifier 4
Cable ID	Fiber ID	Location A	Location B
098307	0001	Antenna Quebec Area	Antenna Quebec Area
	No Of Digits: 4	Inverted by Pair	
Use in file name <input checked="" type="checkbox"/>	Use in file name <input checked="" type="checkbox"/>	Use in file name <input type="checkbox"/>	Use in file name <input type="checkbox"/>

Next Cancel

- Enter how many digits you want to use to increment the second identifier automatically. The numbers will be incremented automatically.

Working with Projects (FR2-FC Mode)

Working in Loopback Mode (FR2-LB)

- If you are using identifiers 3 and 4, you can have the application to automatically invert them for the second file of the loopback. Select the **Inverted by Pairs** option to use the automatic inversion. The Overview page will reflect your choice as follows:

Inverted by Pairs Status	Corresponding Locations A and B Information
Not selected	Row 1: Fiber 0001, Location A, Location B Row 2: Fiber 0002, Location A, Location B Row 3: Fiber 0003, Location A, Location B Row 4: Fiber 0004, Location A, Location B And so on.
Selected	Row 1: Fiber 0001, Location A, Location B Row 2: Fiber 0002, Location B, Location A Row 3: Fiber 0003, Location A, Location B Row 4: Fiber 0004, Location B, Location A And so on.

Working with Projects (FR2-FC Mode)


Working in Loopback Mode (FR2-LB)

- In the case of identifier 3 for iOLM, you can set a predefined list of two or four items to use for each section of the measurement. The items must be separated by a semi-colon (for example, "RX;TX"). If you are using four items, they must all be different, or inverted pairs ("AA;BB;CC;DD" or "AA;BB;BB;AA"). Depending on your sequence for identifier 3, the output in the Overview page will change.

Identifier 3 Sequence	Corresponding Fiber ID and Direction in the Overview Page
RX;TX	Row 1: Fiber 0001, RX Row 2: Fiber 0001, TX Row 3: Fiber 0002, RX Row 4: Fiber 0002, TX And so on.
AA;BB;CC;DD	Row 1: Fiber 0001, AA Row 2: Fiber 0001, BB Row 3: Fiber 0001, CC Row 4: Fiber 0001, DD Row 5: Fiber 0002, AA Row 6: Fiber 0002, BB Row 7: Fiber 0002, CC Row 8: Fiber 0002, DD And so on.

- If you are testing iOLM files, you can use a configuration file to set the threshold values by enabling the corresponding option. Click **Select** to open the Apply Configuration File window, where you can select the desired configuration. Click **OK** when you are done and the selected configuration will be applied.

For more information about configurations files, see *Managing Configuration Files (FR2-FC Mode)* on page 305.




Once you are done, click **Next** to proceed to the next step.

Working with Projects (FR2-FC Mode)


Working in Loopback Mode (FR2-LB)

5. Set how you want the resulting files named.

5a. If desired, change the location where the files will be saved.




- 5b.** Select which items to use in the file name. If you include the measurement direction, select which nomenclature to use (AB, BA; BA, AB; RX, TX or TX, RX).




Working with Projects (FR2-FC Mode)

Working in Loopback Mode (FR2-LB)

- 5c. Select which type of separator you want to use between the items. Click **Next** to proceed to the next step.



- In the **Overview** step, you can see the resulting files. The remaining identification and threshold data other than the identifiers will be from the original file.




- Click **Next** to select the test mode.

Working with Projects (FR2-FC Mode)

Working in Loopback Mode (FR2-LB)

8. Select whether the loop will be automatically detected, or if you want to do so manually. If you select the automated mode, enter a length value for the loop.



9. If you are in Manual mode, set the loopback start and end elements:
 - Click on the element that you want to use as the start element, then click **Set Loop Start**. The selected elements will bear *LS* to indicate their statuses.
 - Click on the element that you want to use as the end element, then click **Set Loop End**. The selected elements will bear *LE* to indicate their statuses.
 - If you want to use a section to set the loop start and end values, select it, then click **Set Loop Section**. The loop start and end will be placed on the event before and after the section.

Note: If you select an item in the cable view, all of the corresponding items in the links are set as loop start or end at once.

OTDR

OTDR Loopback Unidirectional File Creation

Steps: File order Auto documentation Auto naming Overview Loop Localization Summary

Loop Localization

Pos.	1	2	3	4	5	6	7	8
10 Measurements	-0.1515	0.0000	0.2983	0.6492	1.0493	1.1996	1.5996	1.9486
(1550) 098367 00001	→	LS	LE	LE	LE	LE	LE	LE
(1550) 098367 00001	→	LS	LE	LE	LE	LE	LE	LE
(1550) 098367 00001	→	LS	LE	LE	LE	LE	LE	LE
(1550) 098367 00001	→	LS	LE	LE	LE	LE	LE	LE

Automatic Loop length: 0.0000 km Manual

Summary
Remaining number of loops to identify:

Annotations:
 - Set loop: points to the first measurement in the table.
 - Loop remaining to be set: points to the '9' in the summary.
 - Number of loops to set: points to the '9' in the summary.
 - Loop start: points to the 'Set Loop Start' button.
 - Loop end: points to the 'Set Loop End' button.
 - To change tolerance level: points to the 'Set Tolerance...' button.

Working with Projects (FR2-FC Mode)

Working in Loopback Mode (FR2-LB)

iOLM

Steps

- File order
- Auto documentation
- Auto naming
- Overview
- Loop Localization
- Summary

Loop Localization

Pos.	1	2	3	4	
S Fibers	0.0000	0.0562	0.0763	0.1325	0.2876
CAB 034	0.0000	0.0562	0.0763	0.1325	0.2876
CAB 034	0.1580	0.0560	0.0201	0.0562	0.1551
CAB 034	0.1580	0.0560	0.0202	0.0558	0.1549
CAB 034	0.1580	0.0558	0.0202	0.0558	0.1551
	0.1580	0.0556	0.0757	0.1313	0.2864

Automatic Loop length: 0.0000 km

Manual

Summary
Remaining number of loops to identify:


Annotations:

- Set loop
- Loop remaining to be set
- Number of loops to set
- Loop start
- Loop end
- To change tolerance level

- 10.** If needed, you can change the tolerance levels by clicking the corresponding button, and you will be taken to the iOLM or OTDR **Set Tolerance** window to set the new value. Click **OK** to close the window, and the values will be updated accordingly in the **Loop Localization** window.

Note: For more information about setting tolerances, see *Setting Event Matching Tolerances* on page 136.

OTDR



iOLM



- 11.** Click **Next** to proceed to the **Summary** step.

Working with Projects (FR2-FC Mode)

Working in Loopback Mode (FR2-LB)

- The result files and their statuses appear in the **Summary** step. If there was something preventing the file from being generated, you can see an explanation in the corresponding line.

You can select to keep the original files in your current project by selecting the corresponding option at the bottom of the window.

You also have the opportunity to change the tolerance settings in this window, as explained in step 10.

If you want to generate a report of your results, click the **Report** button to open the corresponding window.

OTDR Loopback Unidirectional File Creation

Steps: File order, Auto documentation, Auto naming, Overview, Loop Localization, **Summary**

Summary

	1	2	3	4	
2 Measurements	0.0000	0.2983	0.6492	1.0493	1.0493 km
(1550) 098367 0001 A->B	0.0000	0.2983	0.6492	1.0493	1.0493 km
(1550) 098367 0002 B->A	0.0000	0.3005	0.6495	1.0505	1.0505 km

Summary for unidirectional loopback files

Destination Folder: C:\Users\Public\Documents\EXFO\User Files\OTDR\Loopback

Destination File Name	Dir.	Cable ID	Fiber ID	Location A	Location B	Summary
098367 0001 AB.trc	A->B	098367	0001	Antenna Quebec Area Site A	Antenna Quebec Area Site A	✓
098367 0002 BA.trc	B->A	098367	0002	Antenna Quebec Area Site A	Antenna Quebec Area Site A	✓
098367 0003 AB.trc	A->B	098367	0003	Antenna Quebec Area Site A	Antenna Quebec Area Site A	✗ Loop start/end not set.

Keep original files in current project

Report... Set Tolerance... OK Cancel

- Click **OK** to complete the loopback process. The resulting files appear in the **Files** tab.

If you have selected to keep the original files in your project, they will stay in the **Files** list. Otherwise, all of the files for which the loopback was successfully created will be removed from the list. The resulting OTDR loopback files will have the same number of measurements as the original files.


Performing Bidirectional Loopback Measurements

The bidir loopback mode is available when you select at least two files. The steps are quite similar for the iOLM and OTDR modes; the iOLM steps will be shown here for illustration purposes.

To perform a bidirectional loopback measurement:

1. Select the files that will be paired up.
2. From the **Tools** menu, select either the **iOLM** or **OTDR** menu, then select **Create Loopback Bidirectional Files**.
3. If needed, rearrange the files in the list. Since they appear in the same order as they are in the **Files** tab, they may not be paired as you need them. You can sort the files using the headers in the table, or you can drag the files manually in the list. Once you are done, click **Next** to proceed to the next step.


If you swap a pair, the application will ask you if you want to automatically swap the other pairs in the same way.



Working with Projects (FR2-FC Mode)

Working in Loopback Mode (FR2-LB)

4. Set the automated documentation for your resulting files. If you have done a loopback operation on them before, you may keep the documentation information you had set then by selecting the corresponding option.



If you want to use new information, proceed as follows:

- 4a. Select which identifiers will be used for the documentation. In OTDR mode, you cannot change the identifier types. In iOLM mode, you need at least two identifiers, either from the list of available choices, or you can enter a new identifier of your choice. The first identifier will be the one with the highest occurrence rate in the corresponding identifiers of the selected files. If no values were set, the first two default identifiers are Cable ID and Fiber ID.

Note: You can have four identifiers for OTDR files, and up to five identifiers for iOLM files.

To use the identifiers in the documentation, select the corresponding **Use in file name** option.

OTDR Loopback Bidirectional File Creation

Steps
✔ Pair selection ➡ Auto documentation Auto naming Overview Loop Localization Summary

Auto documentation

Keep existing file documentation Apply new file documentation

Identifier 1	Identifier 2	Identifier 3	Identifier 4
Cable ID	Fiber ID	Location A	Location B
108367	0001	Antenna Quebec Area	Antenna Quebec Area
No. of Digits: 4			
Use in file name <input checked="" type="checkbox"/>	Use in file name <input checked="" type="checkbox"/>	Use in file name <input type="checkbox"/>	Use in file name <input type="checkbox"/>

Next Cancel

Working with Projects (FR2-FC Mode)

Working in Loopback Mode (FR2-LB)

- 4b.** Set the value you want to show for each identifier. Enter also how many digits you want to use to increment the second identifier automatically. The numbers will be incremented automatically.

OTDR Loopback Bidirectional File Creation

Steps
✔ Pair selection ➡ Auto documentation Auto naming Overview Loop Localization Summary

Auto documentation


Keep existing file documentation Apply new file documentation

Identifier 1	Identifier 2	Identifier 3	Identifier 4
Cable ID	Fiber ID	Location A	Location B
198367	0001	Antenna Quebec Area	Antenna Quebec Area
	No Of Digits: 4		
Use in file name <input checked="" type="checkbox"/>	Use in file name <input checked="" type="checkbox"/>	Use in file name <input type="checkbox"/>	Use in file name <input type="checkbox"/>

Next Cancel

If you are testing iOLM files, you can use a configuration file to set the threshold values by enabling the corresponding option. Click **Select** to open the Apply Configuration File window, where you can select the desired configuration. Click **OK** when you are done and the selected configuration will be applied.

For more information about configurations files, see *Managing Configuration Files (FR2-FC Mode)* on page 305.




5. Click **Next** to proceed to the next step.

Working with Projects (FR2-FC Mode)


Working in Loopback Mode (FR2-LB)

6. Set how you want the resulting files named.
 - 6a. If desired, change the location where the files will be saved.



6b. Select which items to use in the file name.


Note: *The Use the measurement wavelength option is available for the OTDR files only.*



Working with Projects (FR2-FC Mode)


Working in Loopback Mode (FR2-LB)

- 6c. Select which type of separator you want to use between the items. Click **Next** to proceed to the next step.



- In the **Overview** step, you can see the resulting bidirectional files. The remaining identification and threshold data other than the identifiers will be of the first file in the pair.

Note: *In the case of OTDR files, a different file is displayed for each matched wavelength.*



- Click **Next** to select the test mode.
- Select the perspective from which you want to display the link view using the corresponding radio buttons. At this point in the loopback process, the bidirectional traces shown are virtual and created from two measurements composed of the two links that are not cut yet. When you select one of the links as the view direction, that link will be considered as the A -> B unidirectional trace and the application ensures that the resulting unidirectional elements of the selected link is correctly aligned. The resulting unidirectional file on the other link will however remain uncertain.

Working with Projects (FR2-FC Mode)

Working in Loopback Mode (FR2-LB)

Switching from one view to the other makes sure that you can verify that the two resulting unidirectional traces are adequate with perfectly aligned elements after the traces are cut. It is important to perform this verification before proceeding to the Overview step, where the final results are produced and you cannot go back.

OTDR Loopback Bidirectional File Creation

Steps

- ✓ Pair selection
- ✓ Auto documentation
- ✓ Auto naming
- ✓ Overview
- ➔ **Loop Localization**
- Summary

Loop Localization

Pos.	1	2	3	4	5	6	7	8
Measurements	1000	0.2991	0.6494	1.0493	1.1987	1.5997	1.9494	2.2489
(1550) 098367 00001	1000	0.2991	0.3503	0.6494	0.3999	1.0504	0.1495	1.1990
(1550) 098367 00002	1000	0.2997	0.3496	0.6494	0.4010	1.5994	0.3496	1.9491
(1550) ...	1000	0.3005	0.3496	0.6502	0.4010	1.0507	0.1487	0.4004


Loop length: 0.0000 km

Display link view from

- **Link 1**
- Link 2

Next Cancel

- 10.** Select whether the loop will be automatically detected, or if you want to do so manually. If you select the automated mode, enter a length value for the loop.



- 11.** If you are in Manual mode, set the loopback start and end elements:
- Click on the element or section that you want to use as the start element, then click **Set Loop Start**. The selected elements will bear *LS* to indicate their statuses.
 - Click on the element or section that you want to use as the end element, then click **Set Loop End**. The selected elements will bear *LE* to indicate their statuses.
 - If you want to use a section to set the loop start and end values, select it, then click **Set Loop Section**. The loop start and end will be placed on the event before and after the section.

Working with Projects (FR2-FC Mode)

Working in Loopback Mode (FR2-LB)

In OTDR mode, you can display the error table at the bottom of the window using the corresponding button. This table indicates if there are problems with the selected measurement files, and provides information about the errors.

Note: If you select the element in the cable view, all of the corresponding elements in the links are set as loop start or end at once.

OTDR

OTDR Loopback Bidirectional File Creation

Steps: Pair selection ✓ Auto documentation ✓ Auto naming ✓ Overview Loop Localization Summary

Loop Localization

Pos.	1	2	3	4	5	6	7	8
Measurements	→	↔	↔	↔	↔	↔	↔	↔
(1550) 098367 00001	0.0000	0.2991	0.6494	1.0493	1.1987	1.5997	1.9494	2.2489
(1550) 098367 00002	0.0000	0.2997	0.3503	0.3999	1.0504	0.1495	0.4010	1.5994
(1550)	0.0000	0.2997	0.3496	0.4010	1.0507	0.1487	0.4004	1.5994

Summary

Remaining number of loops to identify: 4

Display link view from: Link 1 (selected), Link 2

Buttons: Automatic, Loop length: 0.0000 km, Manual, Set Loop Start, Set Loop End, Set Loop Section, Set Tolerance..., Next, Cancel

Callouts:

- Set loop
- Loop remaining to be set
- Number of loops to set
- Loop start
- Loop end
- To change tolerance levels

Working with Projects (FR2-FC Mode)

Working in Loopback Mode (FR2-LB)

iOLM

Steps

- ✓ Pair selection
- ✓ Auto documentation
- ✓ Auto naming
- ✓ Overview
- ➔ **Loop Localization**
- Summary

Loop Localization

Pos.	1	2	3	4	
2 Fibers	0.0000	0.0562	0.0763	0.1325	0.1313 km
CAB 034	0.0000	0.0562	0.0201	0.1325	0.1325 km
CAB 034	0.0000	0.0558	0.0202	0.1313	0.1313 km

Automatic Loop length: 0.0000 | Manual | Set Loop Start | **Set Loop End** | Set Loop Section | Set Tolerance...

Summary
Remaining number of loops to identify: 2

Next Cancel

Annotations:

- Loop remaining to be set
- Set loop
- Loop start
- Loop end
- Number of loops to set
- To change tolerance levels


Working with Projects (FR2-FC Mode)

Working in Loopback Mode (FR2-LB)

- If needed, you can change the tolerance levels by clicking the corresponding button, and you will be taken to the iOLM or OTDR **Set Tolerance** window to set the new value. Click **OK** to close the window, and the values will be updated accordingly in the **Loop Localization** window.

Note: For more information about setting tolerances, see *Setting Event Matching Tolerances* on page 136.


OTDR



The dialog box titled "Set Tolerance" for OTDR displays a table of event matching tolerances. The table has two columns: "Pulse" and "Tolerance". Below the table is a "Default Settings" button, and at the bottom are "OK" and "Cancel" buttons.

Pulse	Tolerance
1 μ s	122.11 m
20 μ s	2062.2 m
10 ns	21.021 m
30 ns	23.063 m
100 ns	30.211 m
500 ns	71.065 m

iOLM



The dialog box titled "Set Tolerance" for iOLM displays an "Extended element matching tolerance" section. It includes a "Tolerance:" label, a text input field containing "0.0050", and the unit "km". Below the input field is a "Default Settings" button, and at the bottom are "OK" and "Cancel" buttons.

13. Click **Next** to proceed to the **Summary** step.
14. The result files and their statuses appear in the **Summary** step. If there was something preventing the file from being generated, you can see an explanation in the corresponding line.

You can select to keep the original files in your current project by selecting the corresponding option at the bottom of the window.

You also have the opportunity to change the tolerance settings in this window, as explained in step 12.

If you want to generate a report of your results, click the **Report** button to open the corresponding window.

OTDR Loopback Bidirectional File Creation

Steps: Pair selection Auto documentation Auto naming Overview Loop Localization [Summary](#)

Summary

Pos.	1	2	3	4	
2 Measurements	0.0000	0.2991	0.6494	1.0493	1.0493 km
(1550) 098367 0001 Bidir	0.0000	0.2991	0.6494	1.0493	1.0493 km
(1550) 098367 0002 Bidir	0.0000	0.2996	0.6492	1.0502	1.0502 km

Summary for bidirectional loopback files

Destination Folder: C:\Users\Public\Documents\EXFO\User Files\OTDR\Loopback

Destination File Name	Dir.	Cable ID	Fiber ID	Location A	Location B	Summary
098367 0001 1550.bdr	Bidir	098367	0001	Antenna Quebec Area Site A	Antenna Quebec Area Site A	<input checked="" type="checkbox"/>
098367 0002 1550.bdr	Bidir	098367	0002	Antenna Quebec Area Site A	Antenna Quebec Area Site A	<input checked="" type="checkbox"/>
098367 0003 1550.bdr	Bidir	098367	0003	Antenna Quebec Area Site A	Antenna Quebec Area Site A	<input type="checkbox"/> Loop start/end not set.

Keep original files in current project

Report... Set Tolerance... OK Cancel

Working with Projects (FR2-FC Mode)

Working in Loopback Mode (FR2-LB)

- 15.** Click **OK** to complete the loopback process. The resulting files appear in the **Files** tab.

The result files and their statuses appear in the **Summary** step. If there was something preventing the file from being generated, you can see an explanation in the corresponding line.

In the case of iOLM files, separate bidirectional files will be created for each wavelength with a matching measurement pair.

If you have selected to keep the original files in your project, they will stay in the **Files** list. Otherwise, all of the files for which the loopback was successfully created will be removed from the list.

4 ***Using EXFO Connect with FastReporter 2 (FR2-FC Mode, PC Only)***

You can use FastReporter 2 conjointly with EXFO Connect to manage your files. This active link let you check out the files you need using specific search criteria, work on them, then check them in back into your server.

You can also download copies of your files if you want to work on them without modifying your source files.


Note: *When you log in to the EXFO Connect server for the first time, you will be asked to read and accept the licence agreement and change the default password to one of your choice.*

Setting Up the Connection to the Server

You can have the connection to the server done automatically, or you can connect manually as needed.

To set up the connection information:

1. From the main window, select the **Settings** menu, then **Project Settings**.
2. Select the **EXFO Connect** tab.



The screenshot shows the 'Project Settings' dialog box with the 'EXFO Connect' tab selected. The dialog has four tabs: 'Identification', 'File Matching', 'Auto Refresh', and 'EXFO Connect'. The 'EXFO Connect' tab contains the following elements:

- A checkbox labeled 'Log in automatically to EXFO Connect' which is currently unchecked.
- A 'Login' section with three input fields: 'Server URL:' containing 'https://xxxx.exfoconnectserver.com', 'Username:' containing 'exfo', and 'Password:' containing '*****'. Below these fields is a checkbox labeled 'Remember my credentials' which is also unchecked. A 'Login' button is located to the right of the password field.
- A checkbox labeled 'Refresh browser automatically' which is checked.
- A 'Refresh browser every:' field containing '15' and a 'min' label.
- A note in a yellow box: 'Note: The EXFO Connect browser will automatically refresh at the inputted time.'
- A 'Default Settings' button at the bottom right of the dialog.

At the bottom of the dialog are three buttons: 'OK', 'Cancel', and 'Apply'.

3. Under **Login**, enter the server and identification information to connect the application to the server. You can have the application remember your credentials and connect automatically to the server for quicker access. This connection is automatic for that user only.

To log in to EXFO Connect:

Use the **EXFO Connect** menu in the main window

OR

Use the corresponding button in the toolbar ().

When you are logged in successfully, you will notice your identifier at the top right part of the main window.

To log out of EXFO Connect:

Use the **EXFO Connect** menu in the main window.

OR

Use the corresponding button in the toolbar ().

Using the EXFO Connect Browser

The EXFO Connect browser features the search tools you need to retrieve the files required for your analyses. As it is the case for the full EXFO Connect application, you can check in and check out files, as well as work on copies of your files so as not to compromise your data.

Note: *The files you can process with this browser include optical test types only. The transport and datacom, or access type files are not available.*

Note: *The browser included with FastReporter 2 only have limited features. For a complete use of the EXFO Connect features and options, use the actual application.*


You can have the list of files in the server refresh automatically at set intervals of time to make sure that you have the latest data to work with.

Using EXFO Connect with FastReporter 2 (FR2-FC Mode, PC Only)

Using the EXFO Connect Browser

To display the browser on-screen:

From the main window, click the corresponding tab on the left part of the screen.



To activate the automatic refresh for the browser:

1. From the main window, select the **Settings** menu, then **Project Settings**.
2. Select the **EXFO Connect** tab.



3. Select the **Refresh browser automatically** option to activate it.
4. Set the desired refresh rate, in minutes. The minimum value is 5 minutes, and the maximum value is 60 minutes.

Using EXFO Connect with FastReporter 2 (FR2-FC Mode, PC Only)

Using the EXFO Connect Browser

Searching for Files in the Browser

You can include different file types in your search, but any advanced search on a specific file type has to be done individually.

To search for files in the browser:

1. In the browser window, select which types of files you want to include in your search.

The screenshot shows the EXFO Connect browser interface. At the top, there is a search bar with the following options: Measurement type: All, OTDR, IOLM, FIF (highlighted with a red circle); Search period: Custom range; From: 3/23/2015; To: 3/24/2015; Business unit: All, Corporate. Below the search bar, there are filters for Files selection filters: Measurement type: OTDR; Wavelength: 1510; Direction: All; 1; None; Span ORL; (dB) None; 10. The main area contains a table with columns for File Name, State, Identifier 1, Identifier 2, Identifier 3, Identifier 4, and Test Type. The table lists various fiber optic cables and their associated identifiers and test types.

File Name	State	Identifier 1		Identifier 2		Identifier 3		Identifier 4		Test Type
		Name	Value	Name	Value	Name	Value	Name	Value	
4.3.4.2.iolm		Cable ID	4-3	Fiber ID	32	Location A		Location B		IOLM
5-2_11.iolm		Cable ID	5-2	Fiber ID	11	Location A		Location B		IOLM
5-2_2.1.iolm		Cable ID	5-2	Fiber ID	11	Location A		Location B		IOLM
5-2_22.iolm		Cable ID	5-2	Fiber ID	22	Location A		Location B		IOLM
5-2_4.1.iolm		Cable ID	5-2	Fiber ID	22	Location A		Location B		IOLM
5-2_42.iolm		Cable ID	5-2	Fiber ID	42	Location A		Location B		IOLM
5-2_5.1.iolm		Cable ID	5-2	Fiber ID	43	Location A		Location B		IOLM
5-2_52.iolm		Cable ID	5-2	Fiber ID	52	Location A		Location B		IOLM
5-2_61.iolm		Cable ID	5-2	Fiber ID	61	Location A		Location B		IOLM
5-2_62.iolm		Cable ID	5-2	Fiber ID	62	Location A		Location B		IOLM
5.2.3.1.iolm		Cable ID	6-1	Fiber ID	42	Location A		Location B		IOLM
6.1.4.2.iolm		Cable ID		Fiber ID	2	Location A		Location B		IOLM
BA_1310_1550_fi		Cable ID	0022	Fiber ID	0002	Location A		Location B		OTDR
BA_1310_1550_fi		Cable ID	0022	Fiber ID	0002	Location A		Location B		OTDR
BA_1310_1550_fi		Cable ID	0022	Fiber ID	0003	Location A		Location B		OTDR
BA_1310_1550_fi		Cable ID	0022	Fiber ID	0003	Location A		Location B		OTDR
BA_1310_1550_fi		Cable ID	0022	Fiber ID	0004	Location A		Location B		OTDR
BA_1310_1550_fi		Cable ID	0022	Fiber ID	0004	Location A		Location B		OTDR
CD80km_exfoccd0		Cable ID		Fiber ID	Fiber1 80km	Location A		Location B		CD
CD80km_exfoccd1		Cable ID		Fiber ID	Fiber1 80km	Location A		Location B		CD

Using EXFO Connect with FastReporter 2 (FR2-FC Mode, PC Only)

Using the EXFO Connect Browser

2. Select the period for which you want to perform your search. You can select a preset value, or select the Custom range item and enter your own value.

The screenshot shows the EXFO Connect browser interface. At the top, there is a 'Display Information' section with the following controls:

- Measurement type: All, OTDR, IOLM, FIF
- Search period: Custom range (highlighted with a red circle) From 3/23/2015 To 3/24/2015
- Business unit: All, Corporate
- Search button

Below this is the 'Files selection filters' section with the following controls:

- Measurement type: OTDR
- Wavelength: 1550
- Direction: All
- Span ORL: (db) None
- Buttons: Select, Select


The main data table is as follows:

File Name	State	Identifier 1		Identifier 2		Identifier 3		Identifier 4		Test T
		Name	Value	Name	Value	Name	Value	Name	Value	
4.3.4.2.iolm		Cable ID	4-3	Fiber ID	32	Location A		Location B		IOLM
5-2_11.iolm		Cable ID	5-2	Fiber ID	11	Location A		Location B		IOLM
5-2_2.1.iolm		Cable ID	5-2	Fiber ID	11	Location A		Location B		IOLM
5-2_22.iolm		Cable ID	5-2	Fiber ID	22	Location A		Location B		IOLM
5-2_4.1.iolm		Cable ID	5-2	Fiber ID	22	Location A		Location B		IOLM
5-2_42.iolm		Cable ID	5-2	Fiber ID	42	Location A		Location B		IOLM
5-2_5.1.iolm		Cable ID	5-2	Fiber ID	43	Location A		Location B		IOLM
5-2_52.iolm		Cable ID	5-2	Fiber ID	52	Location A		Location B		IOLM
5-2_61.iolm		Cable ID	5-2	Fiber ID	61	Location A		Location B		IOLM
5-2_62.iolm		Cable ID	5-2	Fiber ID	62	Location A		Location B		IOLM
5.2.3.1.iolm		Cable ID	6-1	Fiber ID	42	Location A		Location B		IOLM
6.1.4.2.iolm		Cable ID		Fiber ID	2	Location A		Location B		IOLM
BA_1310_1550_fi		Cable ID	0022	Fiber ID	0002	Location A		Location B		OTDR
BA_1310_1550_fi		Cable ID	0022	Fiber ID	0002	Location A		Location B		OTDR
BA_1310_1550_fi		Cable ID	0022	Fiber ID	0003	Location A		Location B		OTDR
BA_1310_1550_fi		Cable ID	0022	Fiber ID	0003	Location A		Location B		OTDR
BA_1310_1550_fi		Cable ID	0022	Fiber ID	0004	Location A		Location B		OTDR
BA_1310_1550_fi		Cable ID	0022	Fiber ID	0004	Location A		Location B		OTDR
CD80km_exfocd0		Cable ID		Fiber ID	Fiber1 80km	Location A		Location B		CD
CD80km_exfocd1		Cable ID		Fiber ID	Fiber1 80km	Location A		Location B		CD

Using EXFO Connect with FastReporter 2 (FR2-FC Mode, PC Only)


Using the EXFO Connect Browser

3. If desired, select the business unit or units from where you want to retrieve the data. The list of available business units will vary depending on which business unit is available on the EXFO Connect server.




4. If you want to add additional search criteria, select the corresponding file type, then select more details.

Note: The available criteria will change depending on the type you select.



5. Select if you want to show a display view specific to the type of files you are listing. This view will give you access to specific columns for each type and help you in your search.

Note: You can only show one type of viewer at a time, or use the general view



6. Click **Search** to start the search.

Applying Filters to Your Search Results

You can use filters in your browser so as to only see the files you want. Both the column of the table and the actual contents of the columns can be filtered.

You can also stretch or narrow the column width as needed.

To filter the columns you want to see:

1. In the browser, right-click on the columns.
2. Select which headers you want to display.

The screenshot shows the EXFO Connect browser interface. At the top, there are search filters for measurement type (OTDR, IOLM, FIP, O), search period (Last 30 days), and business unit (Corporate). Below this is a table of search results. A context menu is open over the table columns, showing options to filter columns: File Name, State, Global P/F, Identifier 1, Identifier 2, Identifier 3, Identifier 4, Test Type, Direction, Test Date, Job ID, Business Unit, More Columns, and Restore Default. The table columns are: File Name, State, Global P/F, Identifier 1, Identifier 2 (Name, Value), Identifier 3 (Name, Value), and Identifier 4 (Name, Value). The table contains various rows including fiber IDs, cable IDs, and test results across different locations like Location A, Location B, Pune, and Quebec.


File Name	State	Global P/F	Identifier 1	Identifier 2	Identifier 3	Identifier 4
11_1310 + 1550	Check Out		File Name	Fiber ID	Value	Value
CD80km_exfocd0			State	Fiber ID	Fiber1 80km	Location A
CD80km_exfocd1			Global P/F	Fiber ID	Fiber1 80km	Location A
CD80km_exfocd2			Identifier 1	Fiber ID	Fiber1 80km	Location A
CD80km_exfocd3			Identifier 2	Fiber ID	Fiber1 80km	Location A
CD80km_exfocd4			Identifier 3	Fiber ID	Fiber1 80km	Location A
CD80km_exfocd5			Identifier 4	Fiber ID	Fiber1 80km	Location A
CD80km_exfocd6			Identifier 5	Fiber ID	Fiber1 80km	Location A
CD80km_exfocd7			Test Type	Fiber ID	Fiber1 80km	Location A
Cable ID 0003 AB			Direction	Fiber ID	Fiber0001	Location A
Cable ID 0004 BA			Test Date	Fiber ID	Fiber0002	Location A
Cable ID 0005 AB			Job ID	Fiber ID	Fiber0003	Location A
Cable ID 0007 AB			Business Unit	Fiber ID	0005	Location A
Demo0em0.trc			More Columns	Fiber ID	Fiber0001	Location A
Demo0em0.trc			Restore Default	Fiber ID	Fiber0001	Location A
Fiber9.trc	Check Out			Fiber ID	Fiber8	Location A
Fiber9.trc	Check Out			Fiber ID	Fiber9	Location A
multi-wavelength			Cable ID	Fiber ID	2	Location A
multi-wavelength			1	Fiber ID	2	Location A
multi-wavelength			1	Fiber ID	2	Location A
multi-wavelength			1	Fiber ID	2	Location A
Cable ID 0006 BA			Cable ID	Fiber ID	0004	Location A
Default Link A-B.io			CAB 001	Fiber ID	Fiber 002	Location A
1_1 0001 AB.iolm			cable id	Fiber Pair	0001	Location
1_1 0002 BA.iolm			cable id	Fiber Pair	0002	Location
1_1 0003 AB.iolm			cable id	Fiber Pair	0003	Location
1_1 0004 AB.iolm			cable id	Fiber Pair	0004	Location
1_1 0005 AB.iolm			cable id	Fiber Pair	0005	Location
Cable ID Fiber000			aa	Fiber ID	bb	Location A
Cable ID Fiber000			aa	Fiber ID	bb	Location A
Cable ID Fiber000			aa	Fiber ID	bb	Location A

Using EXFO Connect with FastReporter 2 (FR2-FC Mode, PC Only)

Using the EXFO Connect Browser

To filter the items in each column:

1. In the browser, click in the column for which you want to use a filter.
2. Select which items you want to view.



3. To perform an even more detailed filter search, you can type a term directly in the search box to reduce the list of available choices, and click OK.

Managing Files

Managing the files is achieved through the available actions below:

- *Checking out files:* allows you to retrieve files from the server where they are stored, and perform analyses and modifications on them. When files are checked out, they are “reserved” by the user and cannot be modified by another user.
- *Discarding checked out files:* If you change your mind about working on some files and want to free them for other users, you can undo your check out. Any change done to the files will be lost.
- *Checking in files:* Once you are done working with the files, you must check them back in the server so that other users can consult them. Any change done to the files you are checking in is saved into the database.
- *Uploading files:* You can add new files to the server.
- *Viewing files:* You can get a read-only copy of the files from the server for consultation purposes.
- *Exporting files:* You can obtain a local copy of a file that is not linked with the server. This file is writable.

You can perform those actions directly in the browser, or by right-clicking in the **Files** tab, then selecting **EXFO Connect**.

Using EXFO Connect with FastReporter 2 (FR2-FC Mode, PC Only)

Using the EXFO Connect Browser

To check out files:


1. In the EXFO Connect browser, select which files you want to check out. You can select more than one file.

The screenshot shows the EXFO Connect browser interface. At the top, there are filters for Measurement type (All, OTDR, IOLM, FIF), Search period (Custom range), From (3/23/2015), To (3/24/2015), and Business unit (All, Corporate). Below this, the 'View to display' is set to OTDR. The 'Files selection filters' section includes Measurement type (OTDR), Wavelength (All), Direction (All), and other parameters. The main table displays a list of files with columns for File Name, State, and four Identifiers (Identifier 1, 2, 3, 4), each with Name and Value sub-columns. A 'Test Type' column is also present. Several files are highlighted in blue, indicating they are selected. The selected files are:

File Name	State	Identifier 1 Name	Identifier 1 Value	Identifier 2 Name	Identifier 2 Value	Identifier 3 Name	Identifier 3 Value	Identifier 4 Name	Identifier 4 Value	Test Type
BA_1310_1550_fi		Cable ID	0022	Fiber ID	0002	Location A		Location B		OTDR
BA_1310_1550_fi		Cable ID	0022	Fiber ID	0002	Location A		Location B		OTDR
BA_1310_1550_fi		Cable ID	0022	Fiber ID	0003	Location A		Location B		OTDR
BA_1310_1550_fi		Cable ID	0022	Fiber ID	0003	Location A		Location B		OTDR
BA_1310_1550_fi		Cable ID	0022	Fiber ID	0004	Location A		Location B		OTDR
BA_1310_1550_fi		Cable ID	0022	Fiber ID	0004	Location A		Location B		OTDR
CD80km_exfoccd0		Cable ID		Fiber ID	Fiber1 80km	Location A		Location B		CD
CD80km_exfoccd1		Cable ID		Fiber ID	Fiber1 80km	Location A		Location B		CD

2. From the EXFO Connect menu, select Check Out and Edit.

3. Once the check-out operation is complete, click **Close** to open the files.



You can see the progress as the files are downloaded to their local folder. If there was a problem with any of the files, you will be notified with an icon next to the file and a description of the problem. The selected files are now identified as checked out in the browser and are added in the **Files** tab.

Using EXFO Connect with FastReporter 2 (FR2-FC Mode, PC Only)

Using the EXFO Connect Browser

To undo a check out of your files:

1. In the EXFO Connect browser, select which files for which you want to remove the check out. You can select more than one file.


Note: You can only remove a check-out status on files that you have checked out.

The screenshot shows the EXFO Connect browser interface. At the top, there are search filters for measurement type (All, OTDR, iOLM, FIF), search period (Last 30 days), and business unit (All, Corporate). Below this is a table with columns for File Name, State, and four Identifiers (Identifier 1, 2, 3, 4). The table contains multiple rows of data, with several rows highlighted in blue. The highlighted rows have a 'Check Out' state and are associated with Cable ID 0022 and Fiber ID 0002-0004. The table also includes a 'Test Type' column with values like iOLM and CD.

File Name	State	Identifier 1		Identifier 2		Identifier 3		Identifier 4		Test Type
		Name	Value	Name	Value	Name	Value	Name	Value	
4.3.4.2.iolm		Cable ID	4-3	Fiber ID	32	Location A		Location B		iOLM
5-2_11.iolm		Cable ID	5-2	Fiber ID	11	Location A		Location B		iOLM
5-2_2.1.iolm		Cable ID	5-2	Fiber ID	11	Location A		Location B		iOLM
5-2_22.iolm		Cable ID	5-2	Fiber ID	22	Location A		Location B		iOLM
5-2_4.1.iolm		Cable ID	5-2	Fiber ID	22	Location A		Location B		iOLM
5-2_42.iolm		Cable ID	5-2	Fiber ID	42	Location A		Location B		iOLM
5-2_5.1.iolm		Cable ID	5-2	Fiber ID	43	Location A		Location B		iOLM
5-2_52.iolm		Cable ID	5-2	Fiber ID	52	Location A		Location B		iOLM
5-2_61.iolm		Cable ID	5-2	Fiber ID	61	Location A		Location B		iOLM
5-2_62.iolm		Cable ID	5-2	Fiber ID	62	Location A		Location B		iOLM
5.2.3.1.iolm		Cable ID	6-1	Fiber ID	42	Location A		Location B		iOLM
6.1.4.2.iolm		Cable ID		Fiber ID	2	Location A		Location B		iOLM
BA_1310_1950_fi	Check Out	Cable ID	0022	Fiber ID	0002	Location A		Location B		OTDR
BA_1310_1950_fi	Check Out	Cable ID	0022	Fiber ID	0002	Location A		Location B		OTDR
BA_1310_1950_fi	Check Out	Cable ID	0022	Fiber ID	0003	Location A		Location B		OTDR
BA_1310_1950_fi	Check Out	Cable ID	0022	Fiber ID	0003	Location A		Location B		OTDR
BA_1310_1950_fi	Check Out	Cable ID	0022	Fiber ID	0004	Location A		Location B		OTDR
BA_1310_1950_fi	Check Out	Cable ID	0022	Fiber ID	0004	Location A		Location B		OTDR
CD80km_exfoccd0		Cable ID		Fiber ID	Fiber1 80km	Location A		Location B		CD
CD80km_exfoccd1		Cable ID		Fiber ID	Fiber1 80km	Location A		Location B		CD

2. From the EXFO Connect menu, select **Discard Check Out**.

3. Confirm that you want to discard your checked out file from your local folder.



You can see the progress as the files are removed from the local folder. If there was a problem with any of the files, you will be notified on-screen.

Using EXFO Connect with FastReporter 2 (FR2-FC Mode, PC Only)

Using the EXFO Connect Browser

To check in files:

1. In the EXFO Connect browser, select which files you want to check in. You can select more than one file.


Note: To find all of the files with a check-out status, you can use a filter search. See Applying Filters to Your Search Results on page 101 for details.

The screenshot shows the EXFO Connect browser interface. At the top, there are search filters for Measurement type (All, OTDR, IOLM, FIF), Search period (Last 30 days), and Business unit (All, Corporate). Below this is a 'Files selection filters' section with a 'Measurement type' dropdown and 'Select' and 'Select Matched Files' buttons. The main part of the interface is a table with the following columns: File Name, State, Identifier 1 (Name, Value), Identifier 2 (Name, Value), Identifier 3 (Name, Value), Identifier 4 (Name, Value), and Test Type. The table contains several rows of data, with some rows highlighted in blue to indicate they are selected. The selected rows have a 'Check Out' status and are of type 'OTDR'.

File Name	State	Identifier 1		Identifier 2		Identifier 3		Identifier 4		Test Type
		Name	Value	Name	Value	Name	Value	Name	Value	
4.3.4.2.iolm		Cable ID	4-3	Fiber ID	32	Location A		Location B		IOLM
5-2_11.iolm		Cable ID	5-2	Fiber ID	11	Location A		Location B		IOLM
5-2_2.1.iolm		Cable ID	5-2	Fiber ID	11	Location A		Location B		IOLM
5-2_22.iolm		Cable ID	5-2	Fiber ID	22	Location A		Location B		IOLM
5-2_4.1.iolm		Cable ID	5-2	Fiber ID	22	Location A		Location B		IOLM
5-2_42.iolm		Cable ID	5-2	Fiber ID	42	Location A		Location B		IOLM
5-2_5.1.iolm		Cable ID	5-2	Fiber ID	43	Location A		Location B		IOLM
5-2_52.iolm		Cable ID	5-2	Fiber ID	52	Location A		Location B		IOLM
5-2_61.iolm		Cable ID	5-2	Fiber ID	61	Location A		Location B		IOLM
5-2_62.iolm		Cable ID	5-2	Fiber ID	62	Location A		Location B		IOLM
5.2.3.1.iolm		Cable ID	6-1	Fiber ID	42	Location A		Location B		IOLM
6.1.4.2.iolm		Cable ID		Fiber ID	2	Location A		Location B		IOLM
BA_1310_1550.F	Check Out	Cable ID	0022	Fiber ID	0002	Location A		Location B		OTDR
BA_1310_1550.F	Check Out	Cable ID	0022	Fiber ID	0002	Location A		Location B		OTDR
BA_1310_1550.F	Check Out	Cable ID	0022	Fiber ID	0003	Location A		Location B		OTDR
BA_1310_1550.F	Check Out	Cable ID	0022	Fiber ID	0003	Location A		Location B		OTDR
BA_1310_1550.F	Check Out	Cable ID	0022	Fiber ID	0004	Location A		Location B		OTDR
BA_1310_1550.F	Check Out	Cable ID	0022	Fiber ID	0004	Location A		Location B		OTDR
CD80km_exfoccd0		Cable ID		Fiber ID	Fiber1 80km	Location A		Location B		CD
CD80km_exfoccd1		Cable ID		Fiber ID	Fiber1 80km	Location A		Location B		CD

2. From the EXFO Connect menu, select **Check In**. If your files were modified, you will be prompted to save them.

3. If desired, enter a comment for your check-in.



You can see the progress as the files are uploaded to the server. If there was a problem with any of the files, you will be notified on-screen. The selected files are removed from the application as they are successfully uploaded.

Using EXFO Connect with FastReporter 2 (FR2-FC Mode, PC Only)

Using the EXFO Connect Browser

To upload files:

1. In the **Files** tab, select which files you want to upload to the server. You can select more than one file.
2. From the **EXFO Connect** menu, select **Upload Files**.
3. If desired, enter a comment for your upload.

Upload

Upload Comments
[New File]


Business Unit : FTTx: I&R

File Name	Status
Gainer_DSF_1550nm_00100ns_BA.trc	

After successfully uploaded files(s)
 Remove original file from FastReporter Delete original file from disk

Upload Close Cancel

4. Select which business unit the uploaded files belong to in the list, if desired.



5. Click **Upload** to complete the transfer.

You can see the progress as the files are uploaded to the server. If there was a problem with any of the files, you will be notified on-screen. The selected files are left in the application.

Note: *The files will appear in the EXFO Connect browser the next time the latter is refreshed.*

Using EXFO Connect with FastReporter 2 (FR2-FC Mode, PC Only)

Using the EXFO Connect Browser

To view files in read-only mode:


1. In the EXFO Connect browser, select which files you want to download. You can select more than one file.

The screenshot shows the EXFO Connect browser interface. At the top, there are search filters for measurement type (All, OTDR, IOLM, FIF), search period (Custom range), and business unit (All, Corporate). Below this, there are filters for measurement type (OTDR), wavelength (10), direction (All), and span ORL (None). The main area is a table with columns for File Name, State, Identifier 1, Identifier 2, Identifier 3, Identifier 4, and Test Type. Several rows are selected, including BA_1310_1950.fi and CD80km_exfocd1.

	File Name	State	Identifier 1		Identifier 2		Identifier 3		Identifier 4		Test Type
			Name	Value	Name	Value	Name	Value	Name	Value	
<input type="checkbox"/>	4.3.4.2.iolm		Cable ID	4-3	Fiber ID	32	Location A		Location B		IOLM
<input type="checkbox"/>	5-2_11.iolm		Cable ID	5-2	Fiber ID	11	Location A		Location B		IOLM
<input type="checkbox"/>	5-2_2.1.iolm		Cable ID	5-2	Fiber ID	11	Location A		Location B		IOLM
<input type="checkbox"/>	5-2_22.iolm		Cable ID	5-2	Fiber ID	22	Location A		Location B		IOLM
<input type="checkbox"/>	5-2_4.1.iolm		Cable ID	5-2	Fiber ID	22	Location A		Location B		IOLM
<input type="checkbox"/>	5-2_42.iolm		Cable ID	5-2	Fiber ID	42	Location A		Location B		IOLM
<input type="checkbox"/>	5-2_5.1.iolm		Cable ID	5-2	Fiber ID	43	Location A		Location B		IOLM
<input type="checkbox"/>	5-2_52.iolm		Cable ID	5-2	Fiber ID	52	Location A		Location B		IOLM
<input type="checkbox"/>	5-2_61.iolm		Cable ID	5-2	Fiber ID	61	Location A		Location B		IOLM
<input type="checkbox"/>	5-2_62.iolm		Cable ID	5-2	Fiber ID	62	Location A		Location B		IOLM
<input type="checkbox"/>	5.2.3.1.iolm		Cable ID	6-1	Fiber ID	42	Location A		Location B		IOLM
<input type="checkbox"/>	6.1.4.2.iolm		Cable ID		Fiber ID	2	Location A		Location B		IOLM
<input checked="" type="checkbox"/>	BA_1310_1950.fi		Cable ID	0022	Fiber ID	0002	Location A		Location B		OTDR
<input checked="" type="checkbox"/>	BA_1310_1950.fi		Cable ID	0022	Fiber ID	0002	Location A		Location B		OTDR
<input checked="" type="checkbox"/>	BA_1310_1950.fi		Cable ID	0022	Fiber ID	0003	Location A		Location B		OTDR
<input checked="" type="checkbox"/>	BA_1310_1950.fi		Cable ID	0022	Fiber ID	0003	Location A		Location B		OTDR
<input checked="" type="checkbox"/>	BA_1310_1950.fi		Cable ID	0022	Fiber ID	0004	Location A		Location B		OTDR
<input checked="" type="checkbox"/>	BA_1310_1950.fi		Cable ID	0022	Fiber ID	0004	Location A		Location B		OTDR
<input type="checkbox"/>	CD80km_exfocd0		Cable ID		Fiber ID	Fiber1 80km	Location A		Location B		CD
<input type="checkbox"/>	CD80km_exfocd1		Cable ID		Fiber ID	Fiber1 80km	Location A		Location B		CD

2. From the EXFO Connect menu, select **View (Read Only)**.

3. Once the download operation is complete, click **Close** to open the files.



You can see the progress as the files are copied to their local folder. If there was a problem with any of the files, you will be notified on-screen. The selected files are now identified as read-only in the browser and are added in the **Files** tab.

Using EXFO Connect with FastReporter 2 (FR2-FC Mode, PC Only)

Using the EXFO Connect Browser

To export a file:


1. In the EXFO Connect browser, select which files you want to copy. You can select more than one file.

The screenshot shows the EXFO Connect browser interface. At the top, there is a search bar with the following settings: Measurement type: All, OTDR, IOLM, FIF; Search period: Custom range; From: 3/23/2015; To: 3/24/2015; Business unit: All, Corporate. The view to display is set to OTDR. Below the search bar, there are file selection filters: Measurement type: OTDR; Wavelength: 1550; Direction: All; 1; None; Span ORL; (dB); None; 10. The main table displays data with columns for File Name, State, Identifier 1, Identifier 2, Identifier 3, Identifier 4, and Test Type. The table is filtered to show only OTDR test types. The following table represents the data shown in the screenshot:

File Name	State	Identifier 1	Identifier 2	Identifier 3	Identifier 4	Test Type
4.3.4.2.iolm		Cable ID 4-3	Fiber ID 32	Location A	Location B	IOLM
5-2_11.iolm		Cable ID 5-2	Fiber ID 11	Location A	Location B	IOLM
5-2_2.1.iolm		Cable ID 5-2	Fiber ID 11	Location A	Location B	IOLM
5-2_22.iolm		Cable ID 5-2	Fiber ID 22	Location A	Location B	IOLM
5-2_4.1.iolm		Cable ID 5-2	Fiber ID 22	Location A	Location B	IOLM
5-2_42.iolm		Cable ID 5-2	Fiber ID 42	Location A	Location B	IOLM
5-2_5.1.iolm		Cable ID 5-2	Fiber ID 43	Location A	Location B	IOLM
5-2_52.iolm		Cable ID 5-2	Fiber ID 52	Location A	Location B	IOLM
5-2_61.iolm		Cable ID 5-2	Fiber ID 61	Location A	Location B	IOLM
5-2_62.iolm		Cable ID 5-2	Fiber ID 62	Location A	Location B	IOLM
5.2.3.1.iolm		Cable ID 6-1	Fiber ID 42	Location A	Location B	IOLM
6.1.4.2.iolm		Cable ID	Fiber ID 2	Location A	Location B	IOLM
BA_1310_1550_f		Cable ID 0022	Fiber ID 0002	Location A	Location B	OTDR
BA_1310_1550_f		Cable ID 0022	Fiber ID 0002	Location A	Location B	OTDR
BA_1310_1550_f		Cable ID 0022	Fiber ID 0003	Location A	Location B	OTDR
BA_1310_1550_f		Cable ID 0022	Fiber ID 0003	Location A	Location B	OTDR
BA_1310_1550_f		Cable ID 0022	Fiber ID 0004	Location A	Location B	OTDR
BA_1310_1550_f		Cable ID 0022	Fiber ID 0004	Location A	Location B	OTDR
CD80km_exfocd0		Cable ID	Fiber ID Fiber1 80km	Location A	Location B	CD
CD80km_exfocd1		Cable ID	Fiber ID Fiber1 80km	Location A	Location B	CD

2. From the EXFO Connect menu, select **Export**.


3. If desired, select a location for your copy.



Using EXFO Connect with FastReporter 2 (FR2-FC Mode, PC Only)

Using the EXFO Connect Browser

4. Click **Export** to confirm the transfer.




You can see the progress as the files are copied to their local folder. If there was a problem with any of the files, you will be notified on-screen. The selected files are now identified as read-only in the browser and are added in the **Files** tab.


5 Working with OTDR Files

The application shows the result of the OTDR analysis in the graph area. You can view the OTDR traces in two different manners:

- Graph view: This is the standard OTDR view. You can see the events along the trace marked by red vertical lines.




- Linear view: The linear view is a graphical representation of the link, where each event is displayed as a box containing the symbol corresponding to the event type.



Working with OTDR Files

When you are working with more than one measurements in the Linear view, you can also display the Cable view at the top of the list. It shows all of the measurements grouped into one link, with the link overview. The total number of selected fibers is indicated on the left and each event has its own identification number.

When matched events are of the same type, you can see how many there are on the upper left corner of the event icon. If the number is blue, all fibers contain this event. If the number is yellow, at least one fiber does not have this event. If events at the same position are not of the same type, a question mark icon replaces the event type.



Note: When viewing grouped fibers, the Span End event (B) is set according to the reference measurement if there is one; if there is no reference measurement, it is set according to the shortest fiber. The events located between the Span Start and Span End events (including both A and B) are numbered.

You can perform the same actions (adding, modifying and deleting events, setting span start and end) on single fiber and multiple fibers; the main difference is that if you perform the actions on the cable at the top of the linear view, all of the included fibers are modified accordingly.

To select the viewing method:

1. Select the fibers that you want to view together in the **Files** or **Measurement** tabs.
2. Right-click in the graph area, then select either the Graph or Linear view. You can also select the view in the **View > OTDR** menu.

When you select a trace in either view, the corresponding data is also selected in the event table.

Note: *When in linear view, the zoom and marker features are not available. However, you can add, delete, and change events from the linear view.*

To display the Cable view:

Right-click in the linear view area, then select **Display Cable View Section**. You can also select the view in the **View > OTDR** menu.

Working with OTDR Files

Depending on the file format, you can perform different operations. See the table below for details:

Action	EXFO Native ^{a,b} (.trc, .bdr)	Telcordia 100 EXFO (.sor)	Telcordia 200 EXFO (.sor)	Telcordia 200 EXFO iOLM (.sor)	Telcordia 100 Non-EXFO (.sor)	Telcordia 200 Non-EXFO ^{c,d} (.sor)
Changing job information (such as Fiber ID, Job ID, Cable ID, and so on)	X	X	X	X	X	X
Editing events	X	X	X	-	-	X
Inserting events	X	X	X	-	-	X
Deleting events	X	X	X	-	-	X
Managing span	X	X	X	-	-	X
RBS, event detection, thresholds	X	X	X	-	-	-
Managing bidir	X	X	X	-	-	X
Managing templates	X	X	X	-	-	X
IOR, Helix	X	X	X	-	-	X
Event Detection (reanalysis)	X	X	X	-	-	-
Pass/Fail thresholds	X	X	X	X	X	X

- The native formats also include FTB-100 version 2.7 (.ftb100) and FTB-300 (.ftb300).
- The 64-bit version of FastReporter 2 may not support all file formats. To view files that come from older OTDR modules, save them first in a newer .trc format using the 32-bit version of the application.
- The actions are valid only if the event markers are properly saved. If not, the files are considered as the same thing as viewing Telcordia 100 Non-EXFO files.
- Providing that the manufacturer complies with the Bellcore standard.

Changing OTDR Settings

When viewing your OTDR files, you can change general properties, pass/fail thresholds for selected wavelengths, event matching tolerances, and automatic file matching rules for the OTDR projects.


Changing General Settings

General options include items such as the pulse baseline, visual settings, and event calculation and threshold settings.

To change OTDR general settings:

1. On the **Settings** menu, select **OTDR**.
2. Click the **General** tab.
3. Select if you want the pulse baseline to be based on time or distance.

Note: *The pulse baseline distance is always given in meters.*




Working with OTDR Files

Changing OTDR Settings


4. Change the numeric value precision settings for distance and length, loss, reflectance, attenuation, or ORL, if desired.

These settings also affect span loss, average loss, average splice loss and maximum splice loss.



Note: *The numeric precision in the linear view does not apply if the selected units are meters or feet.*


5. Indicate whether you want to display the error messages when creating virtual bidirectional files. This option will let FastReporter 2 notify you when a bidirectional file cannot be created, and indicate the reason why.




Working with OTDR Files

Changing OTDR Settings

6. If you want the zoom area and marker positions to be saved in your OTDR file, enable the corresponding option. By default, this option is not selected.



7. If you want the event calculations and pass/fail thresholds to be saved when they are not included in the original file, select the corresponding option. Otherwise, the default values are used.




Working with OTDR Files

Changing OTDR Settings

8. Select how the events will be matched, either using the position (the distance on the fiber), or the event number. The span start is considered as event number 1, or the start position.

Note: *Some operations, such as delete, add, and add to other measurements are not available when the events are matched by number.*



9. To apply the changes without closing the dialog box, click **Apply**. To return the general settings back to their original values, click **Default Settings**.


Changing Pass/Fail Thresholds

You can change the pass/fail threshold values for one, or many wavelengths at a time.

You can also change the threshold values for the current measurement.

To change OTDR Pass/Fail Thresholds:


1. On the **Settings** menu, select **OTDR**.
2. Click the **Pass/Fail Thresholds** tab.



Working with OTDR Files

Changing OTDR Settings

- 3. Select how you want to set the thresholds:
 - If you want to use the threshold values from the measurement file, select the corresponding option. However, if you are working with older file versions, the threshold values may not be available.



- If you want to use the threshold values from the application, proceed as follows:

Select one or several wavelengths to modify.


If you do not see a wavelength, you can add it by clicking the  button, entering the wavelength value, and clicking **OK**.

Modify the thresholds associated with the wavelengths needed, by clicking in the desired threshold value and modifying it in the table. The **Apply** option must be enabled for the threshold to be active and modifiable.

Note: *If you are using the fiber attenuation section threshold, you can specify the minimum section length at the bottom of the table. This can be useful when testing short links, as attenuation measurements on them can be unreliable. The fiber section threshold will not be applied to fiber sections shorter than the length you have set as a minimum value.*

If you have selected more than one wavelength, all of them will be modified at the same time.

Select whether you want to include the span start and end values in your threshold calculations.



Note: When the span start and span end values are included, the corresponding events are included in the ORL calculation. The span start and end loss values, and the span ORL values are updated when the span start and span end inclusion settings are modified. The maximum splice loss is also impacted by the fact that the span start and end values are included or not.

Note: When span start and span end values are excluded, pass/fail thresholds are no longer applied to the corresponding span start or span end events.

- To apply the changes without closing the dialog box, click **Apply**. To apply the changes and close the window, click **OK**.

Working with OTDR Files

Changing OTDR Settings

Note: If the measurement contains connector loss and splice loss for a merged event, the loss value status and measurement status is calculated on the basis of the selected thresholds. If thresholds are applied and the status is pass, the measurement status is indicated as pass. If thresholds are applied and the status is fail, the measurement status is indicated as unknown. If none of the thresholds are applied, the measurement status is indicated as unknown.

Note: When the span ORL value is preceded by a “<” and the ORL threshold is smaller than or equal to the value, the global pass/fail status for the measurement will be unknown or fail.

To view and modify a threshold value for the current measurement:

1. From the **Files** or **Measurement** tab, select the measurement or measurements as desired.

The current pass/fail threshold statuses are indicated in the list: green for pass, yellow for warning and red for fail.



P/F	Identifiers	Type	Direction	Span Length	Span Loss	Span ORL	Events Count	Test Date/Time
	<Cable ID>	Fil	OTDR-1550 A->B	6.4600 km	5.063 dB	<19.50 dB	7	3/1/2004 11:37:4
✖	Fiber0003	OTDR-1550 A->B		8.4376 km	1.571 dB	<24.56 dB	2	3/4/2004 12:51:0
✖	Fiber0003	OTDR-1550 A->B		8.4395 km	1.607 dB	<21.35 dB	2	3/3/2004 11:44:1
✔	0014;0002	OTDR-1310 A->B		39.9987 km	13.693 dB	31.22 dB	5	4/3/2007 11:14:0
✔	Fiber0003	OTDR-1550 A->B		41.7120 km	10.495 dB	30.88 dB	4	3/4/2004 2:28:23
✖	Fiber0190	OTDR-1550 A->B		232.8084 km	47.141 dB	31.83 dB	9	5/11/2010 3:57:0
✖	Fiber0190	OTDR-1625 A->B		232.7588 km	45.910 dB	32.85 dB	8	5/11/2010 4:00:0
✖	Fiber0190	OTDR-1310 A->B		1.4906 km	2.268 dB	<19.89 dB	9	5/11/2010 3:51:4
✖	Fiber0190	OTDR-1550 A->B		1.4906 km	1.823 dB	<20.13 dB	6	5/11/2010 3:52:1
✖	Fiber0190	OTDR-1625 A->B		1.4907 km	1.860 dB	<19.34 dB	9	5/11/2010 3:52:5
✖	Fiber0190	OTDR-1310 A->B		1.3708 km	8.782 dB	32.22 dB	12	5/11/2010 3:26:1
✖	Fiber0190	OTDR-1550 A->B		1.3707 km	7.868 dB	30.54 dB	12	5/11/2010 3:27:0
✖	Fiber0190	OTDR-1625 A->B		1.3706 km	7.748 dB	29.73 dB	12	5/11/2010 3:27:4
✖	OTDR-1550 A->B			43.4225 km	28.505 dB	34.57 dB	8	3/23/2004 12:10:0

2. In the **Results** window, select the **Thresholds** tab.

- If you want to modify a threshold at this point, double-click in the corresponding field, and enter the new value.

Wavelength
1550

Thresholds for 1550 nm

Description	Apply	Fail	Warning
Unidir splice loss	<input checked="" type="checkbox"/>	1.000 dB	1.000 dB
Bidir splice loss	<input type="checkbox"/>	---	---
Unidir connector loss	<input checked="" type="checkbox"/>	1.000 dB	1.000 dB
Bidir connector loss	<input type="checkbox"/>	---	---
Reflectance	<input checked="" type="checkbox"/>	-40.0 dB	-40.0 dB
Fiber section attenuation	<input checked="" type="checkbox"/>	0.400 dB/km	0.400 dB/km
Span loss	<input checked="" type="checkbox"/>	45.000 dB	45.000 dB
Span length	<input checked="" type="checkbox"/>	0.0000 km	0.0000 km
Span ORL	<input checked="" type="checkbox"/>	15.00 dB	15.00 dB

Fiber section attenuation
Minimum section length 0.0000 km

Event calculation and thresholds
 Include span start values
 Include span end values

Note: *If you are using the fiber attenuation section threshold, you can specify the minimum section length at the bottom of the table. This can be useful when testing short links, as attenuation measurements on them can be unreliable. The fiber section threshold will not be applied to fiber sections shorter than the length you have set as a minimum value.*

Note: *If there are more than one threshold value for a given wavelength, they are separated by a semicolon.*

Working with OTDR Files

Changing OTDR Settings

4. If you are using the application's event calculations and thresholds, you can also select whether you want to include the span start and end values.

Wavelength: 1550

Thresholds for 1550 nm

Description	Apply	Fail	Warning
Unidir splice loss	<input checked="" type="checkbox"/>	1.000 dB	1.000 dB
Bidir splice loss	<input type="checkbox"/>	---	---
Unidir connector loss	<input checked="" type="checkbox"/>	1.000 dB	1.000 dB
Bidir connector loss	<input type="checkbox"/>	---	---
Reflectance	<input checked="" type="checkbox"/>	-40.0 dB	-40.0 dB
Fiber section attenuation	<input checked="" type="checkbox"/>	0.400 dB/km	0.400 dB/km
Span loss	<input checked="" type="checkbox"/>	45.000 dB	45.000 dB
Span length	<input checked="" type="checkbox"/>	0.0000 km	0.0000 km
Span ORL	<input checked="" type="checkbox"/>	15.00 dB	15.00 dB

Fiber section attenuation
Minimum section length: 0.0000 km

Event calculation and thresholds

Include span start values Include span end values

Note: Some threshold values may not be available for older file versions.

Setting Macrobend Tolerances

FastReporter 2 can locate macrobends by comparing the loss of events occurring at a certain wavelength (for example, 1310 nm) with the loss of the corresponding events at a greater wavelength (for example, 1550 nm).

FastReporter 2 will identify a macrobend when comparing two events if:

- Of the two events, the greater loss occurred at the greater wavelength.
AND
- The difference between the loss of two events exceed the defined delta loss value. The default delta loss value is 0.5 dB (which is suitable for most fibers), but you can modify it.

Changes made to event matching tolerances will affect macrobends.

To set macrobend tolerances:


- 1.** On the **Settings** menu, select **OTDR**.
- 2.** Click the **Tolerances** tab.

Working with OTDR Files

Changing OTDR Settings

- Under **Macrobend tolerances**, change the tolerance value for wavelength pairs as needed.
 - To add a wavelength pair, click the **+** button, enter the wavelength values, and click **OK**.
 - To remove unwanted pairs, select the values in the **Wavelength Pair** list, and click the **X** button.

Note: If you select more than one wavelength in the list, any modification to the thresholds will apply to all of the selected wavelengths.



Note: To remove all added wavelength pairs and set all tolerance values back to their original settings, click **Default Settings**.

- Click **OK** to exit the window.

To view macrobends:

From the main window, make sure that the macrobends are displayed in the event table: on the **View** menu, select **OTDR**, select **Event Table**, and click **Macrobends**.


Macrobends are identified in the OTDR Event Table by the following symbol: .

In the case where you have multiple files with a single wavelength (this often occurs for Telcordia type files), you must first match those files in order to see the possible macrobends in the **Matched Files** tab, then select these matched files to view the macrobends in the event table.

Setting Event Matching Tolerances

The OTDR Event Table is built by matching events from selected measurements according to the tolerance. To be matched, the distance between events from the different measurements must be within the tolerance.

You can force the matching of two events or separate them by changing the event matching tolerance accordingly. The tolerance is applied to all operations related to the event table including apply reference as template and macrobends.




Although you can set the event matching tolerance to as little as 20 meters for each pulse width, the results may differ due to *cursor aliasing*. Cursor aliasing checks if markers A and B for two events overlap. These markers are set during analysis. Marker A represents the beginning of a measured event while marker B represents its end.

This means that two events could be matched in the event table even if their markers A are farther apart than the tolerance if there is an overlap between the spans created by their markers A and B. Cursor aliasing becomes more important with larger pulse widths since these traces have greater A-B spans.

To change OTDR event matching tolerances:

1. On the **Settings** menu, select **OTDR**.
2. Click the **Tolerances** tab.




Working with OTDR Files

Changing OTDR Settings

- Under **Event matching tolerances**, change the tolerance value for pulses as needed.
 - To add a pulse, click the **+** button, enter the pulse value, and click **OK**.
 - To remove unwanted pulses, select the values in the **Pulse** list, and click the **X** button.

Note: If you select more than one pulse in the list, any modification to the thresholds will apply to all of the selected pulses.



Note: To remove all added pulses and set all tolerance values back to their original settings, click **Default Settings**.

- To apply the changes without closing the dialog box, click **Apply**. To apply the changes and close the dialog box, click **OK**.

See *Setting Macrobend Tolerances* on page 133 for instructions on using the **Macrobend tolerances** section on the **Tolerances** tab.


Using the Auto Template (FR2-FC Mode)

The auto template lets you add and remove events on links based on their occurrence on the total group of selected links. You can set a percentage value that will indicate whether an event should be added or removed. The auto template is particularly useful for obtaining uniformity when testing many traces on a same fiber.

Once the auto template is used, you can analyze the results; if there are issues with some of the elements, you can view them in a descriptive summary.

To enable and use the auto template in your project:


1. On the **Settings** menu, select **OTDR**.
2. Click the **Auto Template** tab.
3. Enable the option to be able to set the preferences.




Working with OTDR Files

Using the Auto Template (FR2-FC Mode)

4. If you want to add events, select the corresponding option and enter the minimum percentage value of occurrences required to add the event to the remaining links.




5. If you want to remove events, select the corresponding option and enter the percentage value of occurrences under which the event must fall to be remove it from the measurement.




6. To apply the changes without closing the dialog box, click **Apply**. To apply the changes and close the window, click **OK**.

To apply auto template settings to the current measurements:

1. Open the measurements you want to include in the auto template operation.
2. From the **Measurement** menu, select **OTDR**, then Event and **Auto Template**.
3. If you want to add events, select the corresponding option and enter the minimum value of occurrences required to add the event to the remaining links.



4. If you want to remove events, select the corresponding option and enter the value of occurrences under which the event must fall to be remove it from the measurement.




5. Click **OK** to confirm your choice and start the operation.

Note: The values modified in the window will not be kept for future applications of the auto template. They are for the current measurements only.

Working with OTDR Files

Using the Auto Template (FR2-FC Mode)

The events will be added or deleted according to the Auto template settings. The results will be updated in the **Event Table**. If some issues occur during the process, a summary will indicate which event is concerned.



Identifiers	Event Position (km)	Action	Description
No Identifiers	0,1253	Span End	Unable to perform this operation because the
Fiber0190	0,1253	Span End	Unable to perform this operation because the
Fiber0190	0,1253	Span End	Unable to perform this operation because the
Fiber0190	0,1253	Span End	Unable to perform this operation because the
Fiber0190	0,1253	Span End	Unable to perform this operation because the
Fiber0190	0,1253	Span End	Unable to perform this operation because the
Fiber0190	0,1253	Span End	Unable to perform this operation because the

Managing the OTDR Event Table View

The OTDR event table can be customized to show only the items that are relevant for your tests. The items you can display or hide include the following:

- Fiber ID
- Fiber Pass/Fail Status
- Wavelength
- Direction
- Event
- Section
- Event Loss
- Event/Section statistics
- Fiber statistics
- Bidir. details (direction, average)
- Reflectance
- Merge details

Working with OTDR Files

Managing the OTDR Event Table View

- Macrobends
- Event position
- Span start/end events
- B -> A position from B (if the bidir details and event position are displayed in the window, this will display the event positions according to B, for example, the last event will be identified as the first event).
- Display the event type as text or as an image
- Section loss
- Attenuation
- Section length
- Values relative to the reference file

OTDR events can be edited if the file format supports modification.

To customize the Event Table view:

1. On the **View** menu, select **OTDR**, then **Event Table**.
2. Select or clear any of the event or segment views as desired.

Note: You can also select the items by right-clicking into the event table itself. The available items depend on where you click in the table.

To edit OTDR events:

1. From the main window, select the **Event Table** tab in the **Results** window.
2. In the **Event** or **Section** column, click the right mouse button.
3. On the shortcut menu, click any of the following edit options:

Edit Option	Description
Delete	Displays a dialog box to confirm deletion of the selected event. Click Yes to delete or No to cancel. An event can be deleted only if the file format supports modification. You cannot delete the Span Start event if it is the same as the Launch level and you cannot delete the Span End event if it is also the End of fiber, End of analysis or if it is a Continuous fiber (no End of fiber event).
Set as Span Start	Sets the selected event as the span start.
Set as Span End	Sets the selected event as the span end..
Add to other measurements	Adds the selected event to other selected OTDR measurements. An event can be added to other measurements only if the file format supports modification.
Properties	Displays the OTDR Event Properties dialog box, where you can edit properties for the selected events or sections.

Working with OTDR Files

Managing the OTDR Event Table View

These edit options, with the exception of **Delete**, are also available on the **Measurement** menu (select **OTDR**, then **Event**). The **Delete** option is available on the **Edit** menu. The actions can be performed regardless of the direction.

You can edit the properties for OTDR events and sections. Event properties that cannot be edited are shaded.

To edit OTDR event properties:

1. In the **Measurements** window, select an OTDR measurement file.

The screenshot shows the FastReporter 2 software interface. On the left, there is a graph of an OTDR trace showing signal loss in dB over a distance of 50 km. The trace has several events marked with red arrows and numbers 1 through 6. On the right, a file list window is open, showing a list of OTDR measurement files. The file '1110_1550_OTDR' is selected and highlighted in red.


Fiber ID	P/F	Wavelength (nm)	Dir.	Event 1 (3/3)	Section (3/3)	Event 2 (1/3)	Section (1/3)	Event 3 (2/3)	Section	
0022	✓	1310	A-B	Launch Level	9.5178 km	Positive	9.5178 km	0.5067 km	Non-reflective	
				Loss (dB)	RefL (dB)	Loss (dB)	Att. (dB/km)	Loss (dB)	Att. (dB/km)	
0022	✓	1350	A-B	---	-42.2	3.328	0.350	0.159	3.743	0.356
0022	✗	1625	A-B	---	-41.8	2.496	0.249			

2. In the **Event** table, select the events or sections to modify.

The screenshot shows the 'Results' window in FastReporter 2, specifically the 'Event Table' tab. The table displays the OTDR measurement data. A red box highlights the 'Event 1 (3/3)' column, which contains the 'Launch Level' event. The table also shows sections and other events, with some cells shaded to indicate they are not editable.

Fiber ID	P/F	Wavelength (nm)	Dir.	Event 1 (3/3)	Section (3/3)	Event 2 (1/3)	Section (1/3)	Event 3 (2/3)	Section	
0022	✓	1310	A-B	Launch Level	9.5178 km	Positive	9.5178 km	0.5067 km	Non-reflective	
				Loss (dB)	RefL (dB)	Loss (dB)	Att. (dB/km)	Loss (dB)	Att. (dB/km)	
0022	✓	1350	A-B	---	-42.2	3.328	0.350	0.159	3.743	0.356
0022	✗	1625	A-B	---	-41.8	2.496	0.249			

3. On the **Measurement** menu, select **OTDR**, select **Event**, and click **Properties**.
4. Modify the properties as needed. The editable values are shown in a white background.
 - You can change the event type from the list of available choices.
 - To add information about the event, type in a comment in the corresponding location.



Note: *The comment that you enter in the **Comments** field is displayed as a tooltip when you hover the mouse pointer over the event in the graph area and event table.*


5. Click **OK** to confirm your changes.

Changing the Main Measurement

FastReporter 2 allows you to select which wavelength is the main measurement for your files.


To change the main measurement:

1. In the **Files** window, select the file for which you want to change the measurement.



2. On the **Measurement** menu, click on **Main**.

3. In the **Main Measurement Selection** window, select the required wavelength and click **OK** to set it as the main measurement.



Note: *When you hover the mouse pointer over the selection area of a trace which is not the main measurement, a tooltip with the fiber ID and measurement wavelength is displayed.*

Setting the OTDR Graphic Display Options

You can change the display of graphics for OTDR measurements.

To change OTDR graphic display options:

1. On the **View** menu, select **OTDR** to display the OTDR graphic display options.
2. Select or clear any of the following OTDR graphic display options:
 - **Outside Spans** to display or hide information outside the measurement spans on the graph, when the zoom level is set to 100 % (1:1).
 - **Markers** to display or hide markers on the graph.
 - **Invert B->A dB Axis** to invert B to A along the dB axis on the graph.

Viewing Section Length for the Linear View

When in linear view, the application displays the section length between the events. You can also choose to hide it.

To view or hide the section length:

1. Select the Linear view for your files.
2. Right-click on the a link and select **View Section Length**.

Using the Zoom Functions

Various zoom options can help you to view specific portion of the graph window.

To select the OTDR zoom options:

1. On the **View** menu, select **Zoom** to display the OTDR zoom options.
2. Select one of the following OTDR zoom options:

Icon	Description	Shortcuts
	100 % (1:1) to display the full graph for the measurement (default setting).	Ctrl + Home
	<p>Horizontal zoom to zoom and view the graph horizontally. You can do the horizontal zoom in the following ways.</p> <ul style="list-style-type: none"> ➤ Press Ctrl + Alt, then scroll the mouse wheel forward or backward. ➤ Press Ctrl + Alt and drag the mouse over the part of the graph that you want to magnify, forming a rectangle. When you release the mouse button, the new zoomed area corresponds to the rectangle size and position. <p>Note: <i>If you press Ctrl + Alt but do not select a rectangle size, the graph is zoomed by a 2X factor.</i></p>	Ctrl + Alt

Working with OTDR Files

Using the Zoom Functions

Icon	Description	Shortcuts
	<p>Vertical zoom to zoom and view the graph vertically.</p> <ul style="list-style-type: none">➤ Press Ctrl + Shift, then scroll the mouse wheel forward or backward.➤ Press Ctrl + Shift and drag the mouse over the part of the graph that you want to magnify, forming a rectangle. When you release the mouse button, the new zoomed area corresponds to the rectangle size and position. <p>Note: <i>If you press Ctrl + Shift but do not select a rectangle size, the graph is zoomed by a 2X factor.</i></p>	Ctrl + Shift
	<p>Horizontal + vertical zoom to zoom and view the horizontal as well as vertical details of the graph for the selected measurement.</p> <ul style="list-style-type: none">➤ Press Ctrl, then scroll the mouse wheel forward or backward.➤ Press Ctrl and drag the mouse over the part of the graph that you want to magnify, forming a rectangle. When you release the mouse button, the new zoomed area corresponds to the rectangle size and position. <p>Note: <i>If you press Ctrl but do not select a rectangle size, the graph is zoomed by a 2X factor.</i></p>	Ctrl
	<p>Selected event from file to zoom to a selected event saved in the file, if present, auto zoom (event splice level) is applied.</p>	None

Icon	Description	Shortcuts
	Manual zoom from file to manually zoom using the information saved in the file. Once this option is selected, it displays the saved zoomed area even if you change the measurement selection.	None
	Undo last zoom operation.	None
	Auto-zoom on Event Splice	None
	Auto-zoom on Event Reflectance	None
	Auto-zoom on the 4 markers to focus where the analysis was used to calculate the event loss. Submarkers a and b are placed where the analysis was used to calculate the event loss, and markers A and B are placed where the analysis was used to calculate the event section loss	None

Managing Markers

FastReporter 2 allows you to set four markers (A, a, B, and b) for manual measurement purposes. You can move the markers independently, or you can also lock or unlock the distance between the four markers and move them as a block. You can lock or unlock the distance between the A and a marker pair, as well as the B and b marker pair and move them. Below you can see the list of the lock options.

- Lock All: All the markers are locked and can be moved as a group.
- Lock a,A: The distance between marker a and A are locked and can be moved as a group.
- Lock b,B: The distance between 'b' and 'B' are locked and can be moved as a group.

Note: *By default, the markers are activated. If you have deactivated them, they can be reactivated from the **View** menu, then **OTDR > Markers**.*

To lock and unlock the marker position:

On the **Measurement** menu, from the **OTDR** option, select **Markers** then click on the required lock option.

Note: *When none of the markers are in a locked mode, you can temporarily lock the distance between all markers and move them as a block by pressing the **Shift** key on the keyboard and dragging them around with your mouse.*

To modify the marker position:

Select the marker from the graph area and drag it to the desired position to modify the marker position.

OR

Select the marker from the graph area and move the marker by scrolling the mouse wheel forward and backward.


OR

Modify the marker position in the **Markers** table by entering a new marker position value direct input from the keyboard.

OR

Select the required marker(s) and move the selected marker(s) by clicking the left and right arrow keys of the keyboard.

Note: You can select the next visible marker by pressing the **Ctrl + Tab** keys.



Working with OTDR Files


Managing Markers

Performing Manual Measurements with Markers

The information related to the markers is displayed in the **Markers** and **Manual measurement** table under the **Markers** tab.

To display and hide the marker-related features:

The **Manual Measurement** table displays the information related to the markers, including their label. Right-click on the **Manual Measurement** table to select the required value option.



The screenshot shows the OTDR software interface with the 'Markers' tab selected. It contains two tables: 'Markers' and 'Manual Measurement'. The 'Manual Measurement' table is highlighted with a red box.

Marker	Position	Value
a	19.7231 km	49.175 dB
A	25.8279 km	47.993 dB
B	50.6604 km	43.153 dB
b	83.7671 km	36.742 dB
B-A	24.8326 km	4.840 dB

Manual Measurement	
4 points event loss	0.065 dB
2 points section attenuation	0.195 dB/km
3 points reflectance	*****
3 points maximum reflectance	*****
A-B ORL	31.97 dB

Various options of the **Manual Measurement** table are described below.

Option	Description
4 points event loss	In the 4 points event loss, four markers (a, A, b, and B) are visible. This least square approximation method is used to fit a straight line to the backscatter data within the two regions defined by markers a, A and b, B, that is over the regions to the left and to the right of the event bordered by markers A and B, respectively.
A-B LSA loss	This loss of event bordered by the markers A and B is obtained by fitting a straight line to the backscatter data between these two markers.
2 points section attenuation	In the 2 points section attenuation, two markers (A and B) are visible. This measurement gives the reduction in Rayleigh backscatter level as a function of distance (always expressed in dB/km to follow the standards of the fiber-optic industry) between two selected points. Only those two points are used to perform the calculation and there is no averaging.
A-B LSA attenuation	This LSA attenuation is obtained by fitting a straight line between two points in the backscatter data between markers A and B.
A-B ORL	This displays the ORL between markers A and B.
3 points reflectance	In the 3 points reflectance, three markers (a, A, and B) are visible. This measurement displays the reflectance pointed by marker a, A, and B.
3 points maximum reflectance	This measurement displays maximum reflectance for the selected event.

Adding an OTDR Event with one Marker

FastReporter 2 allows you to add a new OTDR event according to the position of marker A. It automatically repositions the markers other than A at the best position to characterize the most probable event in the area. It automatically selects the appropriate event type according to the measurement characteristics such as reflective event, non-reflective event, or positive event.

To add an OTDR event with one marker:

1. On the graph, place marker A where you want to add an event.
2. On the **Measurement** menu, from the **OTDR** option, select **Event** then click **Add Event with Marker A**.

Note: *You cannot perform this operation if the origin of the selected file does not allow modifications. For example, you cannot perform this operation on "Telcordia 100" files from other OTDR manufacturers.*

Note: *You cannot add an event using marker A on bidirectional OTDR files.*

Note: *The manually modified events are displayed with an asterisk (*) mark. For more information on changing display options, see Changing FastReporter 2 Options on page 28.*

Adding an OTDR Event with all Markers

The application allows you to add a new OTDR event according to the position of all the markers. It selects the most appropriate event type according to the measurement characteristics such as reflective event, non-reflective event, or positive event.

To add an OTDR event with all markers:

- 1.** On the graph, place all of the markers where you want to add an event.
- 2.** On the **Measurement** menu, from the **OTDR** option, select **Event**, then click **Add Event with All Markers**.

Note: *You cannot perform this operation if the origin of the selected file does not allow modifications. For example, you cannot perform this operation on "Telcordia 100" files from other OTDR manufacturers.*

Note: *You cannot add an event using all markers on bidirectional OTDR files.*


Working with OTDR Files

Managing Markers

When an event cannot be created in the specified position, an error message is displayed. You cannot create any event in following conditions:


- If the marker from any event is present in between markers A and B.

For example: In the below image the gray markers indicate the position of the earlier event and the blue lines indicate the position where you are trying to add new event. In this condition the application displays an error message, to indicate that you cannot insert new event.



- If any event is present between two markers.

For example: In the below image, the blue lines indicate the position of the marker for the new event which you are trying to add. Event 3 is shown between these two markers. In this condition the application displays an error message, to indicate that you cannot insert new event.



Note: *The manually modified events are displayed with an asterisk (*) mark. For more information on changing display options, see Changing FastReporter 2 Options on page 28.*

Modifying Event Marker Positions on Existing Events


FastReporter 2 allows you to reposition the existing events.

To modify the event markers position on an existing event:

- 1.** On the graph, select the event for which you want to modify the marker position.
- 2.** On the **Measurement** menu, from the **OTDR** option, select **Event**, then click **Modify Event Markers**.
- 3.** Modify the marker position from the graph window.

Note: *When the event marker repositioning operation is initiated, the four manual markers position are set to match the selected events own markers. Once the event marker's new position is confirmed, then all the information related to the event is updated.*

4. Press Enter to confirm the repositioning or Esc to cancel the process.



Note: If marker repositioning is not possible in the particular position, a notification message is displayed.

Note: You cannot perform this operation if the origin of the selected file does not allow modifications. For example, you cannot perform this operation on "Telcordia 100" files from other OTDR manufacturers.

Note: You cannot modify event markers on bidirectional OTDR files.

Note: The manually modified events are displayed with an asterisk (*) mark. For more information on changing display options, see Changing FastReporter 2 Options on page 28.

Adding Event to Other Measurements

The application allows you to add the event position of the selected OTDR or bidirectional OTDR measurement to other selected measurements.

Note: *You can add the event position in both actual and virtual bidirectional OTDR measurements.*

Note: *An event can be added to other measurements only if the file format supports modification.*

To add event to other measurements:

1. On the graph, right-click on the event which you want to add on other measurements.

OR

In the **Event Table** tab, right-click on the event.

2. Select **Add to Other Measurements**. The selected event will be added to other selected measurements.

Retrieving Marker Position from File

The application allows you to retrieve the marker position to the original values when the file was last opened or saved.

To retrieve the marker position from file:

- 1.** On the **Measurements** window select the required measurement.
- 2.** On the **Measurement** menu, from the **OTDR** option, select **Marker** then **Markers From File**.

Note: *If there are no marker positions for the measurements, the application sets the marker position with a spacing value of 1/5 of the span length.*

Setting and Applying OTDR/OTDR Bidir Reference as Template (FR2-FC Mode)

The **Apply Reference as Template** tool allows you to analyze measurements and compare them to a reference file. The template concept is to set a reference file (template), add comments about the events, and compare each measurement to the reference file. FastReporter 2 will mark and measure any missing event. Inserted events are indicated by an asterisk (*). Event matching tolerances will affect template results. Events not present in the reference appear as white columns. Comments for events in the reference file are automatically copied to the selected files.

Note: *The measurement file format must support this feature.*

Note: *DWDM OTDR files cannot be used to set a reference as a template.*


Singlemode measurements will be compared to singlemode measurements; multimode measurements will be compared to multimode measurements.

The measurement files must meet the following criteria:

- It must have at least two events.
- It must have a span start and a span end.
- It must have a fiber section.

To set and apply OTDR and bidirectional OTDR files as a reference template:

1. In the **Files** tab, select the OTDR or bidirectional OTDR file that you want to use as the reference.
2. In the **Files** tab, select the OTDR file that will serve as the reference.




3. On the **File** menu, click **Set as Reference File**.

Note: You can also set the virtual OTDR bidirectional file as reference from the **Measurements** tab and **Event Table**.

Working with OTDR Files


Setting and Applying OTDR/OTDR Bidir Reference as Template (FR2-FC Mode)

4. In the **Files** window, select the OTDR files to which you want to apply the reference file as a template.



5. On the **Tools** menu, point to **OTDR**, and click **Apply Reference as Template**.

6. Set the parameters for the OTDR template.



- **Use same wavelength for all measurements:** to apply the same wavelength to all measurements. If a file with multiple wavelength files is used as a reference and the option is not selected, the measurements will be compared to the same wavelength (1310 nm with 1310 nm, 1550 nm with 1550 nm).
- **Remove events not present in reference:** to remove the events not present in the reference file from the selected files.
- **Apply reference spans start/end:** to apply the reference measurement's spans to the selected files.
- **Apply reference event types:** to apply the events between the span start and span end events. This option is active for the current working session only and will be reset when the application is started again.
- **Apply manual measurement markers and zoomed area:** to apply the reference's marker position and zoom to the selected files. If the marker positions is outside the range of the trace destination, the operation will be aborted and the destination trace keeps its original zoom factor.

Working with OTDR Files

Setting and Applying OTDR/OTDR Bidir Reference as Template (FR2-FC Mode)

- **Copy documentation from reference (except Fiber ID):** to include all of the available documentation to the selected files. The fiber ID will not be copied.
- **Copy reference event markers (a,A,B,b) position:** to apply the reference file markers to the selected files.

Note: *You are notified when the zoom is not applied.*

Note: *This option is available only if the **Markers** option is enabled from **View > OTDR > Markers**.*

- **Copy documentation from reference (except Fiber ID):** to apply the documentation from the reference file to the selected files. The documentation includes job ID, customer, company, operator A, operator B, cable ID, location A, location B, and comments.
- **Copy reference events markers (a,A,B,b) position:** to copy the events markers (a, A, B, b) from the reference measurement to the selected files.

Note: *When an event marker position from the reference measurement cannot be copied to the selected measurement due to length constrain or any other reason, the application does not display any error message.*

7. Click **OK**.

Analyzing Measurements

FastReporter 2 lets you analyze the unidirectional and bidirectional OTDR measurements at any time.

The bidirectional measurements are reanalyzed when A->B or B->A measurements are reanalyzed, and in case of the following modifications:

- Event addition
- Event deletion
- Change in event type
- Change in span start position
- Change in span end position
- IOR
- Helix Factor
- Splice Loss Threshold
- Reflectance Threshold
- End-of-Fiber Threshold

Analyzing measurements will:

- analyze measurements acquired from different sources or with other products.
- recreate the original event table if it was modified.
- reset the span start to zero and the span end to end-of-fiber, if desired.

Working with OTDR Files

Using the Failed Items Filter

To analyze measurements:

1. In the **Measurements** tab, select the measurements to analyze.

Note: *You can analyze the multiple measurements of the unidirectional and bidirectional OTDR file, only if the FR2-FC option or trial option is activated in the application.*

2. On the **Measurement** menu, select **OTDR**, and click **Analyze**.
3. Select whether you want to keep the span start and end positions, or if you want to reset them to zero.



4. Click **OK**.

Once the analysis is performed, the window is refreshed automatically. Information such as IOR, Helix factor, splice loss threshold, reflectance threshold, end-of-fiber threshold are analyzed.

Note: *A->B and B->A are re-analyzed when a real bidirectional file is re-analyzed.*

Using the Failed Items Filter

In order to quickly see which events are faulty, you can apply a specific filter to show only the failed items.

To activate the failed item filter:

In the **Event Table** tab, right-click in the table, then select **View Failed Items**.

Displaying Statistics for Measurements

When displaying matched measurements, it might be useful to view statistics for them. The statistics are displayed for:

- Fibers (includes loss for splices, connectors and sections, reflectance for connectors, and attenuation data for sections), which are displayed on the far right of the **Events Table** tab.
- Events and Sections (includes event position, loss and reflectance, section length, loss and attenuation), which are displayed at the bottom of the **Events Table** tab.

The statistics displayed are the minimum value, the maximum value, and an average for the selected files. If you click on the minimum and maximum values, the corresponding event is highlighted in the Graph or Linear views, and in the events table.

Note: *You must have enabled the corresponding item for the statistic to appear. For example, if you chose not to display the positions, the corresponding statistic is also hidden.*

To display the statistics:


1. Select the multiple measurements for which you want to view the statistics.
2. In the **Events Table** tab, right-click in one of the fixed columns, and select the type of statistics you want to view.

Setting Span Positions with Absolute Lengths


The application allows you to set the span start and span end positions using definite values.

To set the span positions:

1. In the **Measurements** window, select the measurements for which you want to set the span.
2. On the **Measurement** menu, click **OTDR** and select **Set Spans by Distance**.
3. Set the launch fiber length as required. Once you set the launch fiber length, the application updates the span start position and span length value based on the new position of the span start. If no event is present at the new position of the span start, it automatically creates a new event.



4. Select whether you want to enter the span length or the receive fiber length, then enter the appropriate value. The other value is updated automatically according to the value you have entered. If no event is present at the new position of the span end then, it automatically creates a new event.



The screenshot shows a dialog box titled "Spans by Distance". It contains the following fields and controls:

- Absolute fiber length: 44.4740; 44.47 km
- Launch fiber length: 0.0000 km
- Span length: 44.4740; 44.47 km
- Receive fiber length: 0.0000 km
- OK button
- Cancel button

5. Click **OK** to save the change or **Cancel** to discard it.

Note: When a new event is created, the exact event position, event type, and measured values are automatically determined to have the best characterization for the most probable event present in the area. When a new event is successfully created, the event is marked with an asterisk (*).


Note: If the origin of the selected file origin does not allow modification, an error message is displayed.

Setting the IOR Value by Distance

The application allows you to modify the IOR value for each selected measurement by modifying the distance from span start to span end.

To modify the IOR value:

1. On the **Measurements** tab select the measurements you want to modify.
2. On the **Measurement** menu, click on **OTDR** and select **Set IOR by Distance**.
3. Enter the distance of span start to span end.



Note: *When the distance values from the selected measurements are not the same, the values are displayed with a semicolon. Once the new IOR values are calculated, the values related to the position and distance and the OTDR graph are updated.*

4. Click **OK** to save the changes or **Cancel** to discard them.


Changing Fiber Core Size (FR2-FC Mode)

The FastReporter 2 application displays the core size of the fiber for the selected measurement in the **Test Settings** table of the **Summary** tab. When multiple measurements are selected and the fiber core sizes are not similar, they are separated with a semicolon.

Note: *The application allows you to change the fiber core size only for the multimode files.*

To change the fiber core size:

1. On the **Measurements** tab, select the multimode measurement for which you want to modify the fiber core size.
2. From the **Summary** tab, select the required fiber core size in the list of available values.



The screenshot shows the OTDR Summary tab with three tables: Results, Test Parameters, and Test Settings. The 'Fiber core size' dropdown in the Test Settings table is highlighted with a red circle.

Results		Test Parameters		Test Settings	
Span length	3.8180; 3.8229 km	Wavelength	1300 nm (62.5 μm); 850	IOR	1.487000; 1.49000
Span loss	5.110; 14.464 dB	Range	5.0000 km	Backscatter	-70.30; -63.10 dB
Average loss	1.338; 3.783 dB/km	Pulse	100 ns	Helix factor	0.00 %
Average splice loss	0.174; 0.358 dB	Duration	45 s	Splice loss detection threshold	0.020; 0.100 dB
Maximum splice loss	0.328; 0.358 dB	High resolution	No	Reflectance detection threshold	-72.0 dB
Span ORL	22.86; 24.92 dB	Resolution	0.630; 0.629 m	End-of-fiber detection threshold	25.000 dB
				Fiber core size	62.5 μm

Revert to File Test Settings

3. The application prompts you to confirm the change. Click **Yes** to set the default values for result and test settings. If you click **No**, the fiber core size value changes, but the default values are not applied for result and test settings.

Note: *You cannot perform this operation if the origin of the selected file does not allow modifications. For example, you cannot perform this operation on "Telcordia 100" files from other OTDR manufacturers.*

Working with OTDR Files

Reverting to File Test Settings

Reverting to File Test Settings


The application allows you to revert the test settings parameters values to the file original values. The retrieved values are IOR, backscatter, Helix factor, splice loss threshold, reflectance threshold, end-of-fiber threshold and fiber core size. The result values are automatically updated to reflect the change.

Note: You can revert to file test settings for multiple files only if the FR2-FC option is activated.

Note: You cannot use this feature when you open a competitor's .SOR files and iOLM generated .SOR files.

To revert to file test settings:

1. On the **Files** tab select the OTDR files you want to modify.
2. From the **Summary** tab, click the **Revert to File Test Settings** button, then confirm your choice.



The screenshot shows a software window titled "Results" with tabs for "Identification", "Summary", "Thresholds", "Event Table", and "Markers". The "Summary" tab is active, displaying OTDR data in three columns: Results, Test Parameters, and Test Settings. A "Revert to File Test Settings" button is highlighted with a red circle at the bottom right.

Results	
Span length	3.8180; 3.8229 km
Span loss	5.110; 14.464 dB
Average loss	1.338; 3.783 dB/km
Average splice loss	0.174; 0.358 dB
Maximum splice loss	0.328; 0.358 dB
Span ORL	22.86; 24.92 dB

Test Parameters	
Wavelength	1300 nm (62.5 µm); 850
Range	5.0000 km
Pulse	100 ns
Duration	45 s
High resolution	No
Resolution	0.630; 0.629 m

Test Settings	
IOR	1.487000; 1.4900
Backscatter	-70.30; -63.10 dB
Helix factor	0.00 %
Splice loss detection threshold	0.020; 0.100 dB
Reflectance detection threshold	-72.0 dB
End-of-fiber detection threshold	25.000 dB
Fiber core size	62.5 µm

Revert to File Test Settings

Managing Bidirectional OTDR Files (FR2-FC Mode)

FastReporter 2 can be used to analyze bidirectional OTDR files, and create them using unidirectional files and combining them.

Analyzing Bidirectional Measurements

If two OTDR measurements were acquired in opposite directions on the same fiber span, you can use the Create Bidirectional Files tool to match the corresponding events. FastReporter 2 performs a bidirectional analysis and generates an event table with the averaged loss for each event; that is, the average of the losses obtained from both directions.

Bidirectional analysis is the recommended method for splice loss measurements on singlemode fibers by the Telecommunications Industry Association (test procedure *EIA/TIA FOTP-61 Measurement of Fiber or Cable Attenuation Using an OTDR*).

This method removes the so-called “gainers” (increase in the optical power) and exaggerated losses and provides accurate measurements. This analysis is particularly useful to test the quality of a link, especially if it comprises several sections with different types of fibers or fiber from different manufacturers.

Gainers and exaggerated losses result from the joining of two fibers of different mode-field diameters (MFD). The mode-field diameter of a fiber corresponds to the size of the area where light is dispersed across its core and cladding.

Mismatch of MFDs will contribute to differences in backreflected signals that are not related to the loss at the splice point, that is to the true loss seen in transmission. In this case, a unidirectional OTDR measurement will show an apparent increase (gainer) or decrease (exaggerated loss) in signal, depending on the direction of measurement.

Bidirectional averaging of OTDR splice loss measurements provides the most accurate splice loss results.

Working with OTDR Files

Managing Bidirectional OTDR Files (FR2-FC Mode)

Creating Bidirectional Measurement Files

You can combine unidirectional measurements into a bidirectional measurement file. It is possible to use both single-wavelength and multiwavelength measurements. FastReporter 2 matches the wavelengths.


The A->B and B->A measurement files must respect the following criteria:

Item	To be valid
Pulse width	Must be identical for both measurement files.
Fiber types	Use only measurements acquired using singlemode fibers.
Wavelengths	Must be identical for both measurements.
Measurement file	Both must be unidirectional files.


To create bidirectional files in FastReporter 2, you must first match A->B files with B->A files. For information on file matching, see *Matching Files* on page 51. Changes made to event matching tolerances will affect bidirectional event table results.

To create a bidirectional file:

1. Select two matched OTDR files of opposite directions.
2. Click on **Tools > OTDR > Create Bidirectional Files**.
3. Select the location where you want to save the bidirectional file.




4. Select the desired file naming options.
 - Select **A->B filename** or **B->A filename** to use the selected A->B or B->A file name.
 - Select **Autonaming** to enter a prefix and a suffix to create the file name.




Working with OTDR Files

Managing Bidirectional OTDR Files (FR2-FC Mode)

5. Select which documentation will be used for the bidirectional measurement.



6. Select whether you want to keep the original unidirectional files in your project once the bidirectional files are created.



7. Click **OK**.


Note: Bidirectional (.bdr) files do not support multiple wavelengths in the same file. When you save the bidirectional files, separate files will be created for each wavelength. The wavelengths are automatically added.

Creating Unidirectional Files From a Bidirectional File


Using FastReporter 2, you can take a bidirectional file and extract the two unidirectional files that were originally used to create it. The resulting files will have the same name as the bidirectional one, but with the direction automatically added.

To extract the unidirectional files:

1. From the main window, select the **File** menu, then **Export**, and **Create OTDR Unidir Files**.
2. If desired, select the location where you want to save the extracted files. The default location is where the original bidirectional file is located.




3. Select the format for the extracted files.




Working with OTDR Files

Managing Bidirectional OTDR Files (FR2-FC Mode)

4. Select whether you want to open the files in the application.



5. Select whether you want to keep the original bidirectional files in your project.



6. Click **OK** to extract the files and return to the main window.


Managing Unidirectional Markers Within a Bidirectional File

Bidirectional files are made of two separate traces in opposite directions. In FastReporter 2, you can see and manage the markers for each A->B and B->A traces. This allows you to calculate loss, ORL and other values for each unidirectional trace.

To access the unidirectional markers for a bidirectional file:

1. Open the desired bidirectional file.
2. If required, switch to the Graph display, as explained in *To select the viewing method:* on page 119.

3. In the **Event Table** tab, right-click in the table to display the **Bidir. Details**.



4. Select the A->B or B->A event for which you want to manage the markers.
5. In the **Markers** tab, modify the marker as needed. For more information, see *Managing Markers* on page 154.

Working with OTDR Files


Managing Bidirectional OTDR Files (FR2-FC Mode)

Working with Virtual Bidirectional Files

Virtual bidirectional files are a way to preview the resulting measurement when you select two matching unidirectional measurements without going through the process of fully creating the bidirectional file. The display in the graph and linear views, and the **Event Table** tab are the same as they would if you are viewing an actual bidirectional measurement. The order of display for the events depend of the A -> B measurement.

To activate the virtual bidirectional file mode:

From the **View** menu, select **OTDR**, then **Display Virtual OTDR Bidir.**



Creating Batch Documentation

FastReporter 2 includes a tool that can be used to batch document or analyze large numbers of OTDR test files. All identification information, with the exception of fiber ID, is copied from the reference file to the selected files. The automated documentation tool can also be used to automatically assign fiber IDs to selected files.

For details on using the automated documentation tool, see *Adding and Removing Measurement Files* on page 43.

Saving an OTDR File in a New File Format

You can save OTDR measurement files in a new file format.

To save OTDR files in a new file format:

1. In the **Measurement** or **Files** window, select the OTDR file or files that you want to save.
2. On the **File** menu, click **Save Selected Files As**.
3. When saving a single file, type a name for the file in the **File name** box.

OR

When saving multiple files, click  on the **Save As** dialog box and select an output folder on the **Browse for Folder** dialog box.

4. In the **Save as type** list, select the appropriate file format.
5. Click **Save**.

Note: *Some file formats (for example, Telcordia and FTB-300) do not support multiple wavelengths in the same file. When saving to those formats, separate files will be created for each wavelength.*



IMPORTANT

If you save an OTDR file in an older format than it was originally in, you will lose the type of data that is not supported by the older file format.

Generating Text Files From OTDR Measurements (FR2-FC Mode)

FastReporter 2 allows you to export the unidirectional or bidirectional OTDR files to a text file format. When one OTDR file is selected, the filename corresponds to the selected OTDR file, with a “.txt” extension. If multiple OTDR files are selected, you have to specify the file name.

Note: *This feature is only supported in OTDR files.*

To export the OTDR file to a text file:

- 1.** Select single or multiple OTDR files from the **Files** tab.
- 2.** From the **File** menu, click on **Export**, and select **To TXT measurement report**.


Select a desired location and enter the desired file name and click on **Save** to generate the text file.

Modifying Space Between Traces on the Graph


For easier viewing of the traces appearing on the graph, you can increase or decrease the vertical space between each of them.

To increase or decrease the space between the traces:

1. On the toolbar, select the  button.
2. Use the buttons in the toolbar or menu to increase or decrease the space between the traces.



An indicator on the left of the graph shows that an offset is applied.



If you are using a keyboard and mouse, you can press and hold the Shift key to select the trace, then use the arrow buttons, or the mouse to drag it to the desired location.

6 Working with OLTS Files

Accepted File Formats

FastReporter 2 lets you work with measurement files saved in different formats, but does not necessarily permit all operations on them.

File format	File extension	Display	Modification
FOT-920, FOT-930, FTB-3930	.olts	X	X
	.olts2	X	X
	.dat	X	X
	.oltsx	X	X
MAX-900	.olts	X	X
ConnectorMax 2	.cmax2	X	X

Note: *The .oltsx format includes both single- and multi-wavelength measurements.*

Note: *The 64-bit version of FastReporter 2 may not support all file formats. To view .olts files that come from FOT-930s or FTB-3930 modules, save them first in a newer .olts format using the 32-bit version of the application.*

Changing OLTS Settings

Depending on the type of files you are working with (whether they come from FTB-3930 and FOT-930 units, or the MAX-900 series), some settings can be modified.


You can change the identification settings for your FTB-3930 and FOT-930 files, as well as the pass/fail threshold values, which can come from different sources:

- From the measurement file
- From the application

In the case of files coming from the MAX-900 series, you can select the unit to display the reference value.

To change OLTS threshold settings:


1. On the **Settings** menu, select **OLTS**.
2. Select the **Pass/Fail Thresholds** tab.
3. Select the type of threshold to use for your analysis.



4. Set the wavelength list as needed if you are using the thresholds from the application:
 - To add a wavelength, click the  button, enter the wavelength value, and click **OK**.
 - To remove one or more wavelengths, select the values in the **Wavelength** list and click the  button.

Each wavelength can have different thresholds. If you have selected the custom thresholds, you can modify the values. The **Apply** option must be enabled for the values to be active and modifiable.

If you select more than one wavelength in the list, any modification to the thresholds will apply to all of the selected wavelengths.




5. To apply the changes without closing the dialog box, click **Apply**. To apply the changes and close the dialog box, click **OK**.

Working with OLTS Files

Changing OLTS Settings


You can view the results in the **OLTS Table** tab in the main window.



Note: In the case of multi-wavelength files, the reference unit may show dB and/or dBm depending on the measurement.

To select the display unit for the reference value on MAX-900 files:

1. On the **Settings** menu, select **OLTS**.
2. Select the **General** tab.
3. Select the desired unit.



The reference unit will be displayed in the **FasTest Table** tab between parentheses.

4. To apply the changes without closing the dialog box, click **Apply**. To apply the changes and close the dialog box, click **OK**.

Working with OLTS Files

Applying a Configuration File to Selected OLTS Files


Applying a Configuration File to Selected OLTS Files

You can select OLTS files and apply preset configuration data that you have in a configuration file. You can use a configuration file you have on your unit, or import it from another location.

Note: *This feature is available for MAX-900 files only.*

To import a set configuration and apply it to your files:

1. From the main window, select the **Tools > OLTS**, then **Apply Configuration**.
2. Select which configuration you want to use in the list of available choices. If you want to import a configuration file from another location, use the **Import** button.



3. Click **OK** to confirm your choice.

Using Custom Identifiers

You can add up to five custom identifiers for your OLTS files. The custom identifiers are displayed in the **Identification** tab, in the **Identifiers** table.


You can find more information on how to manage custom identifiers in *Matching Files Based on Information* on page 51.

To use a custom identifier:

1. Select the measurement for which you want to change the identifier.
2. From the Identifiers table of the Identification tab, use the drop-down list to select the identifier type.

OR

Type the new type directly on-screen.



Changing the OLTS Fiber Type


When working with OLTS files, you can select a specific fiber type. Different fiber types are available depending on the type of mode you are working with (singlemode or multimode).

To change the fiber type:

1. Open the file or files you want to modify.

Note: You can only change the fiber type of multiple files if they are of the same mode.

2. In the **Summary** tab, under **Link Definition**, use the corresponding drop-down list to select the desired fiber type.



The screenshot shows the 'Results' window in FastReporter 2. The 'Summary' tab is active. The window is divided into four main sections:


- Results:** A table with four rows: Link length (0.0065; 0.0019; 0.006), Acquisition status (Completed), Analysis version (OLTS 1.0 (1.0.1535)1.0), Average Loss (850 nm) (0.03; 0.04; 0.05; 0.6), and Average Loss (1300 nm) (0.60; 0.64; 0.54; 0.7).
- Test Parameters:** A table with two rows: Wavelength(s) (850 nm; 1300 nm) and Configuration name (Example for Custom T).
- Test Settings:** A table with two rows: Test method (FastTest) and Bidirectional loss (Average).
- Link Definition:** A table with three rows: Fiber type (OM1 multimode 62.5 µm), Number of connections (2), and Number of splices (0). This section is circled in red.

Changing the Number of Connections in the Link Definition

You can modify the number of connections in the link to see the impact of adding or removing connections on the dynamic loss budget thresholds. The threshold status and link view will be modified accordingly.

To change the number of connections:

1. Open the file or files you want to modify.
2. In the **Summary** tab, under **Link Definition**, click into the corresponding box to enter the desired value.




Note: When you change the link definition parameters, the pass/fail thresholds will be recalculated.

Changing the Number of Splices in the Link Definition

You can modify the number of splices in the link to see the impact of adding or removing splices on the dynamic loss budget thresholds. The threshold status and link view will be modified accordingly.

To change the number of splices:

1. Open the file or files you want to modify.
2. In the **Summary** tab, under **Link Definition**, double-click into the corresponding box to enter the desired value.



The screenshot shows a software window titled "Results" with a tabbed interface. The "Summary" tab is active, displaying a table with four main sections: Results, Test Parameters, Test Settings, and Link Definition. The "Link Definition" section contains a table with two rows: "Fiber type" (OM1 multimode 62.5 μm) and "Number of connections" (2). Below these, there is a field for "Number of splices" with a value of 0, which is highlighted with a red circle. The "Results" section shows various parameters like Link length, Acquisition status, and Average Loss. The "Test Parameters" section shows Wavelength(s) and Configuration name. The "Test Settings" section shows Test method and Bidirectional loss.

Results		Test Parameters		Test Settings		Link Definition	
Link length	-0,0065; 0,0019; 0,006	Wavelength(s)	850 nm; 1300 nm	Test method	FasTest	Fiber type	OM1 multimode 62.5 μm
Acquisition status	Completed	Configuration name	Example for Custom T	Bidirectional loss	Average	Number of connections	2
Analysis version	OLTS 1.0 (1.0.15351.0)					Number of splices	0
Average Loss (850 nm)	-0,03; -0,04; -0,05; 0,0						
Average Loss (1300 nm)	-0,60; 0,64; -0,54; 0,7						

Changing the Loss Calculation Method for Bidirectional Files


If you select at least one direction of a bidirectional file, the application will show you the calculation method used to calculate loss:

- Average
- Worst value
- Average; Worst (when at least one value in the selected files is of each type)

You can change this value for the selected files.

To change the loss calculation method:

1. Open the file or files you want to modify.
2. In the **Summary** tab, under **Test Settings**, click into the **Bidirectional Loss** box to select the desired value.



The changes will be automatically reflected in the **FasTesT** tab and the cable view.

Setting FasTesT Pass/Fail Thresholds

Depending on the type of threshold you have selected for your files, you can adjust some of the values on the current measurements to better fit your needs.


Note: *You can use one or several of the types at a same time.*

Note: *If you set a maximum ORL threshold value, it will apply to all wavelengths.*


- Fixed link thresholds: this setting will use the link pass/fail threshold value, the maximum link length and link loss value as the thresholds.
- Dynamic loss budget: this setting will use the link pass/fail threshold value, and the fiber attenuation, as well as the splice loss and connector loss values as the thresholds. The first and last connectors will also be used in the calculation.
- Certification standards: this setting allows you to determine which certification standards will be taken into account for the cabling or the application.

To apply specific certification standards:

1. Select the file or files for which you want to change the threshold type.
2. Select the **Thresholds** tab, then click **Select Standards**.




3. Navigate in the application and cabling standard lists to select the items you need. Use the + button to show the detailed available choices.




Working with OLTS Files

Setting FasTesT Pass/Fail Thresholds

- If you want to see the threshold details for a specific standard, select it, then use the **View Threshold Details** button at the bottom of the window.




The maximum and minimum link loss, as well as the maximum attenuation values will depend on the wavelength you select on the left. The fiber type selected will also display different values. Click **OK** when you are done to return to the list of standards.




- Once you are done, click **OK** to confirm the addition of the standards. The tab is updated accordingly.

To select and modify the custom thresholds:

1. Select the file or files for which you want to change the threshold type.
2. Select the **Thresholds** tab, then the custom thresholds option.




3. Select whether you want to set fixed link loss thresholds, or a dynamic loss budget, then modify the values as needed.



Note: If the unit used to take the measurements was not a Fiber Certifier (iCERT model), you cannot select the dynamic loss budget option or any of the certification standards and the maximum dynamic loss value is not displayed in the tab.

Viewing FasTesT Results

When you display FasTesT result files, you can see the details in the **FasTesT Table**. Click on the loss value of any result (in the table, link view or **Measurement** tab) to see detailed information about the margin, test configuration used, wavelength, limit and result.



The screenshot shows a software interface with a table titled "Results" and a sub-tab "FasTesT Table". The table has columns for Identifiers, Wavelength (nm), Loss Average (dB), Loss Margin (dB), Length (km), Loss A->B (dB), Ref. A->B (dBm), Loss B->A (dB), Ref. B->A (dBm), and TC Verification (dB). A tooltip is displayed over the "Loss Average" cell for the row "Cable: Fiber6" at 1310 nm, showing "Average Loss 1310 nm: 0,30 dB" and "Custom Pass/Fail Thresholds" with a "Margin" of 5,70 dB and a "Limit" of 6,00 dB.

Identifiers	Wavelength (nm)	Loss Average (dB)	Loss Margin (dB)	Length (km)	Loss A->B (dB)	Ref. A->B (dBm)	Loss B->A (dB)	Ref. B->A (dBm)	TC Verification (dB)
Cable: Fiber1	1310	0,30	---	0,1000	0,30	-7,23	0,30	-5,33	---
Cable: Fiber1	1550	0,30	---	0,1000	0,30	-6,26	0,30	-4,36	---
Cable: Fiber6	1310	0,30	---	0,1000	0,30	-7,23	0,30	-5,33	---
Cable: Fiber6	1550	0,30	---	0,1000	0,30	-6,26	0,30	-4,36	---
Cable: Fiber5	1310	0,30	---	0,1000	0,30	-7,23	0,30	-5,33	---
Cable: Fiber5	1550	0,30	---	0,1000	0,30	-6,26	0,30	-4,36	---
Cable: Fiber6	1310	0,30	---	0,1000	0,30	-7,23	0,30	-5,33	---
Cable: Fiber4	1550	0,30	5,70	0,1000	0,30	-6,26	0,30	-4,36	---
Cable: Fiber3	1310	0,30	0,55	0,1000	0,30	-7,23	0,30	-5,33	---
Cable: Fiber3	1550	0,30	0,55	0,1000	0,30	-6,26	0,30	-4,36	---
Cable: Fiber2	1310	0,30	0,55	0,1000	0,30	-7,23	0,30	-5,33	---
Cable: Fiber2	1550	0,30	0,55	0,1000	0,30	-6,26	0,30	-4,36	---

When working with bidirectional files, the loss will be indicated as the average or worst value, depending on what setting is selected.


Note: The Summary, Threshold and FasTesT tables are displayed if the measurements are of the same type (duplex, FasTesT, etc.).

Note: For a quick general overview of the pass/fail statuses of your measurements according to the certification standards, you can select the **Certification** view in the **Measurement** tab.

Viewing Link View Results

You can view the results for MAX-900 series OLTS files in the graph view.

Click on any result to see detailed information about the margin, test configuration used, wavelength, limit and result.



Working with OLTS Files

Viewing Link View Results

In the case of bidirectional measurements, if you select both measurements from the same file, the link view displays both connections between the main and remote units

Cable1_Fiber13 (OM3) Pass

Loss: 850 nm 2,38 dB
 1300 nm 1,31 dB

Main Remote

Cable11_Fiber14 (OM3) Fail

Loss: 850 nm 11,47 dB
 1300 nm 10,53 dB

Length: 0,5261 km


Identification	Summary	Thresholds	FastTest Table							
Identifiers	Test Units	Wavelength (nm)	Loss (dB)	Loss Margin (dB)	Length (km)	Reference Method	Test Cord	Ref. (dBm)	TC Verification (dB)	
Cable1; Fiber13	M->R	850	2,38	0,06	0,5261	One test cord	Reference grade	-24,83	0,11	
Cable1; Fiber13	M->R	1300	1,31	0,08	0,5261	One test cord	Reference grade	-25,88	0,03	
Cable11; Fiber14	R->M	850	11,47	-9,03	0,5261	One test cord	Reference grade	-23,98	0,09	
Cable11; Fiber14	R->M	1300	10,53	-9,14	0,5261	One test cord	Reference grade	-28,16	0,08	

Viewing Pass/Fail Status Information


When working with MAX-900 series files, you can see the detailed pass/fail information for all standards used during the FasTesT.

To view the global pass/fail information:

1. From the **Files** or **Measurements** tabs, select the file or files for which you want to see the status.
2. Right-click the selected files, then select **Global Pass/Fail Status**.



3. The information appears in a tooltip window. Click anywhere to exit.




Understanding Diagnostics

OLTS result files made with the MAX-900 series provide you with diagnostics to help you with detected problems or ambiguous measurement situations. You can see the diagnostics in the **Measurements** tab, the **FasTesT Table** tab, and in the link view.


To display the diagnostics in the Measurement tab:

1. Right-click in the column headers to make the Diagnostics column appear.
2. Click on the icon of the diagnostic that you want to view.



To view diagnostics in the FasTest Table tab and Link View:

Click on the corresponding icon.



7 Working with CD Files

Accepted File Formats

FastReporter 2 lets you work with measurement files saved in different formats, but does not necessarily permit all operations on them.

File format	File extension	Display	Modification
EXFO CD (FTB-5800 modules)	.exfocd	X	X
CDPMD (FTB-5700 modules)	.cdpmd	X	X

Note: *The .cdpmd file may also contain fiber length and PMD information.*

Note: *When you modify information or data that is common to both CD and PMD formats in .cdpmd files, the contents is automatically updated in both measurement types.*


Changing CD Settings

The pass/fail thresholds that you set for CD projects are displayed on the **Summary** tab in the **Results** window. Should you need to change the wavelength measurement range for analysis purposes, this is also done in the **Summary** tab.

The dispersion thresholds are applied on the maximum dispersion for the measurement file and on each dispersion value of the CD table.

To change CD settings:

1. On the **Settings** menu, select **CD**.
2. Select the type of threshold to use for your analysis, either from the measurement file itself or from a list of predetermined thresholds.
 - The threshold from the measurement file is the one that was used during the actual CD test. When you select this threshold, you cannot modify the values in the threshold table.
 - The threshold from the application is a threshold set by FastReporter 2, which you can select and modify.



3. Modify the displayed values as needed. The **Apply** option must be enabled for the values to be active and modifiable.

- To apply the changes without closing the dialog box, click **Apply**. To apply the changes and close the dialog box, click **OK**.

The thresholds are displayed in the main window, in the **Summary** tab, under **Results**. If some values failed the test, they will appear clearly in red.

Note: *The first figure illustrates the display for a .cdpmd file, and the second for an .exfocd file.*

Results		Test Parameters		Test Settings	
Dispersion @ 1550 nm	832.29 ps/nm	Acq. from	1475 nm	Results from	1200 nm
Slope @ 1550 nm	2.9002 ps/(nm ²)	Acq. to	1598 nm	Results to	1700 nm
Coefficient @ 1550 nm	16.49 ps/(nm*km)			Fiber type	G.652 NDSF
Maximum dispersion	1223.10 ps/nm			RGD data fit	3-Term Sellmeier
Measured Fiber Length	50.458 km				

Lambda Zero	Slope
*1318.68 nm	*4.5111 ps/(nm ²)

Results		Test Parameters		Test Settings	
Dispersion @ 1550 nm	201.366 ps/nm	Acq. from	1530.0 nm	Results from	1530 nm
Slope @ 1550 nm	0.623407 ps/(nm ²)	Acq. to	1624.9 nm	Results to	1624 nm
Coefficient @ 1550 nm	17.419 ps/(nm*km)	Step	2 nm	Fiber type	G.652 NDSF
Maximum dispersion	245.077 ps/nm	Averaging time	1.0 s	RGD data fit	3-Term Sellmeier
Measured Fiber Length	11.560 km			Fiber length	11.560 km

Lambda Zero	Slope
*1294.893 nm	*1.013148 ps/(nm ²)

Working with CD Files

Changing CD Settings

You can view the details for your measurement file in the **CD Table** tab. Depending on the type of CD measurement file you are viewing (.exfocd or .cdpmd), the available information differs. Any failed measurement will also show in this tab.

Note: RGD measurements are only available in .exfocd files.

Note: If you do not see the **CD Table** tab, make sure you have selected only one measurement in the list.

.cdpmd file

Results						
Identification	Summary	Thresholds	CD Table			
Wavelength (nm)	Dispersion (ps/nm)	Dispersion Coef. (ps/(nm ² *km))	RGD (ps)	Fitted RGD (ps)	RGD Deviation (ps)	
1475.00	600.79	11.91	685116.39	685188.31	71.92	
1492.51	657.49	13.03	696257.02	696204.65	52.37	
1510.01	712.49	14.12	708198.61	708197.71	0.90	
1527.52	765.90	15.18	721139.79	721141.19	1.40	
1545.03	817.80	16.21	734982.68	735005.84	23.16	
1562.53	868.28	17.21	749785.08	749766.78	18.30	
1580.04	917.41	18.18	765410.43	765398.96	11.47	
1597.55	965.27	19.13	782037.16	781882.67	154.49	

.exfocd file

Results						
Identification	Summary	Thresholds	CD Table			
Wavelength (nm)	Dispersion (ps/nm)	Dispersion Coef. (ps/(nm ² *km))	RGD (ps)	Fitted RGD (ps)	RGD Deviation (ps)	Used
1530.00	188.702	16.324	0.00	1.330	1.330	Yes
1532.00	189.987	16.435	376.85	380.020	3.170	Yes
1534.00	191.267	16.546	759.82	761.274	1.454	Yes
1536.00	192.543	16.656	1149.10	1145.085	4.015	Yes
1538.00	193.815	16.766	1533.82	1531.444	2.376	Yes
1540.00	195.083	16.876	1920.74	1920.343	0.397	Yes
1542.00	196.348	16.985	2315.30	2311.775	3.525	Yes
1544.00	197.608	17.094	2706.84	2705.731	1.109	Yes
1546.00	198.864	17.203	3097.70	3102.205	4.505	Yes

It is possible for you to change the table wavelength, that is the way to calculate the table according to the Results from and Results to values. You can select from the table wavelength values below.

- 1 nm (Results range with a step of 1 nm in-between values)
- 50 GHz
- 100 GHz
- 200 GHz
- From the acquisition

To change the wavelength table:

From the main window, select the **View** menu, then **CD > Table Wavelength** and select the value you want to use.

If a file is open already, the values are automatically updated.

Changing CD Fiber Type

FastReporter 2 allows you to analyze various fiber types for chromatic dispersion.

To change the CD fiber type:

1. Open a CD measurement file.
2. Select the measurement or measurements for which you want to change the fiber type.
3. In the main window, select the **Summary** tab.

The screenshot shows the 'Results' window in FastReporter 2, with the 'Summary' tab selected. The window is titled 'CD' and contains several data tables.

Results	
Dispersion @ 1550 nm	201.366 ps/nm
Slope @ 1550 nm	0.623407 ps/(nm ²)
Coefficient @ 1550 nm	17.419 ps/(nm*km)
Maximum dispersion	245.077 ps/nm

Test Parameters	
Acq. from	1530.0 nm
Acq. to	1624.9 nm
Step	2 nm
Averaging time	1.0 s


Test Settings	
Results from	1530 nm
Results to	1624 nm
Fiber type	G.652 NDSF
RGD data fit	3-Term Sellmeier
Fiber length	11.560 km

Lambda Zero	Slope
*1294.893 nm	*1.013148 ps/(nm ²)

4. Select the fiber type according to your needs in the **Fiber Type** box:

- G.652 NDSF (3-term Sellmeier fit)
- G.653 DSF (quadratic fit)
- G.655 NZDSF (quadratic fit)
- G.656 Wideband NZDSF (quadratic fit)
- Compensating (quadratic fit)
- Flattened (cubic fit)
- Amplified Links (cubic fit)
- Custom (default cubic fit)

Note: When you select a different fiber type, the fit is automatically changed to match the default fit value for this new fiber type. However, you can change this new fit type as desired in the corresponding list.




Changing Analysis Range


The range used for taking the measurement and the range used for analyzing the results can be different if you want to concentrate your analysis on a specific area. You can change it for both types of CD files.

To change the analysis range (results from and results to values):

1. Open a CD measurement file.
2. Select the measurement or measurements for which you want to change the analysis range.
3. In the main window, select the **Summary** tab.



4. In the **Results from** and **Results to** boxes, change the wavelength range values as needed for your analysis.




Changing the Fiber Length


If you are working with an .exfocd format file, you can change the fiber length to obtain more precision in your analysis.

To change the fiber length:

1. Open a CD measurement file.
2. Select the measurement or measurements for which you want to change the fiber length.
3. In the main window, select the **Summary** tab.



4. In the **Fiber Length** box, enter a new value for the analysis.



Note: If your file is in .cdpmd format, the fiber length was measured automatically during the measurement and cannot be edited.

Switching Between Curve Types

If you have a specified fiber length in your CD file, you can view either the chromatic dispersion or the chromatic dispersion coefficient curves.

To switch between the coefficient and dispersion curves:

From the main window, select **View > CD > Coefficient**.

The table values in the **Summary** tab are updated automatically.

8 Working with PMD Files

Accepted File Formats

FastReporter 2 lets you work with measurement files saved in different formats, but does not necessarily permit all operations on them.

File format	File extension	Display	Modification
PMD (FTB-5500 modules)	.pmd	X	X
PMDB (FTB-5500 modules)	.pmdb	X	X
CDPMD (FTB-5700 modules)	.cdpmd	X	X

Note: *The 64-bit version of FastReporter 2 does not support the .pmd and .pmdb file formats. Install the 32-bit version to view and process those files.*

Note: *The .cdpmd file may also contain fiber length and CD information.*

Note: *When you modify information or data that is common to both CD and PMD formats in .cdpmd files, the contents is automatically updated in both measurement types.*


Changing PMD Settings

You can change the thresholds you want to use for the analysis:


- The threshold from the measurement file is the one that was used during the actual PMD test. When you select this threshold, you cannot modify the values in the threshold table.
- The threshold from the application is a threshold set by FastReporter 2, which you can select and modify.

To change PMD settings:

1. On the **Settings** menu, select **PMD**.
2. Select the type of threshold to use for your analysis.



3. Modify the displayed values as needed if you selected to use a threshold from the application. The **Apply** option must be enabled for the values to be active and modifiable.




4. To apply the changes without closing the dialog box, click **Apply**. To apply the changes and close the dialog box, click **OK**.

Working with PMD Files

Changing PMD Settings

The thresholds are displayed in the main window, in the **Summary** tab, under **Results**. If some values failed the test, they will appear clearly in red.




Note: The *.cdpmd* files do not display a graph for the PMD measurement.

Changing Fiber Length

If you are working with .pmd or .pmdb files, you can change the fiber length to obtain more precision in your analysis.

To change the fiber length:

1. Open a PMD measurement file.
2. Select the measurement or measurements for which you want to change the fiber length.
3. In the main window, select the **Summary** tab.



4. Locate the fiber length value under **Test Settings** and modify it as needed.


Note: If your file is in .cdpmd format, the fiber length was measured automatically during the measurement and cannot be edited.

Working with PMD Statistic Measurements


When selecting more than one PMD measurements on a same file, the **Statistics** tab appears. This tab can be used to see average values for the measurements.

To exclude a measurement from the statistic values:

1. Open a PMD measurement file.
2. Select the measurement or measurements that you want to exclude from the statistics values.
3. In the main window, select the **Summary** tab.




4. Set the measurements as not used for the statistics under **Test Settings**.



To view PMD measurement statistics:

1. Open a .pmdb measurement file.
2. Select more than one measurement to make the tab appear.
3. In the main window, select the **Statistics** tab.



9 Working with OPM/PPM Measurements

Accepted File Formats

FastReporter 2 lets you work with measurement files saved in the following formats, but does not necessarily permit all operations on them.


File format	File extension	Display	Modification
PPM-350 C	.ppm	X	X
iOLM	.iolm	X	X
OPM	.oltsx	X	X
ConnectorMax 2	.cmax2	X	X
MAX-900 Series	.olts	X	X

Selecting the Absolute Power Unit

You can set FastReporter 2 to use either dBm, watts, or use the power unit used in the measurement you are viewing.

To select the power unit:

1. From the main window, select the **Settings** menu, then **OPM/PPM**.
2. In the **General** tab, select which unit to use.



3. Click **OK** to confirm your choice and close the window.


Changing OPM/PPM Settings

The pass/fail thresholds that you set for PON Power Meter (PPM) or Optical Power Meter (OPM) projects and the predefined thresholds are applied on the corresponding table tabs in the **Results** window. If you need to change the threshold for analysis purposes, it can be done in the **Thresholds** tab.

To select which thresholds to use for the measurements:

1. From the main window, select the **Settings** menu, then **OPM/PPM**.
2. In the **Pass/Fail Thresholds** tab, select whether the thresholds to use are those from the measurement file, or those from the application.

Note: *In the case of FTTx measurements, you can only use the thresholds from the measurement files.*





3. Click **OK** to confirm your choice and close the window.

Working with OPM/PPM Measurements

Changing OPM/PPM Settings

To change OPM/PPM settings:

1. Open the file which contains OPM/PPM measurements.
2. On the **Results** window, click the **Thresholds** tab.



3. Select a wavelength or wavelengths to modify.
4. Modify the thresholds associated with the wavelengths needed by clicking in the desired threshold value and modifying it in the table. If you have selected more than one wavelength, all of them will be modified at the same time.

Viewing Power Meter Results

Power meter results are displayed in the OPM and PPM tables.

To view the Power meter results for OPM measurements:

1. Select OPM measurements.
2. From the **Results** window, select **OPM Table**.

Identifiers	Wavelength (nm)	Power
2; 1	850	-1.27 dBm
2; 1	850	-0.67 dBm
2; 1	1625	-12.78 dBm
2; 1	1625	-12.54 dBm
2; 1	1625	-12.54 dBm
2; 1	1490	-11.71 dBm
2; 1	1490	-11.71 dBm
2; 1	1490	-15.05 dBm
2; 1	1310	-12.57 dBm
2; 1	1310	-12.57 dBm
2; 1	1310	-12.57 dBm
2; 1	1650	-6.50 dBm
2; 1	1650	-6.50 dBm

To view the Power meter results for PPM measurements:

1. Select the file which contains PPM measurements.
2. From the **Results** window, select **PPM Table**.

Identifiers	1310 nm (Upstream)	1490 nm (Downstream)	1550 nm (Video)
OLT 01; 001	-4.300 dBm	Low	Low
OLT 01; 001	-4.300 dBm	Low	Low
OLT 01; 001	-4.300 dBm	Low	Low
OLT 01; 001	-4.300 dBm	Low	Low
OLT 01; 001	-4.300 dBm	Low	Low
OLT 01; 001	-4.300 dBm	Low	Low


Changing the Correction Factor (FR2-FC Mode)

Correction factors are used to adjust the OPM and PPM measurements. The correction factor is specified by wavelength only, and the fiber core size is not taken into account. FastReporter 2 allows you to change the correction factor for PPM file types. These corrections should be made before the measurement is taken and should be stored with each measurement. A correction factor of 1.0 has no effect on the measurement.

Note: *The correction factor is not available for measurements from iOLM files.*

To change the correction factor:

1. Open an OPM or a PPM measurement file.
2. Select the measurements for which you want to change the correction factor.
3. In the **Results** window, select the **Summary** tab.



4. Modify the correction factors associated with the wavelengths as needed. Click the desired correction factor value under **Test Settings** column and modify it.

10 Working with Fiber Inspection Probe (FIP) files

Accepted File Formats

FastReporter 2 lets you work with measurement files saved in different formats, but does not necessarily permit all operations on them.

File format	File extension	Display	Modification
FIP (ConnectorMax)	.cmax	X	X ^a
FIP (ConnectorMax2)	.cmax2	X	X

- a. Modified .cmax files can only be saved again in .cmax2 format.

These file formats include:

- Inspection of single-fiber connectors
- Analysis of single-fiber connectors
- Inspection of multiple-fiber connectors

Modifying Unit Model and Serial Number

The application allows you to change the unit model as well as the unit serial number for your FIP measurements on .cmax format files. You can change the unit model and unit serial number of multiple measurements at a time. The entered unit model and unit serial number are also displayed in the FIP report.


Note: In .cmax2 format files, the unit model and serial number cannot be modified.

To change the unit model:

1. Open the FIP measurements to change.
2. On the **Results** window, in the **Identification** tab, double-click on the **Unit model** field and enter the required unit model number.

Note: You cannot enter special characters (?,/, <, >, ", ;, *, |, \).

Note: You can enter a maximum of twenty five characters.



The screenshot shows a software window titled "Results" with a tabbed interface. The "Identification" tab is active. Below the tabs, there is a section labeled "FIP" containing two tables. The first table, "General Identification", lists fields like Filename, Test date, Test time, Job ID, Customer, Company, Operator A, and Operator B. The second table, "Identifiers", lists Cable ID, Fiber ID, Location A, Location B, Connector ID, and Frame. To the right of these tables is a "Location A" section with two input fields: "Unit model" (containing "FIP-400") and "Unit serial number" (containing "12-9563-01"). A red circle highlights the "Unit model" field.

General Identification		Identifiers	Values	Location A	
Filename	Single_Fiber_Single_mode_Con	Cable ID		Unit model	FIP-400
Test date	9/24/2010	Fiber ID	Fiber001	Unit serial number	12-9563-01
Test time	3:01 PM (GMT-05:00)	Location A			
Job ID		Location B			
Customer		Connector ID			
Company		Frame			
Operator A					
Operator B					
		Additional Information			
		Comments			

To change the unit serial number:

1. Open the FIP measurements to change.
2. On the **Results** window, in the **Identification** tab, double-click on the **Unit serial number** field and enter the required unit serial number.

Note: You cannot enter special characters (?, /, <, >, ", ;, *, |, \).

Note: You can enter a maximum of twenty five characters.

The screenshot shows the 'Results' window with the 'Identification' tab selected. The window contains a table with the following data:

General Identification		Identifiers	Values	Location A	
Filename	Single_fiber_Single_mode_Con	Cable ID		Unit model	FIP-400
Test date	9/24/2010	Fiber ID	Fiber001	Unit serial number	12-5563-01
Test time	3:01 PM (GMT-05:00)	Location A			
Job ID		Location B			
Customer		Connector ID			
Company		Frame			
Operator A					
Operator B					
		Additional Information			
		Comments			

Showing or Hiding Threshold and Result Information

You can hide threshold and result information for zones that are not useful for your analysis.

Note: *You cannot modify the information. This is for viewing purposes only.*

To select the zones to display:

On the main window, in the **Thresholds** or **FIP Result** tab of the **Results** window, click the right mouse button, then select or clear any of the zones:

- Zone A: Core
- Zone B: Cladding
- Zone C: Adhesive
- Zone D: Contact


Note: *Changes done in either tab is reflected in the other and are immediate.*

Applying a Configuration File to Selected FIP Files

You can select FIP files, and apply preset configuration data that you have in a configuration file. You can use a configuration file you have on your unit, or import it from another location.

To import a set configuration and apply it to your FIP files:

1. From the main window, select the **Tools > FIP**, then **Apply Configuration**.
2. Select which configuration you want to use in the list of available choices. If you want to import a configuration file from another location, use the **Import** button.



3. Click **OK** to confirm your choice.

FIP Graphic Display Options

The FastReporter 2 application displays the FIP overlay in the graph window along with the FIP Image. An overlay highlights the inconsistencies in your FIP with different colors described below.

Color Legend	Analysis Anomaly Highlighting
Aqua	PASS Scratch
Green	PASS Defect
Red	FAIL Anomaly

- **FAIL Anomaly:** the presence of this anomaly implies automatically a FAIL result.
- **PASS Scratch:** the presence of this anomaly is not sufficient to confirm a FAIL, the anomaly count in this case is relevant.


If you select more than one FIP files and enable the appropriate viewing option, you can have the corresponding graphic displays appear all at once on-screen. This feature is available for both single fibers and multiple fibers.

You can also select to see the images according to the cable connector view. The fibers included in a same cable are grouped, and the cable is identified in the graph view.


You can copy the FIP images and/or overlays and paste them to the clipboard. You can also change the display setting of the graph for FIP measurements so that you can see both the overlay and the graph side by side.

To change FIP graphic display options:

1. On the **View** menu, select **FIP** to display the FIP graphic display options.
2. Select **Multi-Fiber View** to display an image for all of your selected files or **Cable Connector View** to display the corresponding mode. The order of the images is the same as the order of the files in the **Matched Files** tab.



If you want to select a specific item, you can use the drop-down the list in the measurement toolbar.



Using Custom Identifiers

You can add up to five custom identifiers for your FIP files. The custom identifiers are displayed in the **Identification** tab, in the **Identifiers** table.


You can find more information on how to manage custom identifiers in *Matching Files Based on Information* on page 51.

To use a custom identifier:

1. Select the measurement for which you want to change the identifier.
2. From the Identifiers table of the Identification tab, use the drop-down list to select the identifier type.

OR

Type the new type directly on-screen.



The Frame identifier type cannot be modified. Enter the information that describes the groups of connectors included in the frames, as needed.


Saving Legacy FIP Files in .cmax2 File Format

You can import and view legacy image files (.jpg, .jpeg and .bmp formats) using FastReporter 2. Once the image file is open, it is displayed in the graphic window, and is converted and saved in .cmax2 format.

Note: When opening .cmax legacy files (ConnectorMax format), they will also be automatically converted to the .cmax 2 format and can only be saved as such if you modify them.

To import an image file:

1. From the **Files** menu, click on **Import > Image File**.
2. Select the required image and click **Open**.




Note: Under the **Identification** tab, the application displays the file name, test date, and the test time of the image. The rest of the fields remains empty but is editable.

Viewing Power Meter and OLTS Results

Your .cmax2 file could contain both FIP and power meter data, or FIP and loss data in a single file. Power meter and OLTS results are displayed in their respective tables. For more details, see *Viewing Power Meter Results* on page 233 and *Working with OLTS Files* on page 191.

Viewing Geolocation Information

Your fiber inspection probe files can include GPS coordinate data that pinpoints where the test was performed. This information is displayed in the **Identification** tab when you open your file.



The information is the latitude, a separator character, and the longitude. If you have more than one locations, they will be separated by a semi-colon.

Note: *If you are using FastReporter 2 on a computer and have selected a single file, the geolocation information becomes a hyperlink that will take you to the corresponding location on Google Maps, using the default Web browser.*

11 Working with iOLM files

Accepted File Formats

FastReporter 2 lets you work with measurement files saved in the following formats, but does not necessarily permit all operations on them.

File format	File extension	Display	Modification	Reanalysis
iOLM	.iolm	X	X	X
	.iolmcfg	X	X	–
	.iolmbdr	X	X	X

Understanding the Link View

The iOLM Link View is an intuitive representation, which combines several measurement results and values into a single view.

The link view is divided into two different regions.

- Link overview
- Link composition



In the link overview, you can quickly see the status for each element with the corresponding color code:

- Red: The element is fail.
- Green: The element is pass.
- Blue: The element is not tested for Pass/Fail.

Working with iOLM files

Understanding the Link View


The pass/fail status also depends on the threshold values specified. The link overview representing all the elements discovered on the link is described below.



- Length of the measured link: Length of the measured link excluding the launch and receive fibers.
- Selected element: Rectangle representing the selected element.
- Visible region: The colored background represent the visible region in the link composition view.
- Beginning of the link: Beginning of the link under test.
- End of the link: End of the link under test.

Elements before A and after B are referred to as out-of-span elements. Elements out of the span are not tested for pass/fail status, but can have diagnostics on them. If the launch fiber is not defined, the element marked as "A" will not be tested for pass/fail and if the receive fiber is not defined, the element marked as "B" will not be tested for pass/fail.

The link composition is described below.



- Element position: The distance of the element from the beginning of the link under test.
- Navigation arrow: The navigation arrow is only displayed when more items are available on the particular side. It indicates that the you have to scroll to view those items. This arrow can also appear on the left side.
- Selected element: The gray background represents the currently selected element.
- Letter A: The beginning of the link under test.
- Letter B: The end of the link under test.

Note: An arrow (ⓘ) icon is displayed on the element if the start and the end of the link is represented by the same element.

- Element Pass/Fail: The status of the element whether it is pass (✔), fail (✖), or unknown. If you are viewing multiple measurements in Cable view (see *Managing Multiple Measurements* on page 249 for details), the status depends on the statuses of the corresponding matched elements. If at least one of the elements has a fail status, then the cable combined element status is also fail.

Working with iOLM files

Understanding the Link View

- **Pass/Fail not tested:** A gray background indicates that the element is unknown. If there is no icon at the right side corner, it indicates that thresholds are not applied on the element and the element is not tested for Pass/Fail. If you are viewing multiple measurements in Cable view (see *Managing Multiple Measurements* on page 249 for details), the status depends on the statuses of the corresponding matched elements. If at least one of the elements has a status of fail, then the combined element status is also fail. If the statuses are a combination of pass and unknown, then the cable combined element status is set to unknown.
- **Diagnostics  icon:** This icon specifies that some diagnostic is present on the element. See *Understanding Diagnostics* on page 309 for more details.
- **Distance Unit:** The distance unit you have selected.
- **Splitter Ratio:** The splitter ratio is displayed on the element, if the element type is splitter.

Note: *The number of elements displayed in the composition view varies according to the available space, number of elements, and section size.*


Note: *When the link length is large, not all of the elements are visible; you may need to scroll on the link using the navigation arrow.*

Note: *The distance between the elements is not 100 % proportional. To have a proportional representation of the element, look at the link overview.*


Managing Multiple Measurements

When you are working with more than one measurements, you can view the links in two different manners:

- The *Cable* view shows all of the measurements grouped into one link, with the link overview. The total number of selected fibers is indicated on the left, and each element has its own identification number. When matched elements are of the same type, you can see how many there are on the upper left corner of the element icon. If the number is blue, all fibers contain this element. If the number is yellow, at least one fiber does not have this element. If elements at the same position are not of the same type, a question mark icon replaces the element type.



- The *Fiber* view shows the grouped links at the top of the window, then details each fiber with its corresponding elements. You can perform changes to individual fibers in this view.



Working with iOLM files

Managing Multiple Measurements

Note: *When viewing grouped fibers, the End of fiber element (B) is set according to the reference measurement if there is one; if there is no reference measurement it is set according to the shortest fiber. The elements located between the grouped A and B positions (including both A and B) are numbered.*

You can perform the same actions (adding, modifying and deleting elements, setting span start and end) on single fiber and multiple fibers; the main difference is that if you perform the actions in the cable view or on the cable at the top of the Fiber view, all of the included fibers are modified accordingly.

To select the viewing method for multiple fibers:

1. Select the fibers that you want to view together in the **Files** or **Measurement** tabs.
2. Right-click in the Link view, then select either the Cable or Fiber view. You can also select the view in the **View > iOLM** menu.


Selecting Element Alignment Type

Elements can be matched either using the position (the distance on the fiber), or the element number. The span start is considered as element number 1, or the start position.

Note: *Some operations, such as delete, add, and add to other measurements are not available when the elements are matched by number.*

To select the element alignment type:

1. On the **Settings** menu, click **iOLM** and then the **General** tab.
2. Select how the elements will be matched.



3. Click **OK**.


Modifying Tolerance and Bidirectional Settings

You can allow the creation of iOLM bidirectional files for your analyses.

You can also set the extended element matching tolerance. The main purpose to edit the tolerance is to match two elements that are not matching with the intrinsic element tolerance value fixed by signal processing.

To enable the iOLM bidirectional file creation:


1. On the **Settings** menu, click **iOLM** and then the **General** tab.
2. Enable the **Display iOLM bidirectional file creation dialog** option.



3. Click **OK**.

To change the extended element matching tolerance:

1. On the **Settings** menu, click **iOLM**, and then the **Tolerance** tab.
2. Enter the tolerance value to match the element.



3. To save your settings, click **OK**.

Note: If you want to apply the default settings, click **Default Settings**.

Modifying iOLM Thresholds

The types of thresholds that you can view and modify are link and element.

Note: Since you cannot have splitters in multimode measurements and bidirectional measurements, the corresponding threshold table will not appear in the tab if you are working with this type of file. This also applies if you have selected both monomode and multimode files.


Changing Pass/Fail Thresholds

You can change the pass/fail threshold values for one, or many wavelengths at a time.

You can also change the threshold values for the current measurement.


To change iOLM Pass/Fail Thresholds:

1. On the **Settings** menu, select **iOLM**.
2. Click the **Pass/Fail Thresholds** tab.



3. Select how you want to set the thresholds:

- If you want to use the threshold values from the measurement file, select the corresponding option.




Working with iOLM files

Modifying iOLM Thresholds

- If you want to use the threshold values from the application, proceed as follows:


Select if you want to use thresholds associated with specific certification standards, or you can set a custom configuration.

Note: You can use both certification standards and custom configurations at the same time.



If you are using a custom configuration, select how you want to set the thresholds:


Select if you will use fixed link loss thresholds or a dynamic loss budget (in the case of iCERT files) or both. The threshold values that you can modify will change accordingly in the table. If the measurements include a dynamic loss value, it will appear in the table.




Working with iOLM files

Modifying iOLM Thresholds


In the case of iCERT files, select the fiber type used in the setting. If you have selected a specific fiber type, not all fiber types may be available.



Select one or several wavelengths to modify. If you do not see the wavelength you want to use, you can add it by clicking the **+** button, entering the wavelength value, and clicking **OK**.



Modify the thresholds associated with the wavelengths needed, by clicking in the desired threshold value and modifying it in the table. The **Apply** option must be enabled for the threshold to be active and modifiable.



If you have selected more than one wavelength, their maximum and minimum link loss, as well as maximum attenuation will be modified at the same time.

- To apply the changes without closing the dialog box, click **Apply**. To apply the changes and close the window, click **OK**.

Note: When the span ORL value is preceded by a “<” and the ORL threshold is smaller than or equal to the value, the global pass/fail status for the measurement will be unknown or fail.

Setting Pass/Fail Thresholds for the Current Measurements

Depending on the type of threshold you have selected for your files, you can adjust some of the values on the current measurements to better fit your needs.

Note: *You can use one or several of the types at a same time.*

- Fixed link thresholds: this setting will use the link pass/fail threshold value, the maximum link length and link loss value as the thresholds.
- Dynamic loss budget: this setting will use the link pass/fail threshold value, and the fiber attenuation, as well as the splice loss and connector loss values as the thresholds. The first and last connectors will also be used in the calculation.
- Certification standards: this setting allows you to determine which certification standards will be taken into account for the cabling or the application.


To modify the iOLM thresholds for the current measurement:

1. Open an iOLM file.
2. Select the measurements for which you want to view or modify the thresholds.


The current pass/fail threshold statuses are indicated in the list: green for pass and red for fail.

P/F	Identifiers	Type	Direction	Test Date/Time	Link ORL (1310 nm)	Link loss (1310 nm)
✓	Cable 01; Fiber 01	iOLM	A->B	9/17/2013 7:07:11	42.24 dB	0.82
✓	Cable 01; Fiber 02	iOLM	A->B	9/17/2013 7:07:11	42.24 dB	0.82
✓	Cable 01; Fiber 03	iOLM	A->B	9/17/2013 7:07:11	42.24 dB	0.82
✓	Cable 01; Fiber 04	iOLM	A->B	9/17/2013 7:07:11	42.24 dB	0.82
✓	Cable 01; Fiber 05	iOLM	A->B	9/17/2013 7:07:11	42.24 dB	0.82
✓	Cable 01; Fiber 06	iOLM	A->B	9/17/2013 7:07:11	42.24 dB	0.82
✗	Cable 01; Fiber 07	iOLM	A->B	9/17/2013 7:07:11	42.24 dB	0.82
✓	Cable 01; Fiber 08	iOLM	A->B	9/17/2013 7:07:11	42.24 dB	0.82

3. In the **Results** window, select the **Thresholds** tab.
4. Select the type of budget you want to use for the results.




5. Select the wavelengths for which you want to view or modify the maximum and minimum loss, and maximum attenuation loss values, then change the values as needed.



Working with iOLM files

Modifying iOLM Thresholds

6. Enable the element pass/fail thresholds option to be able to modify them and apply them, then change the values as needed.



7. If the files are iCERT, you can select one or more certifications, as explained in the procedures following this one. This will display the threshold values associated with this particular type of certification. You cannot modify the thresholds displayed for them.


If no certification are available, the certification configuration name is set to Custom, and you can modify the thresholds as needed by clicking the corresponding **Apply** box, then modifying the value in the table.

Note: *If you have selected more than one wavelength, all of them will be modified at the same time.*


8. If you want to change the splitter loss ratio values, proceed in the same manner as you have for the thresholds.
9. If you want to apply the default values for all thresholds and standards, click **Default Settings**.

To apply specific certification standards:

1. Select the file or files for which you want to apply standards.
2. Select the **Thresholds** tab, then click **Select Standards**.




3. Navigate in the application and cabling standard lists to select the items you need. Use the + button to show the detailed available choices.



Working with iOLM files

Modifying iOLM Thresholds

4. If you want to see the threshold details for a specific standard, select it, then use the **Details** button at the bottom of the window.




Click **OK** when you are done to return to the list of standards.


5. Once you are done, click **OK** to confirm the addition of the standards. The tab is updated accordingly.

To select and modify the custom thresholds:

1. Select the file or files for which you want to change the threshold type.
2. Select the **Thresholds** tab, then the custom thresholds option.



3. Select the wavelengths for which you want to modify threshold values.



4. Change the threshold values as needed.

Working with iOLM files

Using the Auto Template (FR2-FC Mode)

Note: *If the unit used to take the measurements was not a Fiber Certifier (iCERT model), you cannot select the dynamic loss budget option or any of the certification standards and the maximum dynamic loss value is not displayed in the tab.*

To show the certification standards applied to a specific measurement file:

In the **Files tab**, right-click on the measurement or measurements for which you want to view the standard, and select **Global Pass/Fail Status**.

The result will appear in a tooltip. If you have selected more than one measurements, the standards will be applied to all of them.

Using the Auto Template (FR2-FC Mode)


The auto template lets you add and remove elements on links based on their occurrence on the total group of selected links. You can set a percentage value that will indicate whether an element should be added or removed.

Once the auto template is used, you can analyze the results; if there are issues with some of the elements, you can view them in a descriptive summary. The auto template is particularly useful for obtaining uniformity when testing many traces on a same fiber.


To enable and use the auto template in your project:

- 1.** On the **Settings** menu, select **iOLM**.
- 2.** Click the **Auto Template** tab.

3. Enable the option to be able to set the preferences.




4. If you want to add elements, select the corresponding option and enter the minimum percentage value of occurrences required to add the element to the remaining links.



Working with iOLM files

Using the Auto Template (FR2-FC Mode)


5. If you want to remove elements, select the corresponding option and enter the percentage value of occurrences under which the element must fall to be remove it from the measurement.




6. To apply the changes without closing the dialog box, click **Apply**. To apply the changes and close the window, click **OK**.

To apply auto template settings to the current measurements:

1. Open the measurements you want to include in the auto template operation.
2. From the **Measurement** menu, select **iOLM**, then **Auto Template**.
3. If you want to add elements, select the corresponding option and enter the minimum value of occurrences required to add the element to the remaining links.



4. If you want to remove elements, select the corresponding option and enter the value of occurrences under which the element must fall to be remove it from the measurement.




5. Click **OK** to confirm your choice and start the operation.

Note: *The values modified in the window will not be kept for future applications of the auto template. They are for the current measurements only.*

Working with iOLM files

Using the Auto Template (FR2-FC Mode)

The elements will be added or deleted according to the Auto template settings. The results will be updated in the **Element Table**. If some issues occur during the process, a summary will indicate which element is concerned.



Identifiers	Element Position (km)	Action	Description
1	0,0407	Delete	This element cannot be deleted for "1".
1	0,0509	Delete	This element cannot be deleted for "1".
1	0,0843	Link End	Element cannot be set as the link end
1	0,0843	Link End	Element cannot be set as the link end
1	0,0843	Link End	Element cannot be set as the link end
1	0,0843	Link End	Element cannot be set as the link end
1	0,0843	Link End	Element cannot be set as the link end
1	0,0843	Link End	Element cannot be set as the link end
3	0,0843	Link End	Element cannot be set as the link end
1	0,0843	Link End	Element cannot be set as the link end

Modifying iOLM Settings (FR2-FC Mode)

In the **Summary** tab you can view and modify the IOR and backscatter value for your iOLM measurements.

To modify iOLM settings in the Summary tab:

1. Open an iOLM file.
2. Select the measurement for which you want to view or modify the iOLM settings.
3. In the **Results** window, select the **Summary** tab.

The screenshot shows the 'Results' window with the 'Summary' tab selected. The window title is 'Results' and it has tabs for 'Identification', 'Summary', 'Thresholds', and 'Elements Table'. The main content area is titled 'iOLM' and contains four tables:

Results	
Link length	1,1705 km
Acquisition status	Completed
Analysis version	
Link loss (1300 nm)	0,944 dB
Link ORL (1300 nm)	30,59 dB
Prop. Delay (1300 nm)	5,798 µs
Link loss (850 nm)	3,327 dB

Test Parameters	
Wavelength(s)	1300 nm (9 µm); 850 nm (9 µm)
Measurement type	
Configuration name	MM-850+1300nm

Test Settings	
IOR (850 nm)	1,490000
Backscatter (850 nm)	-63,10 dB
Launch fiber length	0,0000 km
Receive fiber length	0,0000 km
Fiber core size	9 µm
Test method	Standard

Link Definition	
Fiber type	OM1 multimode 62.5 µm
Number of connections	2
Number of splices	0
My Element	3
Splitter ratio stage 1	None
Splitter ratio stage 2	None
Splitter ratio stage 3	None

At the bottom right of the window, there is a button labeled 'Custom Elements...'.

Working with iOLM files

Modifying iOLM Settings (FR2-FC Mode)

4. In the **Results** table you can see all the result components:
 - Link length: Displays the Link length.
 - Acquisition Status: Displays the status of the acquisition (taken normally or interrupted).
 - Link loss: Displays the Link loss for the indicated wavelength.
 - Link ORL: Displays the Link ORL value for the indicated wavelength.
 - Analysis version: Displays the version of the application used to analyze the link. If the measurement is analyzed with FastReporter 2, the analysis version is replaced by the FastReporter 2 version number. This version is saved only if the file is saved. If the version is not available, the field remains empty.
 - Prop. Delay: Displays the propagation delay for the indication wavelength.

Note: *If the link ORL value is saturated (displayed with a < symbol), the test is still performed to obtain a pass/fail status. However, you can only determine that the status is fail and the pass status cannot be specified.*

- In the **Test Settings** table, modify the IOR and the Backscatter values as needed.

The screenshot shows the iOLM software interface with the following data:

Results		Test Parameters		Test Settings		Link Definition	
Link length	1,1705 km	Wavelength(s)	1300 nm (9 μm); 850 nm (9 μm)	IOR (850 nm)	1,490000	Fiber type	OM1 multimode 62.5 μm
Acquisition status	Completed	Measurement type		Backscatter (850 nm)	-63,10 dB	Number of connections	2
Analysis version		Configuration name	MM-850+1300nm	Launch fiber length	0,0000 km	Number of splices	0
Link loss (1300 nm)	0,944 dB			Receive fiber length	0,0000 km	My Element	3
Link ORL (1300 nm)	30,69 dB			Fiber core size	9 μm	Splitter ratio stage 1	None
Prop. Delay (1300 nm)	5,798 μs			Test method	Standard	Splitter ratio stage 2	None
Link loss (850 nm)	3,327 dB					Splitter ratio stage 3	None

The IOR (850 nm) and Backscatter (850 nm) values in the Test Settings table are highlighted with a red box in the original image.

Note: The values set for 1550 nm are automatically computed for other wavelengths. You can only edit the IOR and backscatter values for the 1550 nm wavelength, even if other wavelengths are available in the selected iOLM measurement.

Note: When the IOR value is changed, the position and length of the section will be updated, and when the backscatter value is changed it triggers a reanalysis of the whole link.

Modifying the Splitter Ratio Information

The **Link Definition** table displays the information about the expected number of splitters on the link and their respective splitter ratio. You can modify the splitter ratios so that they are no longer included in the pass/fail calculation and have the application discover the ratios automatically.

The splint ratios are sequential, in the sense that if you set the first in sequence to None, any subsequent splitter ratio is automatically set to None as well.

Note: *Link definition on an iOLM measurement is available for display, but it is in read-only mode.*

To modify the splitter ratio information:

1. Open an iOLM configuration file.
2. In the **Results** window, select the **Summary** tab.
3. You can view and modify the splitter ratio stage 1, 2, and 3 fields in the **Link Definition** table.
4. Select 1:? if you know that a splitter is present, but you do not know its splitter ratio. The iOLM discovers the splitter ratio automatically and the element will not be tested for pass/fail.

Note: *The splitter ratios are defined stage wise, depending on how they are defined in the network.*


Modifying Identifier Labels (FR2-FC Mode)

You can view and modify the identifier labels for your iOLM measurement files.

Note: When multiple iOLM measurements are selected, you will see the information for all selected measurements. If the values are the same, they are displayed once; if not, they are separated by semicolons.

To modify the identifier labels:

1. Open an iOLM file.
2. Select the measurements for which you want to view or modify the Identifier labels.
3. In the **Results** window, select the **Identification** tab.



4. Select the identifier from the list of available choices in the **Identifiers** table to modify it. You can also rename the identifier by selecting it. As needed, you can change the corresponding value.

Note: The identifiers label is not editable if the iOLM measurements are selected with any other type of measurements such as CD or OTDR.

Note: When the Identifier label is selected as None, the values are not editable.

Working with iOLM files

Changing Fiber Core Size (FR2-FC Mode)


Changing Fiber Core Size (FR2-FC Mode)

The FastReporter 2 application displays the core size of the fiber for the selected measurement in the **Test Settings** table of the **Summary** tab. When multiple measurements are selected and the fiber core sizes are not similar, they are separated with a semicolon.

Note: The application allows you to change the fiber core size only for the multimode files.

To change the fiber core size:

1. On the **Measurements** tab, select the multimode measurement for which you want to modify the fiber core size.
2. From the **Summary** tab, select the required fiber core size in the list of available values.



The screenshot shows the 'Results' window with the 'Summary' tab selected. The 'iOLM' section is expanded to show four tables: Results, Test Parameters, Test Settings, and Link Definition. The 'Test Settings' table is highlighted with a red box, and the 'Fiber core size' row is also highlighted with a red box. The 'Fiber core size' is currently set to 62.5 μm.

Results	
Link length	0,5417 km
Acquisition status	Completed
Analysis version	2.5.0.13343
Link loss (1300 nm)	0,652 dB
Link ORL (1300 nm)	33,44 dB
Prop. Delay (1300 nm)	2,683 μs
Link loss (850 nm)	3,710 dB

Test Parameters	
Wavelength(s)	1300 nm (62.5 μm); 850 nm
Measurement type	
Configuration name	Point to Point

Test Settings	
IOR (850 nm)	1,490000
Backscatter (850 nm)	-63,10 dB
Launch fiber length	0,0000 km
Receive fiber length	0,0000 km
Fiber core size	62.5 μm
Test method	Standard

Link Definition	
Fiber type	
Number of connections	---
Number of splices	---
No custom element	0
Splitter ratio stage 1	None
Splitter ratio stage 2	None
Splitter ratio stage 3	None

3. The application prompts you to confirm the change. Click **Yes** to set the default values for result and test settings. If you click **No**, the fiber core size value changes, but the default values are not applied for result and test settings.

Changing the iOLM Fiber Type

When working with iOLM files, you can select a specific fiber type. Different fiber types are available depending on the type of mode you are working with (singlemode or multimode).

To change the fiber type:

1. Open the file or files you want to modify.

Note: You can only change the fiber type of multiple files if they are of the same mode.

2. In the **Summary** tab, under **Link Definition**, use the corresponding drop-down list to select the desired fiber type.

The screenshot shows the 'Results' window with the 'Summary' tab selected. The 'Link Definition' section is highlighted with a red circle, and the 'Fiber type' dropdown is open, showing 'OM1 multimode 62.5 μm' selected.

Results		Test Parameters		Test Settings		LINK DEFINITION	
Link length	1,1705 km	Wavelength(s)	1300 nm (9 μm); 850 nm (9 μm)	IOR (850 nm)	1,490000	Fiber type	OM1 multimode 62.5 μm
Acquisition status	Completed	Measurement type		Backscatter (850 nm)	-53,10 dB	Number of connections	2
Analysis version		Configuration name	MM-850+1300nm	Launch fiber length	0,0000 km	Number of splices	0
Link loss (1300 nm)	0,944 dB			Receive fiber length	0,0000 km	My Element	3
Link ORL (1300 nm)	30,69 dB			Fiber core size	9 μm	Splitter ratio stage 1	None
Prop. Delay (1300 nm)	5,798 μs			Test method	Standard	Splitter ratio stage 2	None
Link loss (850 nm)	3,327 dB					Splitter ratio stage 3	None


Custom Elements...

Changing the Number of Connections in the Link Definition

You can modify the number of connections in the link to see the impact of adding or removing connections on the dynamic loss budget thresholds. The threshold status will be modified accordingly.

To change the number of connections:

1. Open the file or files you want to modify.
2. In the **Summary** tab, under **Link Definition**, click into the corresponding box to enter the desired value.



The screenshot shows the 'Results' window with the 'Summary' tab selected. The 'Link Definition' section is highlighted, and the 'Number of connections' field is circled in red. The 'Number of connections' field is currently set to 2. The 'Fiber type' is 'OM3 multimode 62.5 μm'. The 'My Element' dropdown is set to 3. The 'Splitter ratio stage 1', 'Splitter ratio stage 2', and 'Splitter ratio stage 3' are all set to 'None'. The 'Test Parameters' section shows 'Wavelength(s)' as '1300 nm (9 μm); 850 nm (9 μm)', 'Measurement type' as 'MM-850+1300nm', and 'Configuration name' as 'MM-850+1300nm'. The 'Test Settings' section shows 'IOR (850 nm)' as 1.490000, 'Backscatter (850 nm)' as -63.10 dB, 'Launch fiber length' as 0.0000 km, 'Receive fiber length' as 0.0000 km, 'Fiber core size' as 9 μm, and 'Test method' as 'Standard'. The 'Results' section shows 'Link length' as 1.1705 km, 'Acquisition status' as 'Completed', 'Analysis version' as 'E', 'Link loss (1300 nm)' as 0.944 dB, 'Link ORL (1300 nm)' as 30.69 dB, 'Prop. Delay (1300 nm)' as 5.798 μs, and 'Link loss (850 nm)' as 3.327 dB.

Results		Test Parameters		Test Settings		Link Definition	
Link length	1.1705 km	Wavelength(s)	1300 nm (9 μm); 850 nm (9 μm)	IOR (850 nm)	1.490000	Fiber type	OM3 multimode 62.5 μm
Acquisition status	Completed	Measurement type		Backscatter (850 nm)	-63.10 dB	Number of connections	2
Analysis version	E	Configuration name	MM-850+1300nm	Launch fiber length	0.0000 km	Number of splices	0
Link loss (1300 nm)	0.944 dB			Receive fiber length	0.0000 km	My Element	3
Link ORL (1300 nm)	30.69 dB			Fiber core size	9 μm	Splitter ratio stage 1	None
Prop. Delay (1300 nm)	5.798 μs			Test method	Standard	Splitter ratio stage 2	None
Link loss (850 nm)	3.327 dB					Splitter ratio stage 3	None

Note: When you change the link definition parameters, the pass/fail thresholds will be recalculated.

Changing the Number of Splices in the Link Definition

You can modify the number of splices in the link to see the impact of adding or removing splices on the dynamic loss budget thresholds. The threshold status will be modified accordingly.

If you are working with iCERT files, you can change the number used to calculate the dynamic loss budget. If you have selected multiple iCERT files or if there are more than one custom elements, you will see how many of each are in the links.

To change the number of splices:

1. Open the file or files you want to modify.
2. In the **Summary** tab, under **Link Definition**, double-click into the corresponding box to enter the desired value.

The screenshot shows the 'Results' window with the 'Summary' tab selected. The 'Link Definition' table is visible, and the 'Number of Splices' field is highlighted with a red circle. The 'Number of Connections' field is also highlighted with a red circle.

Results		Test Parameters		Test Settings		Link Definition	
Link length	1,1705 km	Wavelength(s)	1300 nm (9 µm); 850 nm (9 µm)	IOR (850 nm)	1,490000	Fiber type	OM4 multimode 62.5 µm
Acquisition status	Completed	Measurement type		Backscatter (850 nm)	-63,10 dB	Number of connections	2
Analysis version		Configuration name	MM-850+1300nm	Launch fiber length	0,0000 km	Number of splices	10
Link loss (1300 nm)	0,944 dB			Receive fiber length	0,0000 km	My Element	3
Link ORL (1300 nm)	30,69 dB			Fiber core size	9 µm	Splitter ratio stage 1	None
Prop. Delay (1300 nm)	5,798 µs			Test method	Standard	Splitter ratio stage 2	None
Link loss (850 nm)	3,327 dB					Splitter ratio stage 3	None


Custom Elements...

Working with iOLM files

Changing the Number of Splices in the Link Definition

To change the number used to calculate the dynamic loss budget:

1. Open an iOLM file.
2. Under the **Summary** tab, select which custom element you want to modify.



The screenshot shows the 'Results' window with the 'Summary' tab selected. The 'Link Definition' table is visible, and the 'Number of Splices' cell is highlighted with a red circle. The value '3' is currently set in this cell.

Results		Test Parameters		Test Settings		Link Definition	
Link length	1,1765 km	Wavelength(s)	1300 nm (9 µm); 850 nm (9 µm)	IOR (850 nm)	1,490000	Fiber type	OM1 multimode 62.5 µm
Acquisition status	Completed	Measurement type		Backscatter (850 nm)	-63,10 dB	Number of connections	2
Analysis version		Configuration name	MM-850+1300nm	Launch fiber length	0,0000 km	Number of Splices	3
Link loss (1300 nm)	0,944 dB			Receive fiber length	0,0000 km	My Element	3
Link ORL (1300 nm)	30,69 dB			Fiber core size	9 µm	Splitter ratio stage 1	None
Prop. Delay (1300 nm)	5,798 µs			Test method	Standard	Splitter ratio stage 2	None
Link loss (850 nm)	3,327 dB					Splitter ratio stage 3	None

3. Change the value as needed.


Managing Elements

When an element or a section is selected from the link view, the details of the corresponding element or section are displayed in **Elements Table** tab. The loss, reflectance, wavelength, and corresponding pass/fail status for loss and reflectance will be displayed.

When you hover the mouse over any element, the application displays the corresponding details of the element, such as: type, wavelengths, loss, and reflectance.

Note: *Inversely, if you select an item in the **Elements Table** tab, the corresponding item is highlighted in the link view.*


Note: *Reflectance is not displayed if you hover the mouse over a non-reflective element.*




Working with iOLM files

Managing Elements

When you hover the mouse over any element groups, the application displays the group details separated by semicolons.



When you hover the mouse over any element with a diagnostic label, the application displays the description.



Note: It is possible to underestimate the loss or reflectance value if the noise level is too high (for instance, after a lot of loss on the link, the noise levels increase). In that case, it is possible for the signal processing algorithms to detect an element, and to estimate the loss/reflectance values, but since the measured signal does not completely clear the noise floor, the loss or reflectance values are likely to be underestimated. If the loss or reflectance value is underestimated, the value is displayed with a > symbol.

The elements that you could see on the link are described in the table below:

Element Name	Element Icon	Element Description
Macrobend		<p>Displayed in the link view when more than one wavelength is present in the measurement.</p> <p>The macrobend will always be displayed as a failed element.</p>
Out of Range		<p>Displayed when the end of fiber could not be detected by the module because the dynamic range is not large enough.</p>
Splitter		<p>Passive fiber optic coupler that divides light from a single fiber into two or more fiber channels. The splitter ratio is displayed above the icon.</p> <p>(Splitters are not available on multimode or bidirectional files.)</p>
Splice		<p>Indicates the junction of two fiber sections having different fiber backscatter characteristics.</p>
Connector		<p>Used to join two fibers.</p>
Mismatch		<p>The elements on a matching location in the link are not of the same type.</p>
Fault		<p>No splitter was detected on the fiber. This element type is always considered as a fault.</p>
Switch		<p>The switch element is used for multifiber MPO switch automated acquisitions.</p>

Customizing the Elements Table Tab

When viewing measurements, you can customize what is displayed in the **Elements Table** tab to better reflect what you want to see about the elements, the sections, or both.

To customize the Elements Table tab:

From the **View** menu, click on **iOLM**, and then **Element Table** to select the desired items.

- *Element*: to view the element details.
- *Section*: to view the section details.
- *Element/Section Statistics*: to view the statistics for the elements and sections
- *Fiber Statistics*: to view the statistics pertaining to the fibers.
- *Group Details*: to view detailed information for the grouped items.
- *Position*: to view the position details of the elements.
- *Element Loss*: to view the loss details of the elements.
- *Reflectance*: to view the reflectance details of the elements.
- *Display Element Type as Text*: to view the element type in written form.
- *Display Element Type as Icon*: to view the element type as an icon.
- *Length*: to display the section lengths.
- *Section Loss*: To display the loss for the section.
- *Attenuation*: to display the section attenuation.

Note: You can also right-click on the fixed column of the **Elements/Section Details** tab and customize the view.

The corresponding view is displayed in the **Elements Table** tab.

Identifiers	Dir.	P/F	Wavelength (nm)	Pos./Len. (km) Loss, Refl. (dB) Att. (dB/km)	Group	Element 1	Element 2	Section	Element 3	
						0.0000 km	0.0030 km		0.5767 km	
1	A->B	✓	1310	Type:	Group	1/1	Connector	1/1	Splice	
				Pos./Len.:	0.0000	0.0000	0.0030	0.5738	0.5767	
				Loss:	1.242	---	---	0.231	0.196	
				Refl./Att.:	-54.7	-74.7	-54.7	0.403	---	
				1490	Loss:	0.981	---	---	0.166	0.148
					Refl./Att.:	-55.3	-72.7	-55.3	0.290	---
					Loss:	0.936	---	---	0.192	0.136
					Refl./Att.:	-55.3	-74.7	-55.3	0.335	---
				1550	Loss:	0.936	---	---	0.192	0.136
					Refl./Att.:	-55.3	-74.7	-55.3	0.335	---

You can see the attributes below in the tab:

- **Type:** The type of element selected in the link view. You can modify the element type by selecting it from the drop-down menu. If an element is modified as a custom element, the name of the custom element shows in the tool tip.

You can also change the splitter ratio if the selected element is a splitter, including 2:N splitters if the measurement supports them.

Note: The items available in the list depend on the characteristics of the selected element. It may not be possible to change the element type.

Note: If the type of an element is modified, an asterisk (*) is displayed in the **Type** column.


- **Position/Length:** The position of the element on the link and section length. Position 0.00 is set on the first element after the launch fiber.
- **Loss (dB):** The loss at different wavelengths.
- **Reflectance (dB):** The reflectance at different wavelengths.
- **Attenuation (dB/km):** The attenuation value for each wavelength.

Note: The attenuation detail is displayed for the section and the field is displayed only when **View Section Details** is selected.

Viewing Grouped Elements

Link elements will be displayed as groups when the iOLM analysis detects that several elements are too close to be independently characterized. When this occurs, as much information as possible is displayed for each individual sub-element. The pass/fail status is applied to each sub-element whenever possible, and a global status is also displayed for the group.

Groups can also be displayed when a link element (such as a splitter) is found to have wavelength dependant loss. In that case, the link element is grouped with a macrobend element. In this particular case, there might not be a physical macrobend next to the link element, but the macrobend icon is used to highlight the presence of the wavelength dependant loss. When elements are grouped, the group loss and group reflectance value is also displayed in the **Element** tab.



Each sub-element is directly displayed as if they were normal elements.

Note: For grouped elements, some values may not be available individually but are available at the group level, such as loss and reflectance.

Note: If elements are grouped, the total group loss value is compared with the addition of the thresholds defined for each element in the group. If the total group loss value is greater than the addition of the thresholds defined for each element in group, the grouped element will show a fail status. You can individually select grouped elements as any other standalone element. When elements are grouped at the beginning of the link, icon A is displayed on one of the sub-elements. When elements are grouped at the end of the link, icon B is displayed on one of the sub-elements.

Adding Elements

The application allows you to add elements in iOLM and iOLM Bidir files in the link view by selecting any element or section.

You can add elements in both the Fiber and Cable views as well as the **Elements Table** tab. Adding an element to the cable (whether you do it in Cable view, or on the cable at the top of the Fiber view) adds it to all of the fibers. You can also take one element from one fiber and add it to the other fibers.

The added element supports the following scenarios depending on the distance or position of the element:

- The new element is added in a section of the link between two existing elements.
- The new element is added as a sub element in existing element group.
- The new element is added as a sub element to a single element to create a new element group.

Note: *You cannot add any element before Element A or after Element B.*


Note: *You cannot add splitters on multimode or bidirectional measurements.*

Working with iOLM files


Customizing the Elements Table Tab

To add an element:

1. Open an iOLM or iOLM bidir file.
2. Select the section or existing element where you want to add the new element, then from the **Measurement** menu, select **iOLM**, and **Add Element**.
3. Select whether the new element will be located before or after the element you have selected. If you are adding an element to a section, indicate the position of the element.




Element




Section

4. Select the type of the new element as required.



Element



Section

Note: You can change the splitter ratio to 2:N, if the measurement supports it.


Note: The splitter element type is not available for iOLM bidirectional files.

5. Click **OK** to apply the changes or **Cancel** to discard them.


Note: If an element is added, an asterisk (*) is displayed in the **Position** and **Type** columns.

To add an element to a group of elements:

1. Open an iOLM file.
2. Select an element from an existing group of elements where you want to add the new element, then from the **Measurement** menu, select **iOLM**, and **Add Element**.
3. Select whether the new element will be located before or after the element you have selected.



4. Select the type of the new element as required.



5. Click **OK** to apply the changes or **Cancel** to discard them.

Note: When an element is added to another element with no sub-elements, the current element will become a merged/group element. You can view the details in the **Elements Table** tab.

Note: When you add an element to a group of elements, it impacts the pass/fail status of the grouped elements.

Working with iOLM files

Customizing the Elements Table Tab

To add an existing element to other fibers:

1. Select the element you want to add.
2. From the **Measurement** menu, click **iOLM**, and then select **Add to Other Measurements**.

Note: *The application displays a warning message when the element cannot be inserted at the specified location.*

Note: *The Add to Other Measurement feature is not available if you cannot use it (for example, if you are trying to use it while being in Cable view, and that the element is already present in all of the fibers).*

Modifying Element Types

You can view and modify element types that you see in the link view. You can change the type while being in either Fiber view or Cable view, as well as the **Elements Table** tab. Changes done in the Cable view or on the cable at the top of the Fiber view are done on each fiber included in the cable.

Note: *For iOLM bidirectional files and multimode files, the splitter element type is not available.*

Note: *You cannot modify the type of the element if they are out of range or if they are macrobends.*


Note: *If an element type is changed, an asterisk (*) is displayed in the **Type** column.*

Note: *The items available in the list depend on the characteristics of the selected element. It may not be possible to change the element type.*

You can edit the properties for iOLM elements and sections. Event properties that cannot be edited are shaded.

To edit iOLM element properties:

1. Click on the element or section for which you want to change the properties.
2. On the **Measurement** menu, select **iOLM**, select **Element**, and click **Properties**.
3. Modify the properties as needed. The editable values are shown in a white background.



Note: The comment that you enter in the **Comments** field is displayed as a tooltip when you hover the mouse pointer over the element in the graph area and element table.

4. Click **OK** to confirm your changes.

Deleting Elements

The application allows you to delete the manually added elements as well as the elements found by analysis. You can delete the elements either the Fiber view, the Cable view, or the **Element Table** tab, the procedure is the same. An element removed from the Cable or on the cable at the top of the Fiber view view is removed from all fibers included in the cable.

The application does not allow you to delete the following type of elements:

- Splitters 1:N and 2:N
- First connector
- End of fiber
- Out of range
- Link start element
- Link end element

To delete an element:

- 1.** Open an iOLM file.
- 2.** Select the element or elements which you want to delete.
- 3.** Right-click on the link view, and click **Delete Element**.
- 4.** A confirmation message is displayed. Click **Yes** to continue or **No** to cancel it.

Managing Custom Elements

On a given link topology, it is possible to have different types of splices, connectors, and other kinds of elements. For this reason FastReporter 2 lets you create custom elements as per your requirements. You can also configure the details such as pass/fail thresholds.

The application allows you to add, modify or delete custom elements in the test configuration. You can also add the custom element in the iOLM configuration file and apply it to the selected measurement.

You can add custom elements of two types: splice or connector. Each custom element must have its unique name.

Note: *When more than one iOLM measurements are selected, the new custom element will be added to the test configuration in all selected measurements.*


Note: *When more than one iOLM measurements are selected, the application displays all custom elements included in the test configuration for each iOLM measurement selected.*

Working with iOLM files


Customizing the Elements Table

To add a custom element:


1. Open an iOLM file.
2. Click on **Custom Elements** under the **Summary** tab.




3. Click  in to add a new custom element.



4. Enter a name for the element.



5. Select the custom element type.



6. Press **OK** to save the changes and close the dialog box, or press **Cancel** to exit without saving.

Once your custom elements are added, they become available in the list of available element types. You can find information about changing the element type in *Modifying Element Types* on page 290.

The application allows you to view the pass/fail threshold for each custom element of the test configuration even if the FR2-FC option is not activated. If multiple iOLM measurements are selected, the application displays the pass/fail threshold for each custom element included in each test configuration of the selected iOLM measurements.

If the same custom element is included in more than one iOLM measurements and the threshold values are different, the application displays all different threshold values separated with a semicolon.


Note: *You can edit the loss pass/fail thresholds for each custom element only when the FR2-FC option or the trial is activated.*

Working with iOLM files


Customizing the Elements Table

To modify a custom element:

1. Open an iOLM file.
2. Click on **Custom Elements** under the **Summary** tab.



3. Click on the custom element name under the **Element Name** column and modify it as needed.




Note: If the element is in use, you cannot modify it.


4. Press **OK** to save the changes and close the dialog box, or press **Cancel** to exit without saving

To delete the custom element:

1. Open an iOLM file.
2. Click on **Custom Elements** under the **Summary** tab.



3. Select the custom element that you want to delete.



4. Press **x** to delete the custom element.

Note: If the element is in use, you cannot modify it.

Enabling 2:N Splitters


2:N splitters can be used to create network redundancy. If a network break occurs, you can still connect through the other network branch. This ensures active communication while the repairing of the broken network is in progress.

Note: *The application allows you to use the 2:N splitter feature in the iOLM configuration file and you can only use the 2:N splitter feature for splitter ratio stage 1.*


In the splitter ratio stage 1 field, if 1:? or None is selected and you enabled the 2:N splitter option, the 1:? and None are replaced by a 2:2 splitter value.

To enable a 2:N splitter:

1. Open the iOLM configuration file.
2. From the **Summary** tab, enable the **2:N Splitter** option.



3. Select the desired ratio for stages 1, 2 and 3.



In the iOLM file, you can view the 2:N splitter value in the Link composition, and select the element type as 2:N splitter if the selected measurement supports the 2:N splitter values.



Setting Launch and Receive Fibers on Elements

You can change Link Start Element (A) and Link End Element (B) on the link. The application also allows you to change the launch fiber length and receive fiber length on both new and existing elements. If no element is located in this position, a new element is created.


You can set the launch and receive fibers in both Fiber and Cable views, as well as the **Elements Table** tab. However, if you are setting them in Cable view, or on the cable at the top of the Fiber view, the operation must be possible on all of the fibers included in the cable.

To set the Launch fiber and Receive fiber on an existing element:

1. Open the iOLM file.
2. Select the element that you want to set as the launch/receive fiber element from the link or fiber views. Right-click on the element, and select **Set Element as Link Start** or **Set Element as Link End**.

To change the launch fiber and receive fiber positions:

1. Open the iOLM file.
2. Enter the launch fiber length and receive fiber length in the **Test Settings** table under the **Summary** tab.



When the launch fiber length and receive fiber length are changed, a partial analysis is performed. In this partial analysis, the values for link length, link loss, link ORL, element position, element section length, and diagnostics are recalculated. This partial analysis does not change the elements you have added or the elements you have changed in the link.

Note: *If the entered launch fiber length and receive fiber length are not valid, the application prompts an error message. If no element is present at the position, then a new element is automatically inserted in that place.*

Note: *If a macrobend is set either as link start or link end, a new connector is added and that element will be set as link start or link end.*

Analyzing Measurements (FR2-FC Mode)

You can recalculate the acquisition results. However, when the trace is analyzed, the manually added elements will be removed from the link and the element details table is refreshed accordingly.

Note: *You cannot analyze the unidirectional files created by the loopback process.*

To analyze measurements:

1. In the **Measurements** tab, select the measurements to analyze.
2. In the **Measurement** menu, select iOLM, and click **Analyze**.

Using the Failed Element Filter

In order to quickly see which measurements are faulty, you can apply a specific filter to show only the failed element.

To activate the failed elements filter:


In the **Element Table** tab, right-click in the table, then select **View Failed Items**.

Generating a .sor File From iOLM Measurements (FR2-FC Mode)


With FastReporter 2, you can generate OTDR .sor files from iOLM files for each measurement.

To generate an OTDR .sor file:

1. Select single or multiple iOLM files from the **Files** Window.
2. From the **File** menu, click on **Export**, and select **To OTDR SOR file**.
3. Select what you want to do with the resulting file:
 - Export it to the desired location and open it.
 - Export it to the desired location only.
 - Create a temporary file, kept in memory only. This is useful if you want to create reports, for example.




4. If you choose to export the file, select a location for it.



Working with iOLM files

Generating a .sor File From iOLM Measurements (FR2-FC Mode)

5. Select the type of file you want to as the result of the export.



6. Click **OK**.

Note: If a .sor file with the same name already exists on disk, a confirmation message is displayed to overwrite the existing file.

Note: The wavelength is automatically appended to the file name when the iOLM measurement contains more than one wavelength.

Note: When you attempt to generate a .sor file and the iOLM measurement does not contain the necessary intermediate OTDR measurement, the .sor file is not generated.

When an attempt to generate the .sor file is done and the iOLM acquisition state is not completed or interrupted, the application prompts an error message explaining the origin of the problem and the solution to avoid it.

Managing Configuration Files (FR2-FC Mode)


You can create a new configuration file as well as apply configuration settings to existing measurement files.

Creating Configuration File

The **File** menu allows you to create a configuration file and the created file is saved in the configuration file list. You can customize this configuration to fit your needs.

To create a configuration file:

1. From the **File** menu, select **New**, and **iOLM Configuration**.



2. Enter the desired file name in the **Save As** dialog box and click **Save**.

Working with iOLM files

Managing Configuration Files (FR2-FC Mode)

- In the **Identification** tab, enter the desired identifiers for your files, as well as the auto-incrementation scheme you want to use.

The screenshot shows the 'Results' window with the 'Identification' tab selected. The 'iOLM Config' section is visible, containing several tables for configuration.

General Identification		Identifiers	Values	Auto Increment	Start	Stop	Step	Location A	
Filename	ANSL_TIA-568-C3_ISPiolmcf	Fiber ID		<input checked="" type="checkbox"/>	1	99	1	Unit model	
Test date	2016-09-21	Cable ID		<input type="checkbox"/>	0	0	0	Unit serial number	
Test time	11:25 (GMT-05:00)	None						Calibration date	
Job ID		None						Location B	
Customer		None						Unit model	
Company								Unit serial number	
Operator A								Calibration date	
Operator B									
		Additional Information							
		Comments							


- In the **Summary** tab, select the various information for your test settings and link information. If your files were acquired using an iCERT-enabled unit, you can select the fiber type here. If your files were acquired with an Optimode, you can select it here as well.

The screenshot shows the 'Results' window with the 'Summary' tab selected. The 'iOLM Config' section is visible, containing several tables for configuration.

Results		Test Parameters		Test Settings		Link Definition	
		OptiMode	None	IOR (850 nm)	1.490000	Fiber type	---
		iCert	No	Backscatter (850 nm)	-66.30 dB	Number of connections	---
				IOR (1550 nm)	1.468325	Number of splices	---
				Backscatter (1550 nm)	-81.87 dB	No custom element	0
				Fiber core size	9 µm	Splitter ratio stage 1	None
				Test method	Standard	Splitter ratio stage 2	None
						Splitter ratio stage 3	None


Below the tables, there are three buttons: "SOR Pulse Editor...", "Use 2:N Splitter" (with a checkbox), and "Custom Elements..."

If you want to change the SOR pulse and acquisition time, click **SOR Pulse Editor**, then enter the new pulse and time values to use.



Note: If no pulse value is available, the pulse and acquisition time are set to “none”.

- In the **Thresholds** tab, enter the threshold values according to your needs. If you want to include specific certification standards for your iCERT files, you can do it here.



- Save your changes once you are done.

Working with iOLM files

Managing Configuration Files (FR2-FC Mode)

Applying Configuration Settings


You can use the settings of a configuration file, such as identifier labels and thresholds, and apply them to a file you select in the list.

The configuration files are saved in the following location in your computer:

C:\ProgramData\Exfo\FastReporter2\Standard\Configuration Files

To apply the configuration settings:

1. Select an iOLM file from the **Files** tab.
2. From the **Tools** menu, select **iOLM**, and **Apply Configuration**.
3. Select the desired configuration file, click **Apply**, and **OK**.



Note: If the configuration you want to use is not in the list, you can use the **Import** button to add it.

Note: If the configuration file is TIA certification compliant, it will be indicated at the beginning of the row.

Understanding Diagnostics

This section explains the diagnostics feature available in the intelligent Optical Link Mapper application.


Diagnostics are used to provide additional information about detected problems or ambiguous measurement situations, such as root cause possibilities for the fail status of a link element. The diagnostics provide help to troubleshoot faulty connectors, understand why link elements are tagged as fail or unknown, indicate unexpected instrument or test conditions and so forth.

Link elements with an associated diagnostic are marked with an  icon, and the diagnostics are displayed in the **Element** tab. More than one diagnostic can be associated with any given element.

If you are viewing multiple measurements in the Cable view and the elements present an anomaly (for example, the elements are not of the same type or do not have the same threshold values), you will notice an  icon on the upper right-hand corner of the element instead.

Element diagnostics are associated with specific link elements issues. Each failed link element will have associated diagnostics to assist in troubleshooting. Some elements, such as macrobends, will have associated diagnostics even with a pass status.

You can see the details about the diagnostics in the **Elements Table** tab.



Identifiers	Dir.	P/F	Wavelength (nm)	Pos./Len. (km) Loss, Refl. (dB) Att. (dB/km)	Element 4	Section	Element 5	Section	Element 6
CAB 001 Fiber 002	Bidir		1550	Type: Pos./Len.: Loss: Refl./Att.:	0.4998 km 1/1	1/1	0.5750 km 1/1	1/1	0.8003 km 1/1

• Make sure that the fiber is properly spliced.
 The excess loss could be due to an element not identified as a splitter.
 • Possible macrobend.
 Try to test with two wavelengths to confirm the macrobend.
 Inspect the fiber in this area to find excessive bending.

Viewing Power Meter Results

Power meter results are displayed in the OPM and PPM table. For more details, see *Viewing Power Meter Results* on page 233.

Managing Bidirectional iOLM Files

FastReporter 2 allows you to view and create bidirectional iOLM files. Selecting each unidirectional file or the resulting bidirectional file displays the corresponding data in the **Results** window.

Creating a Bidirectional iOLM File


The application allows you to create a bidirectional iOLM file from two matched iOLM measurements of opposite directions. You can create more than one file at once, providing that each have their matching file.

The measurement files must meet the following criteria:

- The measurement lengths in both direction are the same.
- There are no splitters in the link elements.

To create a bidirectional iOLM file:


1. If you have not done so already, activate the iOLM bidirectional file creation option, as explained in *Modifying Tolerance and Bidirectional Settings* on page 252.
2. Select two matched iOLM files of opposite directions.
3. Click on **Tools > iOLM > Create Bidirectional Files**.
4. Select the location where you want to save the bidirectional file.




Working with iOLM files

Managing Bidirectional iOLM Files

5. Select the desired file naming options.
 - Select **A->B filename** or **B->A filename** to use the selected A->B or B->A file name.
 - Select **Identifiers** to save the bidirectional file as per the matched identifiers. The identifiers name is formed from the identifiers order displayed in the **Matched Files** tab, separated by the separating character you have selected.
 - Select **Autonaming** to enter a prefix and a suffix to create the file name.




6. Select which documentation will be used for the bidirectional measurement.




Working with iOLM files

Managing Bidirectional iOLM Files

7. Select which thresholds you will use in the bidirectional measurement.




8. If you want to keep the original unidirectional files open after creating the bidirectional file, select the corresponding option.



Working with iOLM files

Managing Bidirectional iOLM Files

9. If you want bidirectional files created automatically using the current settings, select **Do not display the dialog**. Any future bidirectional file creation will use these settings.



Note: To enable the iOLM Bidirectional File Creation window again, follow the instructions in Modifying Tolerance and Bidirectional Settings on page 252.

10. Click **OK** to save your settings.


Working with Virtual Bidirectional Files

Virtual bidirectional files are a way to preview the resulting measurement when you select two matching unidirectional measurements without going through the process of fully creating the bidirectional file. The display in the link view, **Threshold**, **Elements** and **Results** tables are the same as they would if you are viewing an actual bidirectional measurement. The order of display for the elements depend of the A -> B measurement. Since this is a viewing option only, you cannot perform operations such as adding or removing elements when the virtual bidirectional mode is active.

Note: *You cannot create bidirectional files with multimode measurements.*

To activate the virtual bidirectional file mode:

From the **View** menu, select **iOLM**, then **Display Virtual Bidir**.




Viewing Section Length for Multiple Measurements

When multiple measurements are opened, the application displays the section length on the graph. You can also choose to hide it.

To view or hide the section length:

1. Open multiple iOLM measurements.
2. Right-click on the Fibers view and select **View section Length**.



Matching Link Elements with a Reference

When any measurement is selected as reference measurement, all elements of the reference measurement are considered as reference elements. The application uses an algorithm with tolerance to match these elements. For more information of setting the tolerance, see *Modifying iOLM Settings (FR2-FC Mode)* on page 271.

Note: *If you have selected a reference measurement, the link length displayed is that of the reference measurement.*

To set a reference measurement:

In the **Elements Table** tab, right-click on the measurement that you want to use as the reference, then select **Set as Reference**. The measurement changes color in the table to indicate its new status and the corresponding row is blocked at the top of the table so that you always see it even when scrolling down the list of other measurements.


Identifiers	Dir.	P/F	Wavelength (nm)	Pos./Len. (km) Loss, Refl. (dB) Att. (dB/km)	Group	Element 1	Element 2	Section	Element 3
						0.0000 km	0.0025 km		0.0223 km
						3/3	2/3	1/3	1/3
3	A->B		1310	Type: Pos./Len.: Loss:	Group Connector	0.0000 0.0000	0.0025 0.670	0.0198 0.004	Splice 0.0223 0.896
			1550	Refl./Att.: Loss: Refl./Att.:		-77.4 0.185 -77.1	--- --- ---	0.200 0.004 0.200	--- 0.607 ---
1	A->B		1310	Type: Pos./Len.: Loss:	Group Connector	0.0000 0.672			
			1550	Refl./Att.: Loss: Refl./Att.:		-74.6 0.536 -73.1			

Matching Link Elements Without a Reference

When multiple measurements are selected, the elements from different measurements are matched according to their position (the position of the elements can be slightly different). The application uses an algorithm with tolerances to match these elements. For more information of setting the tolerance, see *Modifying iOLM Settings (FR2-FC Mode)* on page 271.

When no reference measurement is selected, all elements of the first measurement are considered as the reference elements. In the remaining traces, if some elements are not matching, they are also included as reference elements.

Matching is always done from left to right in accordance with the element location. If elements are present before the link start (A), the matching will be done from right to left.



Displaying Statistics for Matched Measurements

When displaying matched measurements, it might be useful to view statistics for them. The statistics are displayed for:

- ▶ Fibers (includes loss, reflection and attenuation data for splices, connectors and sections), which are displayed on the far right of the **Elements Table** tab.
- ▶ Elements and Sections (includes for loss, reflection and attenuation data for each wavelength for each event and sections), which are displayed at the bottom of the **Elements Table** tab.

The statistics displayed are the minimum value, the maximum value, and an average for the selected files. If you click on the minimum and maximum values, the corresponding element is highlighted in the Fiber or Cable views.

Note: *In the case of Fiber statistics, the highlighted element is based on the loss value.*

Note: *You must have enabled the corresponding item for the statistic to appear. For example, if you chose not to display the positions, the corresponding statistic is also hidden.*


To display the statistics:

1. Select the multiple measurements for which you want to view the statistics.
2. In the **Elements Table** tab, right-click in one of the columns, and select the type of statistics you want to view.

Using the FTTx Mode

If you are working with files that include splitter elements, the FTTx view can help you better visualize your results. This type of view will invert the links so that the results are displayed from event B to event A, that is, from the optical network terminal (ONT) to the central office (CO).

In the **Measurements** tab, measurement files containing at least one splitter element are identified by a mark in the FTTx column.




P/F	Identifiers	Type	FTTx	Direction	Link loss (1310)	Link loss (1550)	Link ORL (1310)	Link ORL (1550)	Link length
1		iOLM	✓	A->B	19,334 dB	19,128 dB	51,88 dB	53,69 dB	0,6160 km
1		iOLM	✓	A->B	23,723 dB	23,074 dB	49,36 dB	52,75 dB	3,2030 km

Note: While in FTTx mode, you cannot create bidirectional files, loopback files, or generate application-based reports.

To enable the FTTx mode:

- 1.** On the **Settings** menu, click **iOLM** and then the **General** tab.
- 2.** Enable the mode.



- 3.** Click **OK**.

Working with iOLM files

Using the FTTx Mode

To display the FTTx view:

Right-click in the Link view, then select the FTTx view.

OR

Select the view in the **View > iOLM** menu.

The FTTx links will be identified with specific icons in the Link view, and has its own tab in the result table.

The screenshot displays the FastReporter 2 interface. The top part shows a network diagram with fiber links and various icons representing different components. The bottom part shows the 'Results' table with the following data:

Identification				Summary				Thresholds				FTTx Elements Table					
Identifiers	Dir.	P/P	A (nm)	Pos./Len. (km)	Loss, Refl. (dB)	Att. (dB/km)	Element 1	Section	Element 2	Section	Element 3	Section	Element 4	Section			
1	OLT->ONT		1310	0.0000	0.0000	0.0000	0.0000	0.0000	1/2	0.5000	1/2	0.5375	1/2	0.5651	1/2		
				0.5000	0.5000	0.5375	0.5651	0.5925	0.6200								
				1550	0.5000	0.5375	0.5651	0.5925	0.6200								
				1550	0.5000	0.5375	0.5651	0.5925	0.6200								
1	OLT->ONT		1310	0.0000	0.0000	0.0000	0.0000	0.0000	1/2	0.5000	1/2	0.5375	1/2	0.5651	1/2		
				0.5000	0.5000	0.5375	0.5651	0.5925	0.6200								
				1550	0.5000	0.5375	0.5651	0.5925	0.6200								
				1550	0.5000	0.5375	0.5651	0.5925	0.6200								

Note: The FTTx Results table appears only if you select FTTx measurements. As soon as you include a regular iOLM measurement, the tab will be hidden.

12 *Viewing and Editing Measurements*

Once you have added files to your list, you can view the results for the measurements they contain in the **Results** window, as well as identification information about them.

The tabs available depend on the measurement type selected. For example, for OTDR measurements, in addition to the **Identification** and **Summary** tabs, there is also the **Event Table** tab, and the **Markers** tab, if available for the selected measurement.

Editing Measurement Identification Information

You can edit several of the fields on the **Identification** tab in the **Results** pane. Other fields are populated from information in the measurement file, if present, and will appear shaded.

Your FastReporter 2 application allows you to edit the general identification information for single-fiber as well as multiple-fiber connector FIP files.


To edit the identification information:

- 1.** Open the required file.
- 2.** Select the measurements for which you want to view or modify the identifier labels.
- 3.** In the **Results** window, select the **Identification** tab.

Viewing and Editing Measurements

Editing Measurement Identification Information

- Click in the white section to the right of a field label to select it, then enter the desired value.



Note: The identifier labels are not editable if iOLM measurements are selected with any other type of measurement (for example, OTDR).


Note: When the identifier label is selected as None, the values are not editable.

Modifying Auto-Increment Values for iOLM Configuration Files

You can set auto-increment values for several items in your iOLM measurement files.

To modify the auto-Increment values:


- Open an iOLM configuration file.
- Select the measurements for which you want to modify the auto increment values.
- In the **Results** window, select the **Identification** tab.




Viewing and Editing Measurements

Editing Measurement Identification Information

- For each item that you want to include in the auto-increment process, enable the **Auto-Increment** option.



- Modify the start, stop, and step values for the items as needed.



Note: The step value must be smaller than the difference between the start and stop values. If the start is greater than the stop, then the identifier value begins decrementing by the specified step.

Viewing and Editing Measurements

Editing Measurement Identification Information

Modifying the Calibration Date for OTDRs

Sometimes, older OTDR models do not provide the right calibration date required to view the data and perform your analysis. You may need to change it.

In your OTDR result display, you can see the calibration dates for units A and B, if there are any. You can modify the calibration date of the OTDR file; the updated calibration date is saved in corresponding OTDR file.

The application allows you to edit the calibration date for the OTDR measurements based on the following conditions:

- If the file direction is A->B, you can change the date of location A.
- If the file direction is B->A, you can change the date of location B.
- If the file is in OTDR Bidir format, you can change the date of both locations A and B

Note: *The application displays the date range for up to the last ten years for the calibration date. If no date is indicated, and you want to edit the calibration date, the application displays the date range up to the previous month.*

To edit the calibration date:

1. Select one or several OTDR measurements.
2. Change the calibration date in the appropriate location.

The screenshot displays the software interface for viewing and editing OTDR measurements. The main window shows a plot of the OTDR measurement with a signal loss curve over a distance of 40 km. The y-axis represents power in dB, ranging from 0.00 to 45.00. The x-axis represents distance in km, ranging from 0 to 40. The plot shows a signal loss curve with several sharp peaks and a red line indicating the signal path. Markers 'A' and 'B' are visible on the plot.

The 'Results' window is open, showing the 'Identification' tab. The table below displays the measurement details:

Values	Location A
Fiber003	Unit model 400-ST37-EL-VFL
	Unit serial number 267027
	Calibration date 2/27/2004
	Location B
	Unit model
	Unit serial number

The 'Files' window is also open, showing a list of files and their types. The 'Calibration date' field in the results table is highlighted in red, indicating that the date was changed.

Note: An asterisk (*) will indicate that the date was changed.

Viewing and Editing Measurements

Editing Measurement Identification Information

Modifying Additional Information

You can modify additional information for OLTS and OPM/PPM measurements, such as comments relating to the cables or fibers.

Note: *If a cable comment is present, the application merges this comment with the comment of each fiber measurement of this cable. The cable comment and the fiber comment are separated by a hyphen (-).*

To modify the additional information:

1. Open the required file.
2. Select the **Identification** tab.
3. Click on the **Comments** field under the **Additional Information** section to modify the additional information.

The screenshot shows a software window titled "Results" with a tabbed interface. The "Identification" tab is selected, and the "PPM" section is active. The interface is divided into several sections:

- General Identification:** A table with fields for Filename (FTTx: Samples.ppm), Test date (1/14/2009), Test time (3:04 PM (GMT-05:00); 2:51 PM), Job ID (Job 01), Customer, Company, Operator A, and Operator B.
- Identifiers:** A table with fields for OLT (OLT 01), ONT (001), and Location (ONT; SPLT).
- Location A:** A table with fields for Unit model (PPM-352C-EA) and Unit serial number (449819).
- Additional Information:** A section highlighted with a red circle, containing a "Comments" field with the value "Fiber 01".


Modifying Summary Information (FR2-FC Mode)

When viewing your test results, you can quickly find a summary of the information, and modify the related test settings as needed to view the impact on the measurement.

Note: The items displayed in the **Summary** tab will depend on the type of file you are viewing.

To edit the summary information:

1. Open the desired file.
2. Select the measurement for which you want to view or modify the summary information.
3. Click in the field to the right of the field label.
4. Enter a value.



Viewing and Editing Measurements

Viewing and Sorting Files or Measurements

Viewing and Sorting Files or Measurements

You can view and sort files and measurements according various criteria, depending on the type of file or measurements you are viewing. You can sort the files according the header, or you can do manual sorting.

The available file types at the top window will determine which items displayed:

- CD
- FIP
- iOLM
- Instruments
- Operators
- Job
- Locations
- OTDR
- OTDR (DWDM)
- PMD
- OPM
- PPM
- OLTS (Loss)
- OLTS (ORL)
- Certification

Viewing and Editing Measurements

Viewing and Sorting Files or Measurements

Select which items to view from the list. Depending on which types of files are displayed, the available items will differ.

Click to sort according to a specific column.

Click and drag to change position manually.

Right-click to select other sorting criteria.

Right-click to select columns to display. Change the order by dragging the column to a new location (available for OTDR, iOLM and OLTS only). In the **Files** tab, you can select to display the **Identifiers** column.

P/F	Identifiers	Type	Direction	Span Length	Span Loss	Span ORL	Event Count	Test Date/Time
✓	Fiber003	OTDR-	550 A->B	8.1	✓			3/4/2004 12:51:0
✓	Fiber003	OTDR-	550 A->B	12	✓			3/4/2004 2:01:55
✓	Fiber003	OTDR-	550 A->B	12	✓			3/4/2004 2:01:55
✗	Fiber0190	OTDR-	310 A->B	44	✓			5/11/2010 3:49:2
✗	Fiber0190	OTDR-	550 A->B	44	✓			5/11/2010 3:50:0
✗	Fiber0190	OTDR-	625 A->B	44	✓			5/11/2010 3:50:5
✓	0005; 0022	OTDR-	310 A->B	37	✓			3/28/2007 1:32:5
✓	0005; 0022	OTDR-	550 A->B	37	✓			3/28/2007 1:33:1
✗	0005; 0022	OTDR-	625 A->B	37	✓			3/28/2007 1:33:4
✗	Cable ID; FI	OTDR-	550 A->B	6	✓			3/1/2004 11:37:4
✗	Fiber003	OTDR-	550 A->B	8	✓			3/3/2004 11:44:1
✓	0014; 0002	OTDR-	1310 A->B	39	✓			4/3/2007 11:14:0
✓	Fiber003	OTDR-	1550 A->B	41	✓			3/4/2004 2:28:23
✓	Fiber0190	OTDR-	1550 A->B	23	✓			5/11/2010 3:57:0
✓	Fiber0190	OTDR-	1625 A->B	23	✓			5/11/2010 4:00:0
✓	Fiber0190	OTDR-	1310 A->B	1	✓			5/11/2010 3:31:4
✓	Fiber0190	OTDR-	1550 A->B	1	✓			5/11/2010 3:32:1
✓	Fiber0190	OTDR-	1625 A->B	1	✓			5/11/2010 3:32:5

Context Menu Items:

- P/F
- Type
- Direction
- Span Length
- Span Loss
- Span ORL
- Event Count
- Test Date/Time
- Filename
- Min. Splice Loss
- Max. Splice Loss
- Min. Connector Loss
- Max. Connector Loss
- Min. Connector Reflectance
- Max. Connector Reflectance
- Restore Default

Note: During manual sorting, if the files are not adjacent, you need to group them by pressing **Ctrl+G**.

When you have sorted one of the tabs, you can apply the same sorting criteria to the two other tabs. This is particularly useful to send your criteria to the **Matched Files** tab, since it is used to determine the order in which the files appear in your reports.

Viewing and Editing Measurements

Viewing and Sorting Files or Measurements

To apply sorting to other windows:

1. Select the files in the **Files** window or measurements in the Measurements window.
2. Right-click and select **Apply sort to other windows**.

If you have sorted the files, click  to apply the sorting to the **Measurements** and **Matched Files** tab. If you have sorted the measurements, click  to apply the sorting to the **Files** and **Matched Files** tab.

Note: *When files in the **Matched Files** tab are not of the same type and the sorting is based on the **Files** or **Measurements** tabs, it may be possible that the sorting is not exactly the same, as priority is granted to file type and priority.*

Saving Measurement Files

You can save the changes you make to selected measurement files or to all measurement files in the current project.


When saving several files at a time, you can set an automated naming pattern so that they all follow the same naming scheme. Depending on the type of files you are saving, different items will be available in the window.

To save selected measurement files:

1. In the **Files** tab, select the file or files that you want to save.
2. On the **File** menu, click **Save Selected Files**.

To save selected measurement files under a different name:


1. In the **Files** tab, select the files that you want to save.
2. On the **File** menu, click **Save Selected Files As**.
3. Select the location for your files.




Viewing and Editing Measurements

Saving Measurement Files


4. Select whether you want to use the original file names, or if you want to use the file documentation elements. If you are using the original file names, go to step 9. Otherwise, proceed as instructed below.




5. If your files are in OTDR format, you can select a different format to which to save the files.



6. Select which items you want to include in the name. You can change the order of the items using the arrow buttons.




7. Select the type of character you want to use as a separator between the items.



Viewing and Editing Measurements

Saving Measurement Files

8. If you have selected to add a custom field to the file name, you can enter the value you want in the corresponding box.



9. Click **Save** to confirm your action.

Note: *PMD files will be saved with the .pmdb extension, ConnectorMax files will be saved with the .cmax2 extension, and OLTS files will be saved with the .oltsx extension.*

To save all files:

On the **File** menu, click **Save All**. All measurement files in the current project and the project file are saved.

Using the Identifiers View

Another way to filter and sort your measurements can be according to the identifiers included in them. These identifiers are displayed in a tree view where you can expand or collapse results for easier management and viewing purposes. When you click on a specific part of the tree view, the resulting files are displayed in a table on the right of the tree. This table behaves like the **Measurement** tab and allows you to perform the same actions regarding sorting and selection.

The screenshot shows the 'Identifiers' window. On the left is a tree view with a 'Pass/fail status' column. The tree is organized into 'Parent node' and 'Child node' levels. The right pane shows a table of measurements for the selected identifier 'iOLM'.

P/F	Identifiers	Type	Direction	Link loss (850 n	Link loss (1300 L
✓	FAB0001; J	iOLM BDR	Bidir		
✓	FAB0002; J	iOLM BDR	Bidir		
✓	FAB0003; J	iOLM BDR	Bidir		
✓	FAB 004; Jk	iOLM BDR	Bidir		
✓	FAB 001	iOLM	A->B		
✓	FAB 002	iOLM	A->B		
✓	FAB 003	iOLM	A->B		
✓	FAB 004; Jk	iOLM	A->B		
✓	FAB 005	iOLM	A->B		

The identifier information used to sort the measurements are found under their respective **Identification** tabs. Each identifier down the list in the table creates a node in the tree. The identifiers used for matching the files are those you have selected as active in your project settings. See *Matching Files* on page 51 for more information.

Viewing and Editing Measurements

Using the Identifiers View

The items in the tree view also show pass/fail icons so that you can quickly see if there are problems for specific measurements.

You can regroup identifiers, rename them, and move the measurements within the tree to assign new identifiers to them. The identifiers used in the list

To show and select measurements:

1. From the main window, select the **Identifiers** tab.
2. Select the item you wish to view in the tree. All measurements on this node, as well as those in the children nodes are displayed in the table on the right. The identifiers used in the tree view are shown in a column, you can therefore sort the results using this criterion.

You can select more than one node using the Ctrl key. The multiple selection will work for nodes at the same level, with the same parent.

Note: *You can sort the measurements in the table as you would in the **Measurements** tab. See Viewing and Sorting Files or Measurements on page 332.*

To move measurements within a same branch:

1. Click on the node or measurements to select them.
2. Drag them to the desired node. The information will be updated automatically.



IMPORTANT

The identifier information previously contained in the files you are moving will be replaced with the identifier information of the new node.

3. Confirm the move.

To change the identifiers of all measurements in a specific node:

- 1.** In the tree, select the node that you want to change by right-clicking on it.
- 2.** Select **Rename**.
- 3.** Enter the desired new name.

The values in the **Identification** tab are changed for each measurements and the nodes are updated according to the new name.

13 **Generating, Previewing and Printing Reports**

FastReporter 2 can print and generate three types of reports:

- *Measurement report:* This type of report contains one measurement type and one measurement at a time.
- *Summary report:* This type of report combines different measurements or several measurements of the same type.
- Reports as they are presented when using the OTDR, iOLM, OLTS and FIP applications.

The following options are included in measurement and summary reports:

Property or Element	Option
Tools properties	Distance units
OTDR properties	Pulse baseline Events calculation and thresholds Numeric values precision Pass/Fail thresholds Macrobend tolerances
OPM, PPM, iOLM, OLTS, FIP, CD, and PMD properties	Pass/Fail thresholds
Data graph	Zoom

If you want to include other options in a report, you must modify the associated report template using Crystal Reports. For more details, see *Creating and Modifying Report Templates* on page 358. You can modify the report using Excel template. For more details, see *Using Excel Report Templates* on page 361.

For examples of the reports that you can generate with FastReporter 2, see *Report Samples* on page 431.

Generating, Previewing and Printing Reports

Generating Measurement or Summary Reports (FR2-FC Mode)

Generating Measurement or Summary Reports (FR2-FC Mode)

You can easily generate a variety of reports in either electronic format or print them out for later consultation (see *Printing Summary or Measurement Reports* on page 350 for details on printing).

FastReporter 2 can generate reports in the following formats:

File Type	Application
*.xls, *.xlsx	Microsoft Excel
*.pdf	Adobe Reader
*.html	Any Web browser


Note: *The Crystal Reports (PDF format) have a limited the number of measurements that you can include which changes depending on the files you are including. For reports including larger amounts of files, use an Excel template. You will be notified if the number of files in the report exceeds what the format (or FastReporter 2 itself) can handle.*

Generating, Previewing and Printing Reports


Generating Measurement or Summary Reports (FR2-FC Mode)

To generate a report:

1. Select measurements or files in the **Measurements** or **Files** tabs.
2. On the **Tools** menu, click **Report**.
3. If needed, select the location where to save the report.




4. In the **Template** list, select a report template.



Generating, Previewing and Printing Reports

Generating Measurement or Summary Reports (FR2-FC Mode)

5. You can have the report generated in one file, or multiple files depending on the number of rows or matched groups present in the window. To separate the report into multiple files, select the corresponding option.



6. If you select a multiple-file report, select how the files are named:
 - *Identifiers*: the identifier present in the measurement
 - *Original Measurement Filename*: the measurement file name.

Note: If you clear the **Generate individual report files** option, the **Launch report viewer** option is automatically selected.


Note: If you want to generate the report for more than one measurement files, the list of measurement files involved in the group of matched measurements is displayed in the **Select Report Filename** window.

7. Select whether you want to generate the file name based on the measurement, or if you want to enter a customized name.

Generating, Previewing and Printing Reports


Generating Measurement or Summary Reports (FR2-FC Mode)

- Depending on your choice, select the file name from the list, or enter it directly.



- Click **OK** to close the window.


- Enter a name for the report.



Generating, Previewing and Printing Reports

Generating Measurement or Summary Reports (FR2-FC Mode)

11. In the **File Type** list, select whether you want to save the report as a PDF, html, or Excel file.



Note: By default, the file type is selected as Excel (*.xls) when you run the application for the first time. The templates displayed on-screen depend on the file type you have selected.



IMPORTANT

You should always enable macros in Microsoft Excel before generating the report in that format. Refer to the Excel help for information on how to enable macros.

12. Click **OK**.

Note: The application retains the last selected used file type and report template when you restart the application.


Previewing Summary or Measurement Reports

You can view your reports on-screen before you print them.

Note: *The print preview function is only applied on the reports created using the Crystal Report templates.*

To preview a report:

1. Select measurements or files in the **Measurements** or **Files** tab.
2. On the **File** menu, click **Print Preview**.
3. In the **Select Template File** dialog box, select a report template.



4. Click **OK**.

In the print preview window, click  -, and select a zoom option from the list, if desired.

To select a different summary report template, click , and select a template in the **Select Template File** dialog box.

5. To close the **Print Preview** window, click **Close**.

Note: *Only the Crystal report templates are visible during print preview and print.*

Generating, Previewing and Printing Reports


Printing Summary or Measurement Reports

Printing Summary or Measurement Reports

FastReporter 2 allows you to print your reports for future consultation.

To print a measurement report:

1. Select measurements or files in the **Measurements** or **Files** tab.
2. On the **File** menu, select **Print**.
3. If needed, change the printer or printer settings.
4. Select a measurement report template.



5. Click **OK**.


Generating Application-Related Reports

Generating reports such as you would see on the OTDR, iOLM, OLTS and FIP applications is done in a similar manner. The reports can be generated in PDF, XML or Mhtml formats.

Note: *OLTS reports are available in PDF format only.*

To generate an application-related report:


1. From the main window, select the **Tools** menu, then **OTDR, iOLM, OLTS** or **FIP**.
2. Select the corresponding Generate Application Report in the sub-menu.
3. Select whether you want to put the report in the same location as the source files, or select a new location.




Generating, Previewing and Printing Reports

Generating Application-Related Reports

4. Select the format you want to use to generate the report.



5. Select the items to include in the report. The list of available items will vary depending on the application you have selected.



6. Click **OK** to generate the report.

Using the Clipboard (FR2-FC Mode)

You can copy and paste the measurement graph from FastReporter 2 into other applications. For example, you can paste a graph into an e-mail message, or applications such as Microsoft Excel for use in existing measurement reports.

To use the clipboard:


- 1.** Click on the graph in FastReporter 2.
- 2.** On the **Edit** menu, click **Copy**.
- 3.** Switch to the application you want to paste the graph into (e-mail client, spreadsheet, word processing application, etc.).
- 4.** Place the mouse pointer where you want to insert the graph and, on the application's **Edit** menu, click **Paste**.

Importing and Exporting Templates


You can import existing templates you have elsewhere, or export them to other locations easily.

To import a template:


1. From the **Tools** menu, select **Reports**.
2. Navigate to the desired location, then click **Import**.




3. Click  to access the file location.



4. Browse to the current location of the template, then select it. You may have to change the file filter at the bottom of the window to see the appropriate format.



5. Click **Open**.
6. If desired, rename the template. If you want to add a specific folder name for your report, use the corresponding button.




7. Click **Import**. The new template is now available.

Generating, Previewing and Printing Reports

Importing and Exporting Templates


To export a template to another location:

1. From the **Tools** menu, select **Reports**.
2. Select which report you want to export, then click **Export**.



Note: *The name of the report automatically bears the word Copy to prevent unintentional overwrites.*

3. Select the location where you want to export the file. If needed, you can use the **New Folder** button to add a folder to suit your needs.



4. Click **Save**.

Creating and Modifying Report Templates

You can create a new report template, or to modify an existing report template using the Crystal Reports application. Excel reports are also customizable. For details on using Crystal Reports, refer to your Crystal Reports product documentation. For details on using Excel template, see *Using Excel Report Templates* on page 361.

To create a new report template, EXFO recommends that you start with an existing FastReporter 2 report template and modify it as required. This way you will have access to the database fields for populating the report with measurement data. Once you are done, save it using a different name that suits your testing needs.

To access the available report templates:

Select the **File** menu, then **Print Preview**.

OR

Select the **File** menu, then **Print**.

OR

Select the **Tools** menu, then **Report**.

Using Crystal Report Templates

Using Crystal report templates you can modify the PDF and HTML report templates.

You can access the Crystal report template from
C:\ProgramData\EXFO\FastReporter 2\<version>\English\ReportTemplate.

To modify a PDF or HTML report template:

- 1.** Start Crystal Reports.
- 2.** On the **File** menu, click **Open**.
- 3.** On the **Open** dialog box, select and open the folder containing the report template you wish to modify.
- 4.** Select a report template and click **Open**.
- 5.** On the **File** menu, click **Save As**.
- 6.** Type a new name for the report. This will preserve the original FastReporter 2 report templates.
- 7.** Modify the template by modifying or adding labels, header and footer information, company logo, etc.
- 8.** Add fields to the report as needed by selecting them from the **Field Explorer** window.
- 9.** Once you have finished modifying the report, click **Save** on the **File** menu.

Generating, Previewing and Printing Reports

Using Crystal Report Templates

To add a report template to the list of available templates:

Save the template directly in the appropriate folder within the Report Template folder after you have modified it in Crystal Reports.

OR

Move the template into the appropriate folder within the Report Template folder so that it will be available on the **Select Template File** dialog box.

You can also create your own folders and subfolders within the Report Template folder to organize your report templates.

To remove a report template from the list of available templates:

In Windows Explorer, remove the files from the folder where it is located, either by copying it elsewhere, or by deleting it.

Using Excel Report Templates

The default templates installed in FastReporter 2 are stored in
 C:\ProgramData\Exfo\FastReporter 2\<Version>\English\ReportTemplate

Each template has two sheets:

- A configuration sheet where you can select different tag settings for the report.
- A sheet with the actual report with all the “tags” that are used to generate the required report.

63	B	48.0062	1.894	2 p
64	b	64.0100	4.437	A-I
65	B-A	16.0012	17.744	3 p
66				3 p
67				A-I
69	Pass/Fail Thres			
70	Threshold	Fail	Warning	
71	Splice loss (dB)	1.000	1.000	
72	Connector loss (dB)	1.000	1.000	
73	Reflectance (dB)	-40.0	-40.0	
74	Fiber sect. att. (dB/km)	0.400	0.400	
75	Span loss (dB)	45.000	45.000	
76	Span length (km)	0.0000	0.0000	
77	Span ORL (dB)	15.00	15.00	

Configuration
selection

Report selection

Using the Configuration Sheet

The configuration sheet contains three parts.

- Flags
- Sheet Details
- Filter Details

Flags are used to specify to Excel how to handle specific behavior as well as data display. By default, you have access to two different flag settings, Apply Thresholds and Cell Merging. These flag settings are visible in the **Configuration** sheet. The table below contains details for each flag setting.

Setting	Purpose	Note
Apply Thresholds	Apply pass/fail thresholds from FastReporter 2, that is change font and background color used in the application.	True = will use threshold from FastReporter 2 False = no threshold applied. It can use conditional formatting from Excel.
Cell Merging	Merges cells with matched records. For example, if the FiberID is the same for 3 measurements, they are merged into a single cell.	To improve the performance, this option is always set to "False" in all the report templates, except in the FiberCharacteration template. This should be set to "True" when extra processing is done with Excel's Pivot table.

Some non-mandatory, or supportive flags, are hidden. One or more can be added as needed.

Note: *If the Excel sheet contains only an Image tag in cell A1, and that cell is merged with other cell, then the image will not be displayed in the report.*

Note: *The setting name should be written in one block without spaces. They have been separated on more than one text line in the table below for readability purposes only.*

Setting	Purpose	Default Value
DisplayOnlyMatched Measurements	To specify if only the data common to both matched measurements is to be displayed. For example, if you match two measurements containing common and different wavelengths (measurement one has 1310, 1550 and 1625, while measurement two has 1310, 1410 and 1625), and the setting is set to true, the report data is displayed for every distinct wavelength.	FALSE
DisplayGraphPer Measurement	To specify if a graph should be displayed for each trace in the measurement, or if all measurements are to be displayed in a single graph.	FALSE
MeasurementPerSheet	Maximum number of measurements allowed per sheet. A blank value indicates that there is no limit.	Blank
WavelengthPerSheet	Maximum number of wavelengths allowed per sheet. A blank value indicates that there is no limit.	Blank
MeasurementTypes	To specify which measurement type should be supported. A blank value indicates that it supports all measurement types.	Blank

Generating, Previewing and Printing Reports

Using Excel Report Templates

Setting	Purpose	Default Value
FillOnlyMatched Wavelengths	To display data of common wavelengths. Used when data is coming from different origins and common wavelengths needs to be displayed. For example, if your report includes iOLM, OTDR and FIP files, The iOLM wavelengths are treated first, then only the OTDR files with matching wavelengths.	FALSE
FillMatchedOLM Measurements InSingleRow	To display the details from two different iOLM files with different directions in a single row.(Used in iOLM cable summary reports).	FALSE
MergeAllSheets InSingleSheet	To merge all sheets into the first sheet.	FALSE
MergeSheets ByIdentifier	To merge sheets with the same identifiers.	FALSE

The *sheet details* are used to specify if multiple sheets should be inserted. This table is not mandatory and is hidden by default.

Once the SheetDetails table is displayed, you need to specify the fields below to insert multiple sheets:

- **SheetName:** to specify the name of the sheet for which multiple sheets are inserted. If you rename a sheet, you must also change it in the sheet details to make sure that you generate multiple sheets in the report.
- **AddMultipleSheets:** to specify if multiple sheets should be inserted.
- **Tables (optional):** to specify which tables are used in a particular sheet.
- **PrimaryTable:** to specify the table from which you have to use distinct values and add multiple sheets for each value.
- **PrimaryColumn:** to specify the column name from the Primary table. A new sheet is inserted for each distinct value of the PrimaryColumn.

Filter details are used to specify filter criteria. This is not mandatory, and should be used when filters are required. Filter details are not hard coded. You can specify the required filters; to do so the FilterDetails table must be present in the report template.

The FilterDetails table is divided into three columns:

- SheetName
- Range
- Filters

	SheetName	Range	Filter
20	Fail Report	\$A\$3:\$F\$3	OTDREventTable.IsEvent
21	Fail Report	\$A\$5:\$F\$5	OTDREventTable.IsEvent
22	Fail Report	\$A\$7:\$F\$7	OTDREventTable.IsEvent
23	Fail Report	\$A\$12:\$F\$12	OTDREventTable.IsEvent
24	Fail Report	\$A\$14:\$F\$14	OTDREventTable.IsEvent
25	Fail Report	\$A\$16:\$F\$16	OTDREventTable.IsEvent
26	Fail Report	\$A\$21:\$F\$21	OTDREventTable.IsEvent
27	Fail Report	\$A\$23:\$F\$23	OTDREventTable.IsEvent
28	Fail Report	\$A\$25:\$F\$25	OTDREventTable.IsEvent
29	Fail Report	\$A\$30:\$F\$30	OTDRSummary.SpanLoss
30	Fail Report	\$A\$32:\$F\$32	OTDRSummary.SpanLoss
31	Fail Report	\$A\$34:\$F\$34	OTDRSummary.SpanLoss
32	Fail Report	\$A\$39:\$F\$39	OTDREventTable.IsEvent
33	Fail Report	\$A\$41:\$F\$41	OTDREventTable.IsEvent
34	Fail Report	\$A\$43:\$F\$43	OTDREventTable.IsEvent
35	Length	\$A\$6:\$D\$6	OTDREventTable.IsEvent
36	Loss	\$A\$3:\$E\$3	OTDREventTable.IsEvent
37	Splice and reflectance	\$C\$1:\$E\$8	OTDREventTable.IsEvent


The *sheet name* is used to specify the sheet name for which you want to apply a filter. If you rename the sheet, you must change the name accordingly in the FilterDetails table for it to be identified correctly and apply the filters.

Note: *It is not mandatory to specify sheet names if no filters are applied on that sheet.*

Generating, Previewing and Printing Reports

Using Excel Report Templates

One sheet can have multiple filters.



Failed Splice Loss					
Fiber ID	Event Number	Loss (dB)	Direction	Wavelength (nm)	Comments
SSIdentification.FiberID	EventNumberSSOTDREventTable.EventNumber	EventLossAtoBSSOTDREventTable.EventLossAtoB	A->B	Details.WavelengthSSOTDREventTable.EventWavelength	SSOTDREventTable.EventCommentAtoB
SSIdentification.FiberID	EventNumberSSOTDREventTable.EventNumber	EventLossBtoASSOTDREventTable.EventLossBtoA	B->A	Details.WavelengthSSOTDREventTable.EventWavelength	SSOTDREventTable.EventCommentBtoA
SSIdentification.FiberID	EventNumberSSOTDREventTable.EventNumber	EventLossSSOTDREventTable.EventLoss	SSOTDREventTable.EventDirection	Details.WavelengthSSOTDREventTable.EventWavelength	SSOTDREventTable.EventCommentSSOTDREventTable.EventComment

The *range* indicates the address of the first cell and last cell for which you want to apply the filter, separated by a colon. The range must exactly match the range in the sheet; if you specify a filter range of \$A\$3:\$C\$3 and the actual range in the FilterDetails table is \$A\$3:\$F\$3, the formula is not applied because they are not considered as matching.

The *filters* are to specify conditions and support the AND and OR operators. You need to provide TableName.FieldName as a field. For example, OTDREventTable.IsEvent=true AND OTDREventTable.IsEventReflective=true AND OTDREventTable.EventLossAtoBPassFailStatus='Fail'.

An additional sheet is available, the *Table sheet*. The Table sheet is generated by a macro when a template is saved. It contains information on different tags present in the template and it will be used to generate the appropriate data set (result values) needed for the report.

By default, this sheet is hidden. To view it, right-click on the name of the active sheet and select **Unhide**, then select **Table** and click **OK**.

Note: To create a new template, you must start from an existing template. Otherwise the Table sheet will not be created and the template will not work, as FastReporter 2 will not be able to generate the dataset needed.

Note: Since the Table sheet is generated using a macro, you must enable macros to modify it.

	A	B	C	D
1	SheetName	TagType	Value	Address
2	Cable Information	SingleCell	<<Identification.TestDate>>	\$B\$2
3	Cable Information	SingleCell	<<OTDRSummary.FiberType>>	\$B\$3
4	Cable Information	SingleCell	<<Identification.NumberOfFiber>>	\$B\$4
5	Cable Information	SingleCell	<<Identification.OperatorA>>	\$B\$6
6	Cable Information	SingleCell	<<Identification.LocationA>>	\$B\$7
7	Cable Information	SingleCell	<<Identification.OperatorB>>	\$B\$8
8	Cable Information	SingleCell	<<Identification.LocationB>>	\$B\$9
9	Cable Information	SingleCell	<<Identification.LocationAUnitMode>>	\$B\$13
10	Cable Information	SingleCell	<<Identification.LocationBUnitMode>>	\$C\$13
11	Cable Information	SingleCell	<<Identification.LocationAUnitSerial>>	\$B\$14
12	Cable Information	SingleCell	<<Identification.LocationBUnitSerial>>	\$C\$14
13	Cable Information	SingleCell	<<Identification.LocationACalibratio>>	\$B\$15
14	Cable Information	SingleCell	<<Identification.LocationBCalibratio>>	\$C\$15
15	Measurement Information	SingleCell	Pulse (<<OTDRSettings.PulseUnit>>)	\$B\$2
16	Measurement Information	SingleCell	Span Length (<<GeneralSettings.DistanceUnit>>)	\$L\$10
17	Measurement Information	MultiRow	\$\$OTDRSummary.Wavelength\$\$	\$A\$3
18	Measurement Information	MultiRow	\$\$OTDRSummary.Pulse\$\$	\$B\$3
19	Measurement Information	MultiRow	\$\$OTDRSummary.IOR\$\$	\$C\$3
20	Measurement Information	MultiRow	\$\$OTDRSummary.Backscatter\$\$	\$D\$3
21	Measurement Information	MultiRow	\$\$OTDRMacro BendTolerances.Wavelengthpair\$\$	\$A\$7
			\$\$OTDRMacro BendTolerances.Tole	

The *Report sheet* is where you can define how you want the output (the report) to look like. The report sheet will contain different **FieldName** tags.

Field Name tags are the combination of **TableName** and **ColumnName**. (**TableName.ColumnName**), for example, **Identification.FiberID**. You should use the field names from the Universal sheet. For more information, see *Using the Universal Sheet* on page 374.

Generating, Previewing and Printing Reports

Using Excel Report Templates

You have to provide special prefixes and suffixes to the field name while designing templates. These prefixes and suffixes are used to perform the data insertion, and determine whether data should be filled in a single cell, if multiple rows should be inserted, or a block should be repeated.

Tags are categorized in five groups:

- Single Cell
- Multi Row
- Multi Column
- Block
- Image

The *single cell* tag organizes data in a single cell. If multiple values are available, they are separated by a semicolon. The prefix for this tag is <<, and the suffix is >>.

Example: <<Identification.TestDate>>

The screenshot shows an Excel spreadsheet with a header row containing the text "Identification Information". Below the header, there are six rows of data. Each row contains a label followed by a value enclosed in double angle brackets (<< and >>). The labels and their corresponding values are: "Filename: <<Identification.FileName>>", "Cable ID: <<Identification.CableID>>", "Test date: <<Identification.TestDate>>", "Fiber ID: <<Identification.FiberID>>", "Test time: <<Identification.TestTime>>", "Customer: <<Identification.Customer>>", "Job ID: <<Identification.JobID>>", "Company: <<Identification.Company>>", and "Comments: <<Identification.Comments>>".

Excel template

The screenshot shows the same Excel spreadsheet as above, but with the data fields populated with actual values. The values are: "1310_1550_40km.trc" for Filename, "0006" for Cable ID, "2007-03-28" for Test date, "0014" for Fiber ID, "10:25 (GMT-05:00)" for Test time, "EXFO" for Customer, "239498" for Job ID, and "TechExpert" for Company. The "Comments" field is empty.

Output in the report

Generating, Previewing and Printing Reports

Using Excel Report Templates

The *multi-row* tag inserts multiple rows in Excel. For example, if one file has three measurements, three rows are inserted. The prefix for this tag is \$\$, and the suffix is \$\$.

Example: \$\$OTDRSummary.Wavelength\$\$

Fiber ID	Wavelength (nm)	Connector A		Connector B	
		A->B (dB)	B->A (dB)	A->B (dB)	B->A (dB)
2	1310	-41.9	-45.9	-45.9	-42.0
2	1550	-42.1	-45.5	-45.4	-41.9
3	1310	-42.1	-45.8	-45.8	-42.2
3	1550	-42.1	-45.6	-45.6	-42.1

Excel template

FiberID	Wavelength (nm)	A->B (dB)	B->A (dB)	A->B (dB)	B->A (dB)
2	1310	-41.9	-45.9	-45.9	-42.0
2	1550	-42.1	-45.5	-45.4	-41.9
3	1310	-42.1	-45.8	-45.8	-42.2
3	1550	-42.1	-45.6	-45.6	-42.1

Output in the report

The multi-column tag is used to process one single tag at a time. It does NOT insert new columns, but rather uses the existing columns. While designing the template, you should make sure that there are enough empty columns available after the Multi Column tag. If not, it will overwrite existing data.

The prefix for this tag is {{ and the suffix is }}.

Example, {{OTDRSummary.Wavelength_FiberSize}}

34					iO
36				{{iOLMThreshol	
37	Max. link loss (dB)			{{iOLMThresholds	
38	Min. link loss (dB)			{{iOLMThresholds	
39	Max. splice loss (dB)			{{iOLMThresholds	
40	Max. connector loss (dB)			{{iOLMThresholds	
41	Reflectance (dB)			{{iOLMThresholds	

Excel template

		1310 nm	1550 nm	
36				
37	Max. link loss (dB)	45.000	45.000	Max.
38	Min. link loss (dB)	0.000	0.000	Min.
39	Max. splice loss (dB)	1.000	1.000	
40	Max. connector loss (dB)	1.000	1.000	
41	Reflectance (dB)	-40.0	-40.0	
42				
44				iOLM RPP

Output in the Report

Generating, Previewing and Printing Reports

Using Excel Report Templates

The *Block* tag contains several other tags. It indicates a structure such as that of the Event table, where you insert rows and columns. Only one block tag group should be specified per sheet.

Note: *These tags are supported for the OTDR Event table and iOLM Element and Section tables.*

The prefix for the block tag is ##, and the suffix is ##.

The prefix for inserting rows is [, and the suffix is]].

The prefix to insert column blocks is [[##, the suffix is ##]].

81				
82	Element Type	Position /Length (<<GeneralSettings.DistanceUnits)	Loss (dB)	[[iOLMElement
83				
84	##iOLMElementsSectionData	##iOLMElements	[[##iOL	
86				

[[prefix and]] suffix to specify field for which column should be inserted.

[[##prefix and ##]] suffix to specify fields for which values should be filled for multiple rows and columns.

To add multiple blocks, such as for the iOLM element and section table, add a + sign between the prefix/suffix and the tag.

For example, adding a second block would look like this: [[+##tag##+]]

Adding a third block would look like this: [[++##tag##++]]

You do not need to add a + sign to add a row, as the number of rows will remain the same in the case of multiple blocks.

iOLM Table								
Element Type	Position /Length (km)	Loss (dB)	Loss (dB)	Refl. (dB)	Refl. (dB)	Att. (dB/km)	Att. (dB/km)	Diagnostic
		1310 nm	1550 nm	1310 nm	1550 nm	1310 nm	1550 nm	
Connector (A)	0.0000	1067	0.950	-82.0	-72.5			The fiber under test is not properly connected
Section	0.4031	---	0.091			---	0.226	
Splice	0.4031	---	2335					Make sure that the fiber is properly spliced.
Section	0.1018	0.043	0.049			0.425	0.460	
Splitter 1:32	0.5049	17320	16146		-86.9			
Section	17.065	0.445	0.367			0.261	0.213	
Connector (B)	22.114	---	---	-64.3	-64.2			To characterize loss and include the element

Required Report format

To add blocks for loss, reflectance and attenuation, you have to add blocks for each wavelength. Fill the loss values first (insert a separate column for each wavelength), then reflectance and then attenuation.

	A	B	C	D	E	F	G	H	I	K	M	O
83	Element Type	<<GeneralSettings.DistanceUnit	/Length	[[iOLMElementsSectionDetails.Wavelength]]	(dB)	[[+iOLMElementsSectionDetails.Wavelength]]	(dB/km)	[[++iOLMElementsSectionDetails.Wavelength]]	Diagnostic			
84	###iOLMElementsSectionDetails.Type##	###iOLMElementsSectionDetails.Type##	[[#iOLMElementsSectionDetails.Type##]]	[[++iOLMElementsSectionDetails.Type##]]	###iOLMElementsSectionDetails.Type##							
86												

As mentioned in the figure above, for loss the tag is

- `[[iOLMElementsSectionDetails.Wavelength]]` - To add columns
- `[[#iOLMElementsSectionDetails.ElementLoss##]]` - To add data row and column wise.

For the next block, you have to use the + sign. The next block tag will look like:

- `[[+iOLMElementsSectionDetails.Wavelength+]]`
- `[[++iOLMElementsSectionDetails.ElementReflectance##+]]`

To add one more block for attenuation, you have to add two + signs. The next block tags will look like:

- `[[++iOLMElementsSectionDetails.Wavelength++]]`
- `[[+++iOLMElementsSectionDetails. SectionAttenuation##++]]`

Generating, Previewing and Printing Reports

Using Excel Report Templates

In the case of multiple tags in a single cell, since the tag related to the loss of an event/element or a section are not the same, you need to put the two possibilities.

Lippooara		Font		Alignment		Number								
F84		fx		[[##IOLMElementsSectionDetails.ElementLoss##]]		[[##IOLMElementsSectionDetails.SectionLoss##]]								
A	B	C	D	E	F	G	H	I	K	M	O	P	Q	R
Element Type			/Length	{<<GeneralSettings.DistanceUnit	[[IOLMElementsSectionDetails.Wavelength]]	(dB)	(dB/km)	Diagnostic						
83						[[+IOLMElementsS	[[++IOLMElem							
84	##IOLMElementsSectionData			##IOLMElements	[[##IOLMElement	[[+##IOL_n##++]]	##IOLMElementsSectionD							
86														

Lippooara		Font		Alignment		Number									
F84		fx		[[##IOLMElementsSectionDetails.ElementLoss##]]		[[##IOLMElementsSectionDetails.SectionLoss##]]									
A	B	C	D	E	F	G	H	I	K	M	O	P	Q	R	S
Element Type			/Length	{<<GeneralSettings.DistanceUnit	[[IOLMElementsSectionDetails.Wavelength]]	(dB)	(dB/km)	Diagnostic							
83						[[+IOLMElementsS	[[++IOLMElem								
84	##IOLMElementsSectionData			##IOLMElements	[[##IOLMElement	[[+##IOL_n##++]]	##IOLMElementsSectionD								

Since there is only one possibility for the reflectance, you simply have to put the corresponding tag.

G84		fx										
		[[+##OLMElementsSectionDetails.ElementReflectance##+]]										
	A	B	C	D	E	F	G	H	I	K	M	O
	Element Type			/Length	[[iOLMElements	(dB)	(dB/km)	Diagnostic				
83	(<<GeneralSetti			ngs.DistanceUni	SectionDetails.	Wavelength]]	[[+iOLME	[[+iOL				
84	##iOLMElementsSectionData			##iOLMElements	[[##iOLMElement	[[+##iOL	##iOLMElementsSectionD					

The *image* tag uses ((as a prefix, and)) as a suffix.

Example: ((iOLMGraph.GraphFromApplication))

To modify an Excel report template:

1. Access the Excel report templates folder.
2. Create a copy of the report template that you want to modify.
3. Open the duplicate report template with Microsoft Excel.
4. Add new column information using the {{Tag}}. Refer to the Universal sheet for the list of supported tags. You can remove a column by deleting the cell contents.
5. Add new row information using the \$\$Tag\$\$\$. Refer to the Universal sheet for the list of supported tags. You can remove the row information by deleting the cell contents.
6. Change the logo using the header/footer option in Microsoft Excel.

Note: For more information on the Universal sheet, see Using the Universal Sheet on page 374.

Using the Universal Sheet

The universal sheet provides the list of tags for different fields used in FastReporter 2. You can use these tags to create custom report templates for the fields such as GeneralSettings, MatchedFilesDetails, CustomIdentifier, Identification etc. related to the OTDR, iOLM, OLTS, CD, PMD, OPM/PPM, and FIP measurements. You can copy the supported tags, which are highlighted in green, to customize your Excel report template.

You can access the universal sheet from C:\ProgramData\Exfo\FastReporter 2\<version>\ReportTemplate.

14 Using FastReporter 2 Tools

Tools are available to help you better manage your data:

- Data transfer tools
- Related analysis tools

To start a data transfer application:

On the **Tools** menu, select **Data Transfer**, and select the application associated with the handheld unit to or from which you want to send or receive data.

Note: *Data transferred from a handheld unit is not automatically added to your FastReporter 2 project. The files will be stored on your computer and you need to add them to your project using one of the methods described in Adding and Removing Measurement Files on page 43.*

The corresponding application opens. Refer to the user documentation corresponding to the selected data transfer application for details.

To start an analysis tool:

1. Select the measurement in the **Measurements** tab.
2. On the **Tools** menu, click **Start Related Analysis Tool**.

Note: *If you modify the measurement file in the related analysis tool, FastReporter 2 will ask you if you want to reload the file.*

The corresponding application opens. Refer to the user documentation corresponding to the data analysis application you have selected for more details.


Setting a Reference File or Measurement (FR2-FC Mode)

A reference file is used to compare fibers within the same cable, monitor fiber deterioration or compare fibers before and after installation. Once a measurement file has been added to a project, you can set it as a reference file. The reference file can then be used to automatically document other measurement files (see *Automatically Documenting Measurement Files (FR2-FC Mode)* on page 378).

For supported OTDR file formats, FastReporter 2 will display the reference measurement, in red, in the Event Table. The reference measurement can then be applied as a template (see *Setting and Applying OTDR/OTDR Bidir Reference as Template (FR2-FC Mode)* on page 166). You can set a file as a reference if the file format supports applying a reference as a template.

To set a reference measurement:

1. In the **Measurement** window, select the file.
2. In the event table, right-click on the measurement in the **Fiber ID**, **P/F**, **Wavelength** or **Dir.** column, and select **Set as Reference** on the shortcut menu.



To set a reference file:

1. In the **Files** window, select the file.
2. On the **Files** menu, click **Set as Reference File**.


Automatically Documenting Measurement Files (FR2-FC Mode)

The auto documentation feature can be used to copy selected identification information from a reference file to selected files. You can also use this feature to automatically assign fiber IDs to selected files.

Note: *The auto documentation tool is available even if no reference file is defined; in that case, you cannot copy reference file information to files, but you can assign fiber IDs automatically if your selected files contain at least one fiber ID identifier.*

To use the auto documentation feature:

1. In the **Files** window, select the file that will serve as the reference file.
2. From the **File** menu, click **Set as Reference File**.
3. In the **Files** window, select the files to which you want to export the information.




4. From the **Tools** menu, click **Auto Documentation**.

Using FastReporter 2 Tools

Automatically Documenting Measurement Files (FR2-FC Mode)

- To copy items from the reference trace to your selected file, enable the corresponding option, then select the desired items.



The file information options listed are the identifiers included in the reference file and will differ depending on the file type.

- Select whether you want to copy the fiber IDs or all of the identifiers for all the files.

Auto Documentation

Copy reference file information to selected files

- Job ID
- Customer
- Company
- Operator A
- Operator B
- Comments

Assigning identifiers automatically

Fiber ID All Identifiers

Prefix: Fiber Suffix: 0001

Number of digits: 4

Increment: 1

Identifiers	Values	Auto Increment	Start	Stop	Step	Sequence
<input checked="" type="checkbox"/> Cable ID		<input checked="" type="checkbox"/>	1	10	1	1;2;3;4;5;6;7;8;9;10
<input checked="" type="checkbox"/> Fiber ID	Fiber0003	<input checked="" type="checkbox"/>	1	10	1	Fiber00031;Fiber0003
<input checked="" type="checkbox"/> Location A		<input checked="" type="checkbox"/>	1	10	1	1;2;3;4;5;6;7;8;9;10
<input checked="" type="checkbox"/> Location B		<input checked="" type="checkbox"/>	1	10	1	1;2;3;4;5;6;7;8;9;10
<input type="checkbox"/>		<input type="checkbox"/>				

OK Cancel

- If you are copying the fiber IDs, enter a prefix and suffix, and select the number of digits and increment value to use.

Auto Documentation

Copy reference file information to selected files

- Job ID
- Customer
- Company
- Operator A
- Operator B
- Comments

Assigning identifiers automatically

Fiber ID All Identifiers

Prefix: Fiber Suffix: 0001

Number of digits: 4

Increment: 1


Identifiers	Values	Auto Increment	Start	Stop	Step	Sequence
<input checked="" type="checkbox"/> Cable ID		<input checked="" type="checkbox"/>	1	10	1	1;2;3;4;5;6;7;8;9;10
<input checked="" type="checkbox"/> Fiber ID	Fiber0003	<input checked="" type="checkbox"/>	1	10	1	Fiber00031;Fiber0003
<input checked="" type="checkbox"/> Location A		<input checked="" type="checkbox"/>	1	10	1	1;2;3;4;5;6;7;8;9;10
<input checked="" type="checkbox"/> Location B		<input checked="" type="checkbox"/>	1	10	1	1;2;3;4;5;6;7;8;9;10
<input type="checkbox"/>		<input type="checkbox"/>				

OK Cancel

Using FastReporter 2 Tools

Automatically Documenting Measurement Files (FR2-FC Mode)

- If you are using all of the identifiers, select which values to use in the list. You can modify the ID or start and stop values, indicate whether they will be incremented automatically, and what step value to use if that is the case.



The start and stop values can be either numeric or alphabetic

If you enter items separated by semicolons in the **Values** cell, this is the sequence that will be used for incrementation.

If your selection includes PPM files, OLT, ONT and location identifiers are displayed

If your selection includes OTDR, CD, PMD or OLTS files, Cable ID, Fiber ID, Location and Location B identifiers are displayed.

If your selection includes only iOLM and FIP files, custom identifiers are displayed; you will be able to change their names as needed.

Note: *The information is copied to the selected files only if they contain the corresponding field.*

7. Click **OK**.

Using the Duplicated Measurements Tool (FR2-FC Mode)

Sometimes, you might need to verify if tests were actually performed on fibers and that the analysis or results were not just copied and pasted there for speedy execution purposes. The duplicated measurements tool can help you to quickly locate such files.

When you select at least two measurement files, you can have FastReporter 2 automatically compare them and indicate which files show the same acquisition time, measurement wavelength and module serial number. These files can then be selected automatically so you do not have to look for them through your list, and batch processed.

Note: *For the FIP, the application will match the fiber ID, test configuration name and test date/time of the measurement to mark the measurements as duplicated.*


Note: *In the case of bidirectional OTDR files, both directions are analyzed separately.*

Using FastReporter 2 Tools

Using the Duplicated Measurements Tool (FR2-FC Mode)


To search for duplicated information in files:

1. Open the files on which you want to use the tool.
2. Select the desired measurements.



3. Select the **Tools menu, then **Duplicate Measurements Tool**.**

The files are analyzed and the result appears on-screen. The duplicate measurement tool will display the unit serial number, test date/time, identifiers, and filename details.



4. By clicking **Select Duplicate Measurements, you will automatically pick the detected files in the **Measurements** tab.**


5. Proceed with any batch operation you want to perform for those files.

15 Exporting Data for Postprocessing (FR2-FC Mode)

FastReporter 2 can issue data files in a simplified, raw format for further data processing purposes. The data is put in a Microsoft Excel (.xls) format.


To export data:

1. Select measurements or files in the **Measurements** or **Files** tab.
2. On the **Tools** menu, click **Report**.
3. If needed, select the location where to save the data.




Exporting Data for Postprocessing (FR2-FC Mode)


4. In the **Template** list, select a data export template.



5. In the **File Name** box, type a name for the data file.



6. In the **File Type** list, select **.xls**.



7. Click **OK**.

16 *FastReporter 2 Examples*

This chapter walks you through the tasks required to create and modify projects, reports, and templates. Detailed procedures are provided for creating the following examples:


- *Creating an OTDR Bidirectional project:* Create an OTDR project with OTDR traces going in both directions (that is, from A to B and from B to A).
- *Creating a fiber characterization report:* Create a printed or electronic fiber characterization report based on selected measurements.
- *Creating a project template:* Create a project template containing the properties and settings that you often use in your projects.

Creating an OTDR Bidirectional Project

You can change the directions of the OTDR files and create bidirectional projects.

To create an OTDR Bidirectional project:

1. On the **File** menu, point to **New**, and click **Project**.
2. In the list, click the template you want to use.




3. Click **OK**.
4. On the **File** menu, click **Open File**.
5. Select the OTDR files to be added to the project. The selected files are highlighted.
6. Click **Open**.
7. In the **Files** window, select the file or files for which you want to change the direction.
8. On the **File** menu, point to **Direction**, and click **A->B** or **B->A**.

Creating a Fiber Characterization Report

Throughout the network life cycle, fiber characterization reports are essential for avoiding delays in service provisioning before system component installation, in results comparison for post-installation troubleshooting, and in ongoing network analysis and trending.

To create a fiber characterization report:

1. On the **File** menu, point to **New**, and click **Project**.
2. In the list, click the template you want to use.



3. Click **OK**.
4. On the **File** menu, click **Open File**.
5. Select multiple CD, OLTS, PMD, iOLM or OTDR files.


Note: *You must select files with matching fiber IDs and Cable IDs.*

6. Click **Open** to add the selected files to the project.
7. On the **Settings** menu, click **Project Settings**.
8. Click the **File Matching** tab.

FastReporter 2 Examples


Creating a Fiber Characterization Report

- Click **By information present in the file**.



- Click **OK**.


- In the **Measurements** window, select the measurements you want to include in the report.



- To print or create an electronic version of the report, follow the appropriate procedure below.

To print the report:

- 1.** On the **File** menu, click **Print**.
- 2.** If needed, change the printer settings.
- 3.** In the **Template** list, select **Fiber Characterization**.




- 4.** Click **OK**.

FastReporter 2 Examples


Creating a Fiber Characterization Report

To create an electronic version of the report:


1. On the **Tools** menu, click **Report**.
2. To change the destination folder, click , select a folder on the **Browse for Folder** dialog box, and click **OK**.



3. Select a file type for your report. You can select between Excel, PDF and HTML.




4. In the **Template list, click **Fiber Characterization**.**



(Example shown for Excel format)

5. In the **File Name box, type a name for the report.**




Creating a Project Template

You can save the properties and settings you often use when creating projects in a project template. For example, you can save the pass/fail thresholds that you often use in your OTDR projects in an OTDR project template.


To create a project template:

- 1.** On the **File** menu, point to **New**, and click **Project**.
- 2.** In the list, click a template. Use an existing template that already contains some of the properties and settings that you want to use as a starting point, if applicable.



- 3.** Click **OK**.

4. On the **Settings** menu, click **Project Settings**.




5. Under the **Identification** tab, enter the information to identify your template. Click into each item to activate it, then type in the information.
6. When you have finished making changes to the project properties, click **OK**.
7. On the **File** menu, click **Save Project As Template**.

FastReporter 2 Examples

Creating a Project Template

8. In the **File name** box, type a name for the project template file.




IMPORTANT

FastReporter 2 automatically saves project templates in the Project Template folder. If you change the location, the template will not be available for selection in the New Project dialog box when you start a new project.

9. Click **Save**.
10. On the **File** menu, point to **New**, and click **Project**.

- 11.** To set the new project template as the default template, click the file name, and click **Set as Default**.



- 12.** Click **OK** to start a new project or **Cancel** if you do not wish to start a new project at this time.

17 **Troubleshooting**

The table below presents common problems and their solutions.

Problem	Solution
I have trouble installing the application	<ul style="list-style-type: none">➤ Remove the old version before installing the new version.➤ Turn off your anti-virus program and try to install the application again.
I cannot see my files in the application	<p>Some file formats, such as CD and PMD, or older OTDR files, cannot be viewed in the 64-bit version of the application. Try to open them in the 32-bit version of the application.</p> <p>In the case of the older OTDR files, you can try to save them in a newer format in the 32-bit version of the application, then open them in the 64-bit version of the application.</p>

Consulting the Online Help

Help for FastReporter 2 is available directly in your application.

To display online help:

On the **Help** menu, click **Help on FastReporter 2**.

OR

Press the F1 key.

Troubleshooting

Contacting the Technical Support Group

Contacting the Technical Support Group

To obtain after-sales service or technical support for this product, contact EXFO at one of the following numbers. The Technical Support Group is available to take your calls from Monday to Friday, 8:00 a.m. to 7:00 p.m. (Eastern Time in North America).

Technical Support Group

400 Godin Avenue
Quebec (Quebec) G1M 2K2
CANADA

1 866 683-0155 (USA and Canada)
Tel.: 1 418 683-5498
Fax: 1 418 683-9224
support@exfo.com

For detailed information about technical support, and for a list of other worldwide locations, visit the EXFO Web site at www.exfo.com.

If you have comments or suggestions about this user documentation, you can send them to customer.feedback.manual@exfo.com.

A ***Description of Event Types***

This section describes all types of events that may appear in the events table generated by the application. Here is a guide to the descriptions:

- Each type of event has its own symbol.
- Each type of event is represented by a graph of a fiber trace, which illustrates the power reflected back toward the source as a function of distance.
- An arrow points to the location of the event type in the trace.
- Most graphs show one complete trace; that is, an entire acquisition range.
- Some graphs show only a portion of the entire range to view events of interest more closely.

Description of Event Types

Span Start

Span Start

The Span Start of a trace is the event that marks the beginning of the fiber span. By default, the Span Start is placed on the first event of a tested fiber (typically the first connector of the OTDR itself).

You can make another event the start of the span you want to focus your analysis on. This will set the beginning of the events table at a specific event along the trace.

Span End


The Span End of a trace is the event that marks the end of the fiber span. By default, the Span End is placed on the last event of a tested fiber, and is called the end-of-fiber event.

You can also make another event the end of the span you want to focus your analysis on. This will set the end of the events table at a specific event along the trace.

Short Fibers

You can test short fibers with the application. You can even define a fiber span for short fibers by placing the span start and the span end on the same event.

Continuous Fiber ----




This event indicates that the selected acquisition range was shorter than the fiber length.

- The fiber end was not detected because the analysis process ended before reaching the end of the fiber.
- The acquisition distance range should therefore be increased to a value greater than the fiber length.
- There is no loss or reflectance specified for continuous fiber events.

Description of Event Types

End of Analysis


End of Analysis →



This event indicates that the pulse width used did not provide enough dynamic range to get to the end of the fiber.

- The analysis ended before reaching the end of the fiber because the signal-to-noise ratio was too low.
- The pulse width should therefore be increased so the signal reaches the end of the fiber with a sufficient signal-to-noise ratio.
- There is no loss or reflectance specified for end-of-analysis events.

Non-Reflective Event




This event is characterized by a sudden decrease in the Rayleigh backscatter signal level. It appears as a discontinuity in the downward slope of the trace signal.

- This event is often caused by splices, macrobends, or microbends in the fiber.
- A loss value is specified for non-reflective events. There is no reflectance specified for this type of event.
- If you set thresholds, the application indicates a non-reflective fault in the events table, whenever a value exceeds the loss threshold.

Description of Event Types

Reflective Event


Reflective Event ▮



Reflective events appear as spikes in the fiber trace. They are caused by an abrupt discontinuity in the index of refraction.

- Reflective events cause a significant portion of the energy initially launched into the fiber to be reflected back toward the source.
- Reflective events may indicate the presence of connectors, mechanical splices, or even poor-quality fusion splices or cracks.
- Normally, loss and reflectance values are specified for reflective events.
- When the reflective spike reaches the maximum level, its top may be clipped due to the saturation of the detector. As a result, the dead zone (minimum distance for making a detection or attenuation measurement between this event and a second nearby) may be increased.
- If you set thresholds, the application indicates a reflective fault in the events table, whenever a value exceeds reflectance or connector loss thresholds.

Positive Event




This event indicates a splice with an apparent gain, due to the junction of two fiber sections having different fiber backscatter characteristics (backscatter and backscatter capture coefficients).

Description of Event Types

Launch Level

Launch Level →



This event indicates the level of the signal launched into the fiber.

- The figure above shows how the launch level is measured.


A straight line is plotted using least-square approximation to fit all trace points in the linear area between the first and second detected events.

The straight line is projected toward the Y-axis (dB) until it crosses the axis.

The crossing point indicates the launch level.

- <<<< in the events table indicates that the launch level is too low.

Fiber Section




This symbol denotes a fiber section with no event.

- The sum of all fiber sections contained in an entire fiber trace equals the total fiber length. Detected events are distinct even if they cover more than one point on the trace.
- A loss value is specified for fiber section events. No reflectance is specified for this type of event.
- The attenuation (dB/distance in kilometers) is obtained by dividing the loss by the fiber section length.

Description of Event Types

Merged Event

Merged Event Σ



This symbol denotes an event combined with one or more other events. It also indicates the total loss produced by the merged events following it in the events table.

- A Merged Event is composed of subevents. Only the Merged Event is attributed a number in the events table, not the subevents composing it, if they are displayed.
- *Reflective* events may indicate the presence of connectors, mechanical splices, or poor-quality fusion splices or cracks.
- *Non-reflective* events may indicate the presence of splices, splitters or bendings.
- A reflectance value is specified for all merged events and indicates the maximum reflectance for the merged event. A reflectance value is also displayed for each reflective subevent composing the Merged Event.


- The total loss (Δ dB) produced by the events is measured by plotting two straight lines.
 - The first line is plotted by fitting, through least-square approximation, trace points in the linear area preceding the first event.
 - The second line is plotted by fitting, through least-square approximation, trace points in the linear area following the second event. If there were more than two merged events, this line would be plotted in the linear area following the last merged event. This line is then projected toward the first merged event.
 - The total loss (Δ dB) equals the power difference between the point where the first event begins (point A) and the point on the projected straight line located just below the first event (point B).
 - No loss value can be specified for the subevents.

Description of Event Types

Merged Event

Pass/Fail Tests

As an example about pass/fail tests, let us consider the situation below:



Merged sub-events:

2 reflective losses
1 non-reflective loss

Thresholds:

Reflective loss: 0.5 dB
Non-reflective Loss: 0.2 dB

For a merged event, it is possible to determine the global event loss, but not the contribution of each sub-event. This is why the pass/fail test may sometimes lead to “false positive” or “false negative” results.

When evaluating event status against thresholds, we are faced with two possible conditions:

- All event types are tested (reflective, non-reflective)
- Only some event types are selected (for example, you could decide not to test reflective loss)


The third case would be to test none of the event types, which means the same as not wanting to know the status of the events.

All Event Types Are Tested

In the first case, where all event types are tested, the pass/fail conditions are as follows:

- If the event loss is less than or equal to the smallest threshold value, then the event status is *Pass*.
- If the event loss is greater than the sum of the number of sub-events of a type, multiplied by the threshold value for this event type, then the event status is *Fail*.
- If the event loss is “in between”, since it is not possible to know exactly the weight of a sub-event in the merged event, the global event is considered to have a status of *Pass*.

Pass/Fail Analysis



Fail Level

$$\begin{aligned}
 &= \sum(N_{\text{sub}} \times Th_{\text{sub}}) \\
 &= (2 \times 0.5) + (1 \times 0.2) \\
 &= 1.2
 \end{aligned}$$

If the merged event loss is smaller than or equal to 1.2, then the status is *Pass*. Otherwise, it is *Fail*.


Description of Event Types

Merged Event

Not All Event Types Are Tested

In this situation, the only thing that we can clearly know is when the loss has a *Pass* status. If the global event loss is less than or equal to the smallest threshold value (a value that is tested, of course), we are sure that the merged event status is *Pass*. Otherwise, we cannot know, so the status of the event is *Unknown*.

In our example, if we suppose that you chose not to test non-reflective losses, then the analysis would be done as shown below:



Effect of Event Status in the Global Trace Status


- A trace status is, by default, set to *Unknown*.
- If a trace is set to *Fail* once, it remains with that status (it cannot be set back to *Pass* or *Unknown*).
- Whenever an event status is *Fail*, so is the trace status.
- If an event status is *Pass*, the trace status can change from *Unknown* to *Pass*.
- If an event status is *Unknown*, the trace status remains the same. In other words, the event, in this case, has no influence on the trace status.

To avoid *Unknown* statuses, do not unselect loss thresholds individually.

Description of Event Types

Echo


Echo Π_{nr}



This symbol indicates that a reflective event has been detected after the end of the fiber.

- In the example above, the launched pulse travels up to the end connector and is reflected back toward the OTDR. Then, it reaches the second connector and is reflected again toward the end connector. It is then reflected back to the OTDR.
- The application interprets this new reflection as an echo because of its characteristics (reflectance and particular position with respect to other reflections).
- The distance between the second connector reflection and the end connector reflection is equal to the distance between the end connector reflection and the echo.
- There is no loss specified for echo events.

Reflective Event (Possible Echo)



This symbol indicates a reflective event that can be a real reflection or an echo produced by another stronger reflection located closer to the source.

- In the example above, the launched pulse hits the third connector, is reflected back to the OTDR and reflected again into the fiber. It then reaches the third connector a second time and is reflected once more to the OTDR.

The application would therefore detect a reflective event located at twice the distance of the third connector. Since this event is almost null (no loss), and since its distance is a multiple of the third connector distance, The application would interpret it as a possible echo.

- A reflectance value is specified for reflective events (possible echo).

Description of Event Types

Coupler

Coupler

This symbol indicates that the event is a coupler port.

A coupler port is an optical fiber device with one or more input fibers and one or several output fibers. This device is associated with a minimum loss value; for example, a 1 1x2 coupler has a loss of 3 dB.

Any event can be set as a coupler port in the application. However, once an event is set as a coupler port, its loss threshold cannot be applied anymore, but its loss is taken into account in the total loss value.

If you are using a tunable OTDR, the OTDR analysis automatically sets the span start and span end events as coupler ports if their losses are greater than 1.5 dB.

B *Measuring Chromatic Dispersion: Theory*

EXFO's Chromatic Dispersion Analyzer applies the phase-shift method, which consists of measuring the phase variation of a sinusoidal intensity modulated signal at a specific wavelength to obtain the relative group delay of a fiber. The derivative of the relative group delay calculated from fitted equations on computed results gives the dispersion, the zero-dispersion wavelength and the dispersion slope.

Method behind the Chromatic Dispersion Analyzer

In EXFO's Chromatic Dispersion Analyzer, the light source is a broadband source, which is intensity modulated at a high frequency. This light is injected into the fiber under test and the modulated light travels along the fiber. The high-frequency intensity modulation propagates at a speed that depends on wavelength and polarization. Values are obtained for the differences in travel time between modulations at different wavelengths. The higher the number of wavelengths at which this is done, the more accurate the chromatic dispersion results will be.

The first fixed filter in the receiver extracts the portion of the light that will follow an optical path. A second filter, which is a time-tunable filter, will extract a second part of the original signal and then follow a different optical path.

Different path combinations are added using a chopper. The amplitude of the high-frequency signals are measured and digitized. The phase difference is then computed using the different amplitudes. This value is stored along with the tunable filters position and a new measurement cycle begins. A new time delay is computed and stored with wavelength data. When sufficient data is accumulated, chromatic dispersion can be computed.

Measuring Chromatic Dispersion: Theory

Using Data Fits to Obtain Dispersion

Using Data Fits to Obtain Dispersion

This section gives you details about the way EXFO uses the data fits to obtain dispersion. Once group delays are computed, equations are fitted in order to obtain dispersion, dispersion slope and zero-dispersion wavelengths. The dispersion curve of typical singlemode fibers follows certain equations used to interpolate zero-dispersion wavelength and slope. The following table graph shows the equations applied to singlemode fibers in specific wavelength ranges.

Fiber Type and Wavelength Range	Expression for D
G.652 NDSF 1200 nm ≤ λ ≤ 1600 nm	$\tau(\lambda) = A + B\lambda^2 + C\lambda^{-2}$ $D(\lambda) = 2(B\lambda - C\lambda^{-3})$
G.653 DSF 1500 nm-1600 nm	$\tau(\lambda) = A + B\lambda^2 + C\lambda$ $D(\lambda) = 2B\lambda + C$
G.655 NZDSF up to 1560 nm	$D(\lambda) = \left\{ \left[\frac{D(1560) - D(1530)}{30} \right]^\circ \cdot (\lambda - 1560) \right\} + D(1560)$
G.655 NZDSF 1530 nm-1565 nm (C Band) 1565 nm-1625 nm (L Band)	$D(\lambda) = \left\{ \left[\frac{D(1565) - D(1530)}{35} \right]^\circ \cdot (\lambda - 1565) \right\} + D(1565)$ $D(\lambda) = \left\{ \left[\frac{D(1625) - D(1565)}{60} \right]^\circ \cdot (\lambda - 1625) \right\} + D(1625)$

Measuring Chromatic Dispersion: Theory

Using Data Fits to Obtain Dispersion

Fiber Type and Wavelength Range	Expression for D
G.653 DSF $1200 \text{ nm} \leq \lambda \leq 1600 \text{ nm}$	$\tau(\lambda) = A + B\lambda + C\lambda \ln(\lambda)$ $D(\lambda) = B + C + C \ln(\lambda)$
50/125 $50 \text{ nm} \leq \lambda \leq 1450 \text{ nm}$	$\tau(\lambda) = A + B\lambda^2 + C\lambda^{-2}$ $D(\lambda) = 2(B\lambda - C\lambda^{-3})$
62.5/125 $750 \text{ nm} \leq \lambda \leq 1450 \text{ nm}$	$\tau(\lambda) = A + B\lambda^2 + C\lambda^{-2}$ $D(\lambda) = 2(B\lambda - C\lambda^{-3})$
G.655 NZDSF 1530 nm-1565 nm	$D(\lambda) = \left\{ \left[\frac{D(1565) - D(1530)}{35} \right]^\circ \cdot (\lambda - 1565) \right\} + D(1565)$

Measuring Chromatic Dispersion: Theory

Helping You Manage Chromatic Dispersion

As the previous table demonstrates, specific fits are recommended for specific types of fiber and specific wavelength ranges. Fits should be used carefully when extrapolating parameters to obtain maximum precision.

- The 3-Term Sellmeier applies mostly to standard fibers with single zero dispersion at 1300 nm.
- The 5-Term Sellmeier has five zero crossings. Since it is extremely elastic, it should be used with caution when extrapolating because the fit may curve away from the true results beyond fitted points.
- The same warning applies to the cubic fit.
- The lambda-log-lambda fit is applicable to dispersion-shifted fibers with a zero dispersion wavelength in the 1550 nm wavelength region.
- The linear fit is useful when there are too few measurements for multiple parameter fits to be used. It is applicable to all fibers if the range is sufficiently small.

The fits will give you a tool to obtain the dispersion slope and zero-dispersion point.

Helping You Manage Chromatic Dispersion

The zero-dispersion wavelength (where dispersion is at zero) corresponds to the wavelength point at which the fiber under test reaches its maximum bandwidth. The slope from this zero-dispersion point indicates how fast dispersion rises as wavelength increases. Key chromatic dispersion parameters are the dispersion zero and the slope at zero dispersion.

Getting precise chromatic dispersion parameters helps you choose the right dispersion-compensated fiber or material in order to reverse the dispersion and dispersion slope before the data is interpreted by the receiver at the other end of the line.

The effects of chromatic dispersion decrease with a reduction in the absolute value of the fiber chromatic dispersion or with dispersion compensation.

C **Measuring Polarization Mode Dispersion: Theory**

The dispersion phenomenon is described as a number of non-intensity-dependant physical occurrences resulting directly in signal loss (pulse spreading or time jitter in a digital system; distortion in an analog system). PMD is an important type of signal dispersion. As unrepeated link distances are increased and transmission rates pushed upwards, PMD can significantly reduce system performance.

To better understand the impact of PMD, consider the example of a pulse passing through a wave plate. Upon entering the wave plate, the pulse is decomposed into polarization components aligned with each of the two birefringent axes of the plate (known as the fast and slow axes). The components propagating independently through the wave plate at different group velocities will recombine at the end of the wave plate as a superposition of two pulses split in time.

The delay between those pulses is designated as the differential group delay (DGD) and is written as $\delta\tau$. For a Gaussian, unchirped input pulse of rms width σ_0 , the rms width at the output is given by

$$\sigma^2 = \sigma_0^2 + r_0(1 - r_0) \cdot \delta\tau^2$$

where r_0 is the fraction of the input-pulse energy launched into one of the birefringence axes.

Worst-case spreading occurs when the signal is perfectly split in two ($r_0 = 1/2$), while no spreading occurs if the input state of polarization (SOP) of the launched signal is aligned with one of the birefringence axes.

To generalize this example, consider a long, weakly birefringent telecommunications fiber as a concatenation of many, randomly orientated birefringent wave plates. Each interface between two wave plates redistributes the optical energy along both axes of the subsequent wave plate. This transfer of energy is called mode coupling.

Measuring Polarization Mode Dispersion: Theory

In a long fiber, numerous mode-coupling events occur along the fiber length, so that light emerging from the output end is the superposition of a number of pulses with different delays. Nonetheless, it turns out that for any given optical frequency, ω , one can always find two orthogonal input principal states of polarization (PSPs) such that a light pulse with the same input SOP as the input PSP, undergoes no spreading. For a single wave plate, the PSPs are the two birefringent axes, whereas for a concatenation of wave plates, neither the input nor the output PSPs correspond to the alignment of the birefringent axes anywhere.

Contrary to the case of a wave plate, the DGD and PSPs of a long fiber are dependent on wavelength and fluctuate in time as a result of environmental variations such as temperature, external mechanical constraints, etc. Their behavior is random, both as a function of wavelength at a given time and as a function of time at a given wavelength. Fortunately, this behavior can be characterized statistically. It can be demonstrated that the probability density function of $\delta\tau$ is Maxwellian and, by definition, PMD is its rms value, that is:

$$\text{PMD} = \sqrt{\text{DGD}^2}$$

Note: *PMD is sometimes defined as the mean value of the DGD, which for a Maxwellian distribution yields a value 17 % lower than the rms definition.*

If the average is calculated over ω , PMD is stable in time, provided that the averaging window is sufficiently large ($D\omega dt \gg 1$).

It is essential to keep in mind that DGD fluctuates in time and can be either smaller or larger than its rms value or PMD. This results in a statistical probability that a pulse (information bit) is broadened, and leads to the eventual impaired ability of the receiver to efficiently decode the information. This adverse PMD effect makes it a critical phenomenon in limiting transmission of high-bit-rate information.

In the case of PMD in a long fiber, there is a specific state called input PSP. In this state, when the input SOP of the signal is aligned with one of its axes, it will propagate through the fiber without any spreading or distortion of the signal. This phenomenon is defined as this specific input SOP such that the output SOP is independent of optical frequency. Again, the worst case occurs when the signal is equally split between both input PSPs.

For long telecom fibers with random coupling of energy between modes (that is. $L \gg h$, where h is the coupling length), PMD grows as the square root of the distance, whereas PMD of strong HiBi fiber (negligible mode coupling) is directly proportional to the distance. Therefore, the PMD coefficient for negligible mode coupling is expressed as ps/km, while the PMD coefficient for random mode coupling is defined as ps/km^{1/2}.

D *Report Samples*

This section presents samples of some reports you can generate using FastReporter 2. Keep in mind that those reports are samples and your final results may differ depending on the options and number of files you have selected. Various other report types are also available for your other testing needs.

Bidirectional OTDR

OTDR Bidirectional Report

General Information Bidir 1310nm

Filename: Bidir0001_1310.bdr Cable ID: 0022
Test date: 4/12/2007 Fiber ID: 0001
Test time: 10:26 PM (GMT+05:30) Customer:
Job ID: Company:

Location A

Location:
Operator:
Unit model: S7300D
Unit s/n:
Calibration date:

Location B

Location:
Operator:
Unit model: S7300D
Unit s/n:
Calibration date:

OTDR Bidir Thresholds

Description	Fail	Warning
Bidir splice loss	1.000 dB	1.000 dB
Connector loss	1.000 dB	1.000 dB
Reflectance	-40.0 dB	-40.0 dB
Fiber section attenuation	0.400 dB/km	0.400 dB/km
Span loss	45.000 dB	45.000 dB
Span length	0.0000 km	0.0000 km
Span ORL	15.00 dB	15.00 dB

Signature: _____ Date: 12/13/2012

Page 1 of 7

OTDR

OTDR Report

General Information

Filename: 1310_1550_1625_MacroBend.trc Cable ID: 1
 Test date: 3/28/2007 Fiber ID: 4
 Test time: 11:02 PM (GMT+05:30) Customer:
 Job ID: Company:

Comments:

Location A

Location: 3
 Operator:
 Unit model:
 Unit s/n:
 Calibration date:

Location B

Location: 4
 Operator:
 Unit model: S7300D
 Unit s/n:
 Calibration date:

OTDR Thresholds

Description	Fail	Warning
Unidir splice loss	1.000 dB	1.000 dB
Connector loss	1.000 dB	1.000 dB
Reflectance	-40.0 dB	-40.0 dB
Fiber section attenuation	0.400 dB/km	0.400 dB/km
Span loss	45.000 dB	45.000 dB
Span length	0.0000 km	0.0000 km
Span ORL	15.00 dB	15.00 dB

Signature: _____ Date: 12/13/2012

Page 1 of 9

Report Samples

Fiber Characterization

Fiber Characterization

Fiber Characterization Report

General Information

Cable ID: Cable001

Customer: TopNetWork; Rediff;

Company: ExpertCable; india; ; Expert

Fiber Characterization

Fiber ID	CD @ 1550 nm		PMD		OLTS							OTDR		
	Dispersion (ps/nm)	Coef. (ps/nm ² km)	Delay (ps)	Coef. (ps/km ^{1/2})	Wave length (nm)	Loss A->B (dB)	Loss B->A (dB)	Average Loss (dB)	ORL A->B (dB)	ORL B->A (dB)	Length (km)	Length (km)	Max Splice (dB)	Avg Splice (dB)
Fiber001;	201.366	17.419	2.2010	0.5502	1310	---	---	---	>3.00	-Infinity		8.4921		
					1450	0.00	---	---	-Infinity	-Infinity				
					1480	-0.03	---	---	-Infinity	-Infinity				
					1490	---	-41.30	---	-Infinity	111.29	0.005			
					1550	-49.52	-41.70	-47.18	100.00	112.39	0.005	8.4936	0.032	0.021
					1625	-49.80	---	---	100.00	-Infinity	0.005	0.0000	0.585	0.585
Fiber001;						---	---	---						

Fiber Inspection Probe

EXFO FIP Report ❌ Fail

General Identification

Filename:	Single_fiber_Single_mode_Connector_Analysis_FAIL_defects_3.cmax2	Test time:	3:08 PM (GMT-05:00)
Test date:	9/24/2010	Customer:	
Job ID:	001-00022	Operator:	
Company:		Unit s/n:	12-23456
Unit Model:	FIP-410B		

Comments:

Identification

Cable ID:	Cable001	Connector ID:	
Fiber ID:	Fiber002	Location:	Paris


Test Parameters

Configuration:	IEC-61300-3-35 Single-Mode Single-Fiber PC Connector with ORL \geq 45 dB		
Connector type:	(SF) Single-Fiber connector	Ratio fail/pass:	1/0
Fiber type:	(SM) Single-Mode fiber	Number of fibers:	1
Polishing type:	(PC) Physical contact	Analysis mode:	Manufacturing


Measurement Information ❌

Fiber ID:	Fiber002	Test time:	3:08 PM (GMT-05:00)
Focus level:	59% (Nominal)		

Graphics A->B



Image



Overlay

❌ Fail

EXFO Signature: _____ Date: 12/3/2013 Page 1 of 2

Report Samples

iOLM

iOLM

iOLM Report



General Information

Filename: 1310 1490 1550 Close events.iolm
Test date: 1/20/2012
Test time: 9:14 AM (GMT-05:00)
Job ID:
Company:
Comments:

Customer:
Operator:
Unit model: FTB-730-236B-EA
Unit S/N: 574715
Calibration date: 10/4/2011

Identifiers

Cable ID	Fiber ID	Location A	Location B	None
	1			

iOLM Results

Wavelength (nm)	Link loss (dB)	Link ORL (dB)	Propagation delay (µs)
1310	3.470	19.62	---
1490	2.845	20.05	---
1550	2.749	20.73	---

Link length: 1.4905 km
Acquisition status: Completed

iOLM Pass/Fail Thresholds

	1310 nm	1490 nm	1550 nm
Max. link loss	45.000 dB	45.000 dB	45.000 dB
Min. link loss	0.000 dB	0.000 dB	0.000 dB
Max. link ORL	15.00 dB	15.00 dB	15.00 dB
Max. splice loss	1.000 dB	1.000 dB	1.000 dB
Max. connector loss	1.000 dB	1.000 dB	1.000 dB
Reflectance	-40.0 dB	-40.0 dB	-40.0 dB

Max. link length: 10.000 km
Min. link length: 0.0000 km

iOLM Test Parameters

Wavelength(s): 1310 nm; 1490 nm; 1550 nm

iOLM Test Settings

Launch fiber length: 0.0000 km
Receive fiber length: 0.0000 km
Fiber core size: 9 µm

IOR: 1.468325
Backscatter: -81.87 dB



Signature: _____

Date: 12/4/2013

Page 1 of 2

OTDR Advanced Cable (Excel Template)

This report displays various information related to the OTDR Advance cable, such as: Cable information, Measurement information, Fail report, Length, Reflectance, Splice and reflectance, Splice loss, Attenuation, and Loss.

Security Warning				
Macros have been disabled. Options...				
A1 Cable Information				
A	B	C	D	E
Cable Information				
2	Test Date:	1/25/2012		
3	Fiber Type:	9 micron singlemode		
4	Number of fiber:	1		
6	Operator A:			
7	Location A:			
8	Operator B:			
9	Location B:			
Unit Information				
		Location A	Location B	
13	Model:	FTB-730-236B-EA (iOLM)		
14	Serial Number:	574712		
15	Calibration Date:	10/6/2011		
16				
17				
18				
19				
20				
21				
22				
23				
24				


Navigation tabs: Cable Information | Measurement Information | Fail Report | Length | Reflectance | Splice and reflectance | Splice loss | Attenuation | Loss

Report Samples

iOLM + FIP (Excel Template)

iOLM + FIP (Excel Template)

This report displays the iOLM and FIP measurement values in single report based on matching. If multiple measurements are selected, the report displays multiple worksheets for the each of the selected measurements. The worksheets are labeled as iOLM + FIP (n). Where, (n) represents the measurement number.



iOLM Bidirectional (Excel Template)

This report displays the Bidirectional measurement with corresponding unidirectional measurements A-B and B-A.

Identification Information										
Filename:	Link with group - 3WL - A-B iolmldr				Customer:	EXFO				
Test date:	12/9/2013				Company:	EXFO				
Test time:	10:57 AM (GMT-05:00)				Operator:	EXFO				
Job ID:	ID 1233									
Comments:										
Location A					Location B					
Unit model:	FTB-730-023B-04B-OPM2-EA				Unit model:	FTB-730-023B-04B-OPM2-EA				
Unit s/n:	SIMFTB0578				Unit s/n:	SIMFTB0578				
Calibration Date:	10/19/2010				Calibration Date:	10/19/2010				
Identifiers										
Cable ID	Fiber ID	Location A	Location B	None						
Cable 002	Fiber 005	OE	EO							
IOLM BDR Results										
Wavelength (nm)	1310	1550	Link Length (km): 2.0009							
Link loss (dB)	13.075	12.791	Acquisition status: Completed							
			Analysis Version: 2.6.0.1132							
IOLM BDR Pass/Fail Thresholds										
	1310 nm	1550 nm								
Max. link loss (dB)	45.000	45.000	Max. link length (km):				10.000			
Min. link loss (dB)	0.000	0.000	Min. link length (km):				0.0000			
Max. splice loss (dB)	1.000	1.000								
Max. connector loss (dB)	1.000	1.000								
Reflectance (dB)	-40.0	-40.0								
IOLM BDR Test Parameters										
Wavelength(s) (nm):	1310,1550,1625									
IOLM BDR Test Settings										

Report Samples

iOLM Advanced Cable Report (Excel Report)

iOLM Advanced Cable Report (Excel Report)

This report shows detailed information for your cables. Each category of the report (cable information, measurement information, fail report, summary results, link elements, splice elements, connector elements, A & B elements, and attenuation section) is on a separate sheet.

1 2 3 4 5	A Identifiers	B Wavelength (nm)	Element Connector 0.0570 (km)						Element Connector 0.0537 (km)						Element 1 Connector (A) 0.0000 (km)					
			Loss (dB)			RefI (dB)			Loss (dB)			RefI (dB)			Loss (dB)			RefI (dB)		
			A>B	B>A	Avg.	A>B	B>A	Worst	A>B	B>A	Avg.	A>B	B>A	Worst	A>B	B>A	Avg.	A>B	B>A	Worst
6	1	1310	---	---	---	-76.9	---	---	---	---	---	---	---	0.952	0.143	0.602	-55.5	---	---	
8	1	1310												0.143	0.143	-74.5	-74.5			
10	1	1550	-0.029		-0.029	---			0.226			0.226	-67.8		0.570	-66.6	-66.6			
12	1	1550														-73.3	-73.3			
14	1	1310												0.918	0.918	-74.9	-74.9			
16	1	1625												0.574	0.574	-48.1	-48.1			
18	1	1550												0.678	0.678	-72.0	-72.0			
20																				
21																				
22																				
23																				
24																				
...																				

Index

- 2:N splitters..... 298
- A**
- A-B
- LSA loss 157
 - OTDR trace direction..... 43
- absolute
- lengths, span positions..... 174
 - power unit..... 230
- activating product..... 16
- adding
- elements..... 287
 - files to project..... 43
- adding elements automatically 266
- adding events automatically 139
- advanced cable report, iOLM (Excel) 440
- after-sales service 404
- alignment, iOLM alignment..... 251
- analysis range..... 218
- analyzing
- bidirectional measurements, OTDR..... 179
 - measurements, iOLM..... 302
 - measurements, OTDR 171
- appearance, modifying 22
- application, exiting..... 36
- application-related reports..... 351
- applying sorting to other windows 334
- attenuation, OTDR settings 122
- auto template 139, 266
- automatic loopback 61, 77
- automatically
- documenting measurement files 378
 - hiding panes..... 24
 - incrementing values for iOLM..... 326
 - matching files, OTDR 55
 - refreshing folder 59
- available features
- CD..... 5
 - FIP..... 6
 - general..... 2
 - iOLM 6
 - OLTS..... 4
 - OPM and PPM..... 6
 - OTDR..... 3
 - PMD..... 5
- average loss measurement, OLTS..... 201
- B**
- B-A
- axis inverting, OTDR..... 150
 - OTDR trace..... 43
- basic PMD theory 427
- batch documentation, OTDR 187
- bidirectional
- extracting unidirectional files 183
 - iOLM files..... 252, 310
 - loopback..... 77
 - OTDR files 180
 - OTDR measurements..... 179
 - OTDR report..... 432
 - project example 391
 - unidirectional markers in file..... 184
- browser for EXFO Connect 96
- C**
- cable view..... 118, 249
- calibration date for OTDR 328
- caution
- of personal hazard 8
 - of product hazard..... 8
- CD
- analyzer, internal design 423
 - available features..... 5
 - changing analysis range..... 218

Index

- changing fiber length 219
 - fiber type 216
 - files supported 211
 - options 212
 - switching between curve types 220
 - changes, unsaved in project template 46
 - changing
 - connections in link 199, 278
 - core size 177
 - direction, files 50
 - display options 31
 - element matching tolerance 253
 - element type 290
 - fiber length 225
 - iOLM fiber type 277
 - main measurement, OTDR 148
 - measurement identification 325
 - OLTS fiber type 198
 - OTDR file format 188
 - splices in link 200, 279
 - supported measurement types 30
 - checking in files, EXFO Connect 103, 108
 - checking out files, EXFO Connect 103, 104
 - chromatic dispersion
 - coefficient 220
 - factors 426
 - managing 426
 - theory 423
 - clipboard 353
 - closing panes 23
 - coefficient, dispersion 220
 - columns, EXFO Connect 101
 - composition, link 245
 - configuration
 - files, iOLM 305
 - FIP, importing 239
 - OLTS, importing 196
 - settings 308
 - sheet 362
 - connecting to EXFO Connect 94
 - connections in link 199, 278
 - connector 283
 - conventions, safety 8
 - coordinates for FIP file 244
 - copying graph 353
 - core size, changing 177
 - correction factor, power meter 234
 - creating
 - bidirectional files 180
 - iOLM bidirectional file 252
 - project from scratch 37
 - reports 343, 358
 - Crystal reports 358, 359
 - Ctrl key 27
 - current threshold, changing 130
 - curve type, CD 220
 - custom
 - elements 293
 - FasTesT thresholds 202
 - identifiers, FIP 242
 - identifiers, OLTS 197
 - thresholds 260
 - customizing
 - display 22
 - elements for multiple measurements ... 284
 - main window 22
- D**
- data
 - exporting 387
 - transfer applications, handheld 375
 - default template 48
 - deleting
 - elements 292
 - template 48
 - description
 - event types 405
 - main window 22
 - details, elements and sections 281
 - diagnostics
 - iOLM 309
 - OLTS 210
 - direction, OTDR trace 43

-
- discarding check out, EXFO Connect 103
 - display
 - modifying 22
 - options 23, 31
 - panes 23
 - toolbars 23
 - distance, OTDR settings 122
 - documentation
 - batch 187
 - measurement files 378
 - online 403
 - duplicated measurement tool 383
 - dynamic
 - FasTest thresholds 202
 - iOLM thresholds 260
- E**
- editing
 - iOLM element properties 291
 - measurement identification 325
 - OTDR event properties 146
 - elements
 - adding 287
 - aligning, iOLM 251
 - custom 293
 - deleting 292
 - description 283
 - details 281, 284
 - editing, iOLM 291
 - group 286
 - matching tolerance 253
 - matching with a reference 319
 - matching without a reference 320
 - statistics 173, 321
 - types 290
 - enabling
 - 2:N splitters 298
 - bidirectional file creation 252
 - end-of-fiber
 - event 406
 - threshold 171
 - erasing element 292
 - event types
 - description 405
 - continuous fiber 407
 - coupler 422
 - echo 420
 - end of analysis 408
 - end-of-fiber 406
 - fiber section 413
 - launch level 412
 - merged event 414
 - non-reflective event 409
 - positive event 411
 - reflective event 410
 - reflective event (possible echo) 421
 - short fiber 406
 - span end 406
 - span start 406
 - events 153
 - adding to other measurements 164
 - description of types 405
 - editing OTDR 146
 - macroband tolerance 133
 - matching tolerances 121, 136
 - modifying marker 162
 - pulse matching tolerances 138
 - table, options 145
 - zoom on splice 153
 - examples
 - fiber characterization report 391
 - project template 391
 - tasks 391
 - Excel
 - iOLM advanced cable report 440
 - iOLM bidirectional report 439
 - iOLM plus FIP 438
 - OTDR advanced cable report 437
 - reports 344, 358
 - templates 361
 - EXFO Connect
 - browser 96
 - checking in files 103, 108

Index

- checking out files..... 103, 104
- connection information 94
- discarding files..... 103
- exporting files..... 103, 114
- filters 101
- log in 95
- log out..... 95
- searching files..... 98
- undo check out files 106
- uploading files..... 103, 110
- viewing files..... 103, 112
- existing element, launch/receive fibers 300
- exiting FastReporter 2 36
- exporting
 - data 387
 - EXFO Connect files..... 103, 114
 - fiber characterization project..... 42
 - OTDR file to text 189
 - report templates..... 356
- extracting unidir files from bidir file 183

F

- failed items, viewing 172, 302
- FasTesT
 - results 206
 - selecting thresholds..... 202
- FastReporter 2
 - exiting 36
 - installing on a computer..... 10
 - installing on an EXFO platform..... 11
 - starting..... 15
 - uninstalling..... 11
- features for your product..... 2
- fiber
 - changing length 219, 225
 - core size 177, 276
 - type 216
 - view 249

- fiber characterization
 - exporting project 42
 - importing project..... 40
 - report example 391, 434
- fiber inspection probe. *see* FIP
- fiber type
 - iOLM 277
 - OLTS 198
- field of application selection..... 29
- files
 - additional information..... 330
 - bidirectional, iOLM 310
 - changes unsaved 40
 - changing direction..... 50
 - format..... 120, 191, 221, 229, 245
 - format, OTDR..... 188
 - matching rules 121
 - matching, identifiers..... 53
 - measurements 120, 191, 221, 229, 245
 - reference..... 376
 - renaming 40
 - saving 335
 - sorting 332
 - summary information 331
 - supported format 120, 191, 211, 235
 - Telcordia 120
 - test settings, OTDR 178
- filters
 - details 362
 - EXFO Connect 101
 - failed items 172, 302
- FIP
 - application related report 351
 - available features..... 6
 - cable connector view 241
 - configuration file, importing..... 239
 - custom identifiers 242
 - file formats 235
 - geolocation..... 244
 - image..... 240
 - legacy file format..... 243
 - multi-fiber view..... 241

- overlay 240
 - plus iOLM report (Excel)..... 438
 - report 435
 - results 238
 - serial number..... 237
 - thresholds..... 238
 - unit model..... 236
 - fits
 - 3-Term Sellmeier 426
 - 5-Term Sellmeier 426
 - cubic..... 426
 - equations..... 424
 - lambda log lambda 426
 - linear 426
 - fixed
 - FasTesT thresholds..... 202
 - iOLM thresholds 260
 - license..... 18
 - flags 362
 - floating license 18
 - folder auto refresh 59
 - formats, OTDR files 188
 - four points event loss..... 157
 - FTTx mode, iOLM..... 322
 - full graph zoom 151
- G**
- generating
 - measurement reports 345
 - reports 343
 - summary reports 345
 - text files, OTDR measurements 189
 - geolocation for FIP files 244
 - global pass/fail status, OLTS 209
 - graph
 - space between traces 190
 - view, OTDR 117
 - zoom 151
 - graphic
 - display options, OTDR..... 150
 - overlay, fiber inspection probe 240
 - group elements 286
 - grouped view 118, 249
- H**
- handheld data transfer applications 375
 - hiding
 - FIP results..... 238
 - markers..... 156
 - horizontal
 - plus vertical zoom..... 152
 - zoom 151
 - html report..... 344
- I**
- identifiers
 - custom for FIP..... 242
 - custom for OLTS 197
 - file matching..... 53
 - filtering 339
 - labels 275
 - importing
 - configuration file 196, 239
 - fiber characterization project 40
 - FIP file 243
 - report template..... 354
 - information, splitter ratio 274
 - installing FastReporter 2
 - computer 10
 - EXFO platform 11
 - minimum requirements 9
 - inverting B-A dB axis, OTDR..... 150
 - iOLM
 - advanced cable report (Excel) 440
 - analyzing measurements 302
 - application-related report 351
 - auto template 266
 - auto-increment values 326
 - available features..... 6
 - bidirectional files..... 310
 - bidirectional report (Excel) 439
 - cable view 249

Index

- changing number of connections 278
 - changing number of splices 279
 - configuration files 305
 - configuration settings 308
 - customizing elements 284
 - diagnostics 309
 - editing element properties 291
 - element alignment 251
 - element or section details 284
 - enabling bidirectional file creation 252
 - extended element matching tolerance 253
 - fiber core size 276
 - fiber type 277
 - fiber view 249
 - file formats 245
 - FTTx mode 322
 - group elements 286
 - identifier labels 275
 - link view 245
 - matching elements, no reference 320
 - matching link elements, reference 319
 - measurement statistics 173, 321
 - multiple measurements 249
 - pass/fail thresholds 254
 - plus FIP report (Excel) 438
 - report 436
 - section length 318
 - selecting thresholds 260
 - settings 271
 - SOR file 303
 - splitter ratio 274
 - thresholds 260
 - virtual bidirectional files 317
 - IOR value by distance 176
- L**
- labels, identifier 275
 - language selection 28
 - launch fiber existing element 300
 - launching FastReporter 2 15
 - legacy file format, FIP 243
 - length, OTDR settings 122
 - license agreement iii
 - license, activating 18
 - linear view
 - OTDR 117
 - viewing section length 150
 - link
 - grouped 118, 249
 - matching elements 320
 - view 245
 - link view results, OLTS 207
 - locating FIP file on a map 244
 - locking markers 154
 - log in, EXFO Connect 95
 - log out, EXFO Connect 95
 - loopback
 - bidirectional 77
 - unidirectional 61
 - loss
 - OTDR settings 122
 - statistics 173, 321
- M**
- macrobends
 - description 283
 - identification 133
 - tolerances 133
 - viewing 135
 - main measurement, OTDR 148
 - main window, customizing 22
 - managing
 - multiple measurements 249
 - projects 37
 - manual
 - loopback 61, 77
 - matching of OTDR files 57
 - measurement on OTDR markers 156
 - sorting of measurements 332
 - zoom 153

-
- markers
 - adding OTDR event..... 158, 159
 - hiding 156
 - locking..... 154
 - manual measurements, OTDR..... 156
 - modifying position 162
 - OTDR 150, 154
 - retrieving position 165
 - showing..... 156
 - unidirectional from bidirectional 184
 - zoom 153
 - matched measurements, statistics..... 173, 321
 - matching
 - identifiers for files..... 53
 - link elements 319, 320
 - OTDR files 51, 55, 57
 - tolerance, elements 253
 - measurement files, auto documenting..... 378
 - measurements
 - adding event 164
 - analyzing 171, 302
 - changing direction..... 50
 - copying graph 353
 - duplicated 383
 - editing identification 325
 - files..... 120, 191, 221, 229, 245
 - generating text files, OTDR 189
 - OTDR bidirectional..... 179
 - printing reports 350
 - reference 376
 - reports, generating..... 345
 - reports, overview 343
 - saving files 335
 - sorting 332
 - statistics..... 226
 - types..... 30
 - measuring chromatic dispersion..... 423
 - menus, accessing 27
 - minimum requirements..... 9
 - mismatch 283
 - model number, FIP..... 236
 - modifying
 - additional information on file 330
 - application display 22
 - element type..... 290
 - marker position..... 154
 - measurement identification 325
 - OTDR calibration date..... 328
 - reports 358
 - summary information 331
 - monitors..... 26
 - moving
 - items between monitors 26
 - pane..... 25
 - toolbars 24
 - multiple items, selecting..... 27
 - multiple measurements
 - customizing elements 284
 - managing 249
 - viewing section length 318
- N**
- navigating the graph window, OTDR..... 151
 - new element..... 287
 - number, FIP 236
- O**
- OLTS
 - adding/removing wavelengths..... 192
 - available features 4
 - average loss 201
 - changing number of connections 199
 - changing number of splices 200
 - configuration file, importing..... 196
 - custom identifiers 197
 - diagnostics..... 210
 - display unit for reference value..... 195
 - FasTesT results 206
 - FasTesT thresholds 202
 - fiber type 198
 - file formats 191
 - link view results 207

Index

- loss calculation method..... 201
 - pass/fail status information 209
 - results..... 244
 - settings..... 192
 - worse loss..... 201
 - online help 403
 - opening
 - handheld data transfer applications 375
 - project 39
 - related analysis tools 375
 - OPM
 - available features..... 6
 - correction factor..... 234
 - settings..... 231
 - optical tests possible 1
 - options
 - activating..... 18
 - CD 212
 - event table view, OTDR..... 145
 - PMD..... 222
 - ORL thresholds 202
 - OTDR
 - absolute span positions 174
 - adding event to other measurements.. 164
 - adding event with all markers 159
 - advanced cable report (Excel) 437
 - analyzing measurements 171
 - application-related report..... 351
 - apply reference as template..... 166
 - auto template..... 139
 - available features..... 3
 - batch documentation 187
 - bidirectional measurements..... 179
 - bidirectional project example 391
 - bidirectional, report..... 432
 - cable view..... 118
 - calibration date 328
 - changing file format..... 188
 - changing main measurement 148
 - creating bidirectional files 180
 - current measurement thresholds..... 130
 - editing event properties 146
 - event matching tolerances..... 121, 136
 - event table view options..... 145
 - event with one marker..... 158
 - fiber core size..... 177
 - file formats 120
 - file test settings 178
 - generating text files 189
 - graph 117
 - graphic display options..... 150
 - inverting B-A dB axis..... 150
 - IOR value by distance 176
 - linear..... 117
 - macrobend tolerances 133
 - marker position..... 165
 - markers..... 150, 154
 - markers, manual measurements 156
 - matching files 51
 - matching files automatically 55
 - matching files manually 57
 - modifying marker position..... 162
 - outside spans..... 150
 - pass/fail thresholds 121, 127
 - pulse baseline 121
 - pulse tolerance value 138
 - report..... 433
 - section length 150
 - settings 121
 - SOR file 303
 - trace direction..... 43
 - viewing method..... 119
 - virtual bidirectional files..... 186
 - zoom functions..... 151
 - out of range element..... 283
 - outside spans, OTDR..... 150
 - overview, link 245
- P**
- panes
 - auto-hiding..... 24
 - closing 23
 - display 23

Index

- exporting templates 356
- fiber characterization..... 434
- FIP..... 435
- formats..... 344
- importing template 354
- iOLM..... 436
- iOLM advanced cable report (Excel) 440
- iOLM bidirectional (Excel) 439
- iOLM plus FIP (Excel)..... 438
- measurement..... 343
- modifying 358
- OTDR 433
- OTDR advanced cable (Excel) 437
- previewing..... 349
- printing 350
- summary..... 343
- requirements for installing FastReporter 2 9
- resizing panes 23
- results
 - FasTesT 206
 - iOLM..... 271
 - link view 207
 - OLTS 244
 - power meter..... 244, 310
- reverting to file test settings 178
- right-clicking in menus..... 27

S

- safety
 - caution 8
 - conventions 8
 - warning 8
- saving
 - measurement files 335
 - OTDR file in a different format 188
- searching files, EXFO Connect 98
- section details
 - customizing 284
 - viewing..... 281, 284

- section length
 - linear view 150
 - multiple measurements 318
- sections
 - editing element properties..... 291
 - editing event properties..... 146
 - statistics..... 173, 321
- selected event, zoom..... 152
- selecting
 - FasTesT thresholds 202
 - field of application..... 29
 - language..... 28
 - multiple items 27
 - thresholds..... 260
- serial number, FIP..... 237
- server for EXFO connect 94
- settings
 - application 12
 - CD..... 212
 - configuration 308
 - display 22
 - OLTS 192
 - OPM/PPM..... 231
 - OTDR..... 121
 - OTDR file tests..... 178
 - PMD..... 222
- sheet
 - details 362
 - universal 374
- Shift key 27
- showing
 - FIP results..... 238
 - markers..... 156
- software customization wizard 12
- SOR file..... 303
- sorting
 - files 334
 - measurements 332
- space between traces 190
- span end
 - description 406
 - excluded 129

Index

U

undoing check out, EXFO Connect	106
unidirectional	
files from bidirectional file	183
loopback	61
marker from bidirectional file	184
uninstalling FastReporter 2	11
universal sheet	374
unsaved changes	40
Update Manager	9
uploading files, EXFO Connect	103, 110
user guide	403
user interface language	28

V

vertical zoom	152
viewing	
EXFO Connect files	103, 112
failed items	172, 302
macrobends	135
method, OTDR	119
OLTS results	244
online help	403
power meter results	244, 310
section length	150, 318
views	
cable	118, 249
fiber	249
identifiers	339
link	245
section length	150, 318
virtual bidirectional files	
iOLM	317
OTDR	186

W

warranty	iii
wavelength	
adding and removing	192
adding to OLTS project	192

OTDR main measurement	148
table	215
windows, sorting	334
working with two monitors	26
worse loss measurement, OLTS	201

Y

Y spacing	190
-----------------	-----

Z

zero-dispersion wavelength, definition	426
zoom	
event reflectance	153
event splice	153
four markers	153
full graph	151
horizontal	151
horizontal plus vertical	152
manual	153
OTDR functions	151
selected event	152
undo	153
vertical	152

P/N: 1071150

www.EXFO.com · info@exfo.com

CORPORATE HEADQUARTERS	400 Godin Avenue	Quebec (Quebec) G1M 2K2 CANADA Tel.: 1 418 683-0211 · Fax: 1 418 683-2170
EXFO AMERICA	3400 Waterview Parkway Suite 100	Richardson, TX 75080 USA Tel.: 1 972-761-9271 · Fax: 1 972-761-9067
EXFO EUROPE	Winchester House, School Lane	Chandlers Ford, Hampshire S053 4DG ENGLAND Tel.: +44 2380 246 800 · Fax: +44 2380 246 801
EXFO ASIA-PACIFIC	62 Ubi Road 1, #09-01/02 Oxley Bizhub 2	SINGAPORE 408734 Tel.: +65 6333 8241 · Fax: +65 6333 8242
EXFO CHINA	Beijing Global Trade Center, Tower C, Room 1207, 36 North Third Ring Road East, Dongcheng District	Beijing 100013 P. R. CHINA Tel.: +86 (10) 5825 7755 · Fax: +86 (10) 5825 7722
EXFO SERVICE ASSURANCE	270 Billerica Road	Chelmsford MA, 01824 USA Tel.: 1 978 367-5600 · Fax: 1 978 367-5700
EXFO FINLAND	Elektroniikkatie 2	FI-90590 Oulu, FINLAND Tel.: +358 (0) 403 010 300 · Fax: +358 (0) 8 564 5203
TOLL-FREE	(USA and Canada)	1 800 663-3936

© 2017 EXFO Inc. All rights reserved.
Printed in Canada (2017-03)

